

**JLR-7500/7800  
NWZ-4740**

---

**GPS NAVIGATOR**

**INSTRUCTION  
MANUAL**



*Japan Radio Co., Ltd.*



## **Foreword**

Thank you for purchasing the JRC GPS Navigator JLR-7500/7800.

This equipment is a high-performance navigation equipment consisting of a DGPS/GPS sensor and navigator, can retrieve the position data using the DGPS/GPS sensor to display various navigation information on the display.

- Thoroughly read this instruction manual before operating the equipment.
- Keep this manual nearby the equipment to allow ready access to it if necessary. It may provide valuable information on how to deal with a given situation that may arise during the operation.

## Before Commencing the Operation

### Symbols

Several symbols are used in this manual to ensure safety and proper operation of the equipment and to avoid possible human injury or property damage. These symbols and their meanings are shown below. Please read and understand these symbols before proceeding to read this manual.



### **WARNING**

Instructions shown with this symbol represent what can cause death or serious injury if not observed.



### **CAUTION**

Instructions shown with this symbol represent what may cause injury or property damage if not observed.

### Examples of the Symbols



The symbols shown in the  $\Delta$  mark represent those that require attention (including potential dangers and warnings).

A depiction of the type of caution is shown inside the symbol (the left symbol indicates a general caution).



The symbols shown in the  $\odot$  mark represent actions which are prohibited. A depiction of the type of prohibited action is shown inside the symbol (the left symbol indicates that disassembly is prohibited).



The  $\bullet$  symbol indicates required actions. A depiction of the type of required action is shown inside the symbol (the left symbol indicates that the power plug must be disconnected from the outlet).

## Precautions Upon the Operation



### WARNING



Do not disassemble or modify the equipment. Doing so may result in fire, electric shock, or equipment failure.



Do not allow the display to become wet. Doing so may result in fire, electric shock, or equipment failure.



Operate the equipment only at the indicated voltage. Failure to do so may result in fire, electric shock, or equipment failure.



Install this unit at least 1 m away from any magnetic compasses. Installation near a magnetic compass may result in interference with the magnetic compass, and may result in an accident.



Do not perform internal inspections or modifications of the equipment. Inspection or modification by unauthorized personnel may result in fire, electric shock, or equipment failure. Please consult with JRC or an affiliate to perform internal inspections or repair.



When disposing of the used lithium battery, place insulating tape over the battery terminals, or otherwise insulate the battery. Failure to do so may result in heating, explosion, or fire due to a shorted battery.

## Precautions Upon the Operation



### CAUTION



This equipment is not designed to automatically make judgments on the position data. The navigation information including the position data needs to be judged by the user himself.



Do not use the equipment in the environment other than those provided in the specification. Doing so may result in equipment failure, malfunction, or injury.



Do not install the display unit in the location where it may come in contact with water, oil, or chemicals. Doing so may result in equipment failure, malfunction, or injury.



Do not install the equipment in the place subject to vibration or shock. Doing so may result in the equipment falling or collapsing, resulting in equipment failure or injury.



Do not place any item on the top of the equipment. Doing so may result in equipment failure, malfunction, or injury.



Please consult with JRC or an affiliate to perform installation. Installation by unauthorized personnel may result in malfunction.



Use only the specified battery. Failure to do so may result in battery leakage or rupture, resulting in fire, injury, or equipment failure.



Use the indicated screws when installing the display unit to a stable wooden surface. Failure to do so may result in the display unit falling over, causing injury or property damage.



Use only the specified fuse. Failure to do so may result in fire or equipment failure.



Use only the specified battery. Failure to do so may result in equipment failure or malfunction.



## CAUTION



When connecting the cable attached to the equipment, do not bend it acutely, twist it, or impart excessive force. Doing so sometimes causes cracks or damage to the coating, resulting in fire or electrocution.



Do not install the sensor where there is excessive vibration.  
Vibration may cause sensor failure.



Do not paint the sensor.  
Doing so may result in reception problems.



The junction box rubber gaskets ( $\phi$  25 Gland side) fit  $\phi$  10 - 20 cables.



Install the sensor where there are no obstacles, in order to ensure that GPS signals can be directly received from satellites without interference or reflection of signals from surrounding objects.

Whenever possible, select a place with the following characteristics.

- 1. An open space, which allows uniform reception of satellite signals.**
- 2. Far away from any high power transmission antennas.**
- 3. Outside radar beams.**
- 4. Away from the INMARSAT antenna by at least 5 meters and outside the INMARSAT beam.**
- 5. Away from the antenna of a VHF transmitter and a direction finder by at least 3 meters.**
- 6. Away from a Magnetic Compass by at least 1 meter.**
- 7. 3 meters or more away from amateur radio antennas.**

If it is difficult to find an ideal site, select a place temporarily and install the equipment. Conduct a test to make sure that the proper performance can be obtained and then fix the equipment in position. If it is installed at an improper place, reception accuracy may be impaired.

## Appearance of the Equipment

### ● NWZ-4740 Display Unit



### ● JLR-4341 DGPS Sensor Unit



### ● JLR-4340 GPS Sensor Unit



## Terminology

<b>Term</b>	<b>Meaning (Descriptions)</b>
2D (2 dimension)	Positioning with antenna elevation height in addition to satellite data.
3D (3 dimension)	The three dimensional position fix, 4 or more satellites required.
Active route	Route that is currently used by a ship
Anchor alarm	This alarm monitors that the own ship is the preset distance or more away from the waypoint.
Arrival alarm	This alarm informs that the own ship has traveled the preset distance, approaching the waypoint.
Beacon information	Beacon data which is broadcast by message type 16.
Boundary alarm	This alarm informs that the own ship has got into the preset route.
CCRP	Abbreviation of Consistent Common Reference Point. Reference position of the own ship.
CDI	Abbreviation of Course Deviation Indicator. This indicator shows information on the deviation from the scheduled route and on the direction into which the ship should be steered.
Checksum	An error detection method to check that the data has been correctly transmitted.
COG	Course Over Ground.
Course	Direction in which the ship is traveling, which is the bearing mainly displayed by the GPS.
CURRENT	Sea and ocean currents, expressed in speed and direction.
Data route	Ship route data that is stored in the memory of the equipment
Default gateway	Equipment connected externally from a constructed network.
DISP-DPU	The main circuitry of display unit.
DGPS	Abbreviation of Differential Global Positioning System. GPS satellite error data sent from a reference station whose position is accurately known is received via beacon from a beacon station, improving positioning accuracy.
FRAM	Nonvolatile memory using a ferroelectric substance.
Geodetic	Conditions for expressing position via latitude and longitude.
GPS Satellite (GPS)	Abbreviation of Global Positioning System. Refers to satellites launched for navigational support of military vessels managed by the United States Department of Defense.
HDOP	Abbreviation of Horizontal Dilution of Precision. Indicates accuracy of positioning. The smaller the number, the higher the accuracy. If GPS satellites are unevenly distributed, this number will grow. If GPS satellites are evenly distributed, this number will be smaller.
IEC	IEC is the abbreviation of International Electrotechnical Commission. It is an international standard governing electrical and electronic technologies.
IP address	ID number assigned to equipment on a constructed network.

IPXX	IPXX is Degrees of protection provided by enclosures (IP Code) 1st numeral: Against ingress of solid foreign objects (0 – 6) 2nd numeral: Against ingress of water with harmful effects (0 - 8). (IPX4: splash-proof, IPX6: waterproof)
LAN	Abbreviation of Local Area Network. A network is constructed for transmitting and receiving data.
LCD Unit (LCD)	Liquid Crystal Display Unit.
Log Pulse	Contact output signal, output in 1 pulse per nm. Expressed in units of "p/nm". mi/h Unit of ship speed.
Loran time difference display	Method for expressing the present position with loran system time difference. (The method is for operators who have a background in loran navigation.)
MAC address	ID number assigned to LAN IC
Master reset	This function changes the settings of the display unit and GPS sensor back to the factory settings. The function clears all the data.
Multipath Wave	Waves received from multiple directions due to reflection or refraction of an initial wave by obstacles.
Mutual monitoring mode	When two navigators are installed, they monitor their position fixing status each other by using this function.
NMEA0183 (NMEA)	Abbreviation of National Marine Electrical Association 0183. International standard for naval equipment transmission established by the National Marine Electrical Association.
Positioning	Use of GPS or DGPS receiving functions to determine the current position of a ship.
RAIM Accuracy Standard (RAIM)	Abbreviation of Receiver Autonomous Integrity Monitoring. This system automatically detects failed satellites and deselects their positioning data from calculations. Including data from failed satellites will result in a decrease in positioning accuracy; the RAIM accuracy standard indicates the accuracy degradation base for removal of failed satellites from positioning calculations.
Ranging	Positioning with the use of SBAS satellite in addition to GPS satellite.
Reception Level	GPS signal reception level.
Route plan	Plan registered with multiple waypoints in the navigation order
RS-232C	Serial data transmission standard. It is unbalanced, and hence can only be used for short distance transmission.
RS-422	Balanced serial transmission standard.
SBAS	Abbreviation of Satellite Based Augmentation System. It is a blanket term for wide scale GPS support systems using fixed position satellites which send GPS error correction data over a wide range.
SBAS Search	SBAS reception mode (manual / automatic).
Shared route	Function that uses the same route as other functions such as ECDIS do. The route can be updated automatically by sharing the active route.
Smoothing	Function for averaging over a specified number of seconds.

SOG	Speed Over Ground, This is the ship's relative speed to the ground.
SPEED	The speed mainly measured by the GPS.
STW	Speed Through Water.
Subnet mask	Value for identifying the network address
Symbol information	Information of symbols displayed on the plotting screen. The information includes symbol positions, comments, etc.
TD	Abbreviation of Time Difference. Time difference from the master-station signal of the loran system to the slave-station signal.
Message Type 0	SBAS satellite test broadcasting.
UTC	Abbreviation of Coordinated Universal Time.
XTD alarm	This alarm informs that the own ship has got out of the scheduled route by the preset distance or more.

## Contents

FOREWORD .....	I
BEFORE COMMENCING THE OPERATION .....	II
PRECAUTIONS UPON THE OPERATION .....	III
PRECAUTIONS UPON THE OPERATION .....	IV
APPEARANCE OF THE EQUIPMENT .....	VI
TERMINOLOGY .....	VII
<b>SECTION1 EQUIPMENT OVERVIEW.....</b>	<b>1-1</b>
1.1 FUNCTIONS .....	1-1
1.2 FEATURES .....	1-1
1.3 CONFIGURATION .....	1-2
Standard Configuration .....	1-2
Option 3 .....	1-3
1.4 CONSTRUCTION .....	1-5
1.5 SYSTEM DIAGRAM.....	1-13
<b>SECTION 2 NAMES AND FUNCTIONS OF EACH UNIT.....</b>	<b>2-1</b>
2.1 NWZ-4740 DISPLAY UNIT .....	2-1
2.2 JLR-4341 DGPS SENSOR .....	2-3
2.3 JLR-4340 GPS SENSOR.....	2-3
<b>SECTION 3 DISPLAY SCREEN .....</b>	<b>3-1</b>
3.1 DISPLAY SCREEN .....	3-1
3.1.1 Navigation Information Screen.....	3-4
3.1.2 Plotting Screen 1.....	3-7
3.1.3 Plotting Screen 2.....	3-7
3.1.4 Plotting Screen 3.....	3-7
3.1.5 CDI Screen.....	3-8
3.1.6 GPS Information Screen.....	3-9
3.1.7 Waypoint Information Screen.....	3-9
3.1.8 Beacon Information Screen .....	3-9
3.1.9 Navigation Assistance Screen .....	3-10
<b>SECTION 4 OPERATION .....</b>	<b>4-1</b>
4.1 MENU LIST .....	4-1
4.2 BASIC OPERATION .....	4-5
4.2.1 Turning the Unit On.....	4-5
4.2.1.1 Startup (Standard) .....	4-5
4.2.1.2 Startup (Error-1) .....	4-6
4.2.1.3 Startup (Error-2) .....	4-6
4.2.1.4 Startup (Error-3) .....	4-7
4.2.2 Turning the Unit Off.....	4-7
4.2.3 Adjusting the Backlight.....	4-8
4.2.4 Adjusting the Contrast.....	4-8
4.2.5 Stopping the Alarm Buzzer.....	4-9
4.2.6 Changing the Display .....	4-9
4.2.7 Displaying Alarm Information .....	4-9
4.3 PLOT SCREEN OPERATION .....	4-10
4.3.1 Cursor Operation .....	4-10
4.3.1.1 Displaying the Cursor .....	4-10
4.3.1.2 Moving the Cursor .....	4-10
4.3.1.3 Centering the Cursor Position .....	4-11
4.3.1.4 Changing Cursor Size .....	4-11
4.3.2 Moving the Screen .....	4-11
4.3.3 Zooming the Screen In and Out.....	4-12

4.3.4	Selecting North Up, Course Up, Relative North Up .....	4-12
4.3.5	Centering the Screen on the Ship.....	4-12
4.3.6	Waypoint Symbol Display .....	4-13
4.3.6.1	Displaying Waypoint Information.....	4-13
4.3.6.2	Editing Waypoint Symbols.....	4-14
4.3.6.3	Deleting Waypoint Symbols .....	4-15
4.3.7	Route Display.....	4-15
4.3.7.1	Displaying Route Information .....	4-16
4.3.7.2	Editing Route Information.....	4-16
4.3.7.3	Skipping Route Waypoints .....	4-17
4.3.8	Track Display .....	4-18
4.3.8.1	Setting the Track Period.....	4-18
4.3.8.2	Changing Track Line Type.....	4-19
4.3.8.3	Deleting Tracks.....	4-19
4.3.9	Event and Mark Symbol Display .....	4-20
4.3.9.1	Entering Events.....	4-20
4.3.9.2	Entering Marks .....	4-20
4.3.9.3	Changing Event/Mark Shapes .....	4-21
4.3.9.4	Displaying Event/Mark Information .....	4-21
4.3.9.5	Editing Event/Mark Information .....	4-23
4.3.9.6	Registering Event/Mark Positions to the Waypoint List.....	4-24
4.3.9.7	Deleting Event/Mark Symbols .....	4-24
4.3.10	Line Display.....	4-25
4.3.10.1	Drawing Lines.....	4-25
4.3.10.2	Deleting Lines.....	4-26
4.3.10.3	Changing Line Types.....	4-27
4.3.11	Own Ship Display.....	4-27
4.3.11.1	Displaying the Distance Circle .....	4-27
4.3.11.2	Displaying the Own Ship Vector.....	4-27
4.3.12	Hiding Plot Screen Symbols .....	4-28
4.4	REGISTERING WAYPOINTS .....	4-29
4.4.1	Displaying the Waypoint List.....	4-29
4.4.2	Registering Waypoints .....	4-30
4.4.2.1	Registering the Own Ship Position.....	4-31
4.4.2.2	Registering Latitude and Longitude .....	4-31
4.4.2.3	Registering the Cursor Position .....	4-32
4.4.2.4	Registering a Bearing and Distance from a Specified Position.....	4-32
4.4.2.5	Registering from the Event/Mark List.....	4-34
4.4.3	Changing the Waypoint Symbol Shape .....	4-34
4.4.4	Editing Waypoint Information .....	4-35
4.4.5	Copying Waypoint Information.....	4-36
4.4.6	Deleting Waypoints .....	4-39
4.5	ROUTE PLANNING .....	4-40
4.5.1	Displaying the Route List .....	4-40
4.5.2	Creating Routes .....	4-42
4.5.3	Editing Routes.....	4-43
4.5.3.1	Changing Waypoint Information .....	4-43
4.5.3.2	Adding Route Waypoints .....	4-44
4.5.4	Copying Routes .....	4-46
4.5.5	Deleting Routes .....	4-48
4.5.6	Sharing Routes with ECDIS.....	4-49
4.5.6.1	Sharing Data Routes .....	4-49
4.5.6.2	Sharing Active Routes .....	4-51
4.5.7	Setting Route Default Settings.....	4-53
4.6	PERFORMING NAVIGATION .....	4-54
4.6.1	Selecting a Route from the Route List .....	4-54
4.6.2	Starting Navigation with the GOTO Key.....	4-56
4.6.3	Stopping Navigation .....	4-60
4.6.3.1	Ending Navigation with GOTO key .....	4-60
4.6.3.2	Ending Navigation in Menu .....	4-60
4.7	EVENTS/MARKS .....	4-61
4.7.1	Displaying Events/Marks.....	4-61
4.7.2	Event and Mark Information Display .....	4-61
4.7.3	Editing Event and Mark Information.....	4-62

4.7.4	Deleting Event/Mark Information.....	4-62
4.8	LIST SCREEN OPERATION.....	4-63
4.8.1	Moving the Cursor within a List.....	4-63
4.8.1.1	Moving the Cursor with the Directional Keys .....	4-63
4.8.1.2	Using the Numeric Keypad to Enter a Number and Move the Cursor .....	4-64
4.8.2	Moving the Cursor to an Unregistered Number .....	4-64
4.8.2.1	Moving the Cursor with the Directional Keys .....	4-64
4.8.2.2	Jumping to an Unused Number .....	4-65
4.8.2.3	Using the Numeric Keypad to Enter a Number and Move the Cursor .....	4-66
4.8.3	Selecting a Range within a List.....	4-67
4.8.3.1	Moving the Cursor with the Directional Keys and Selecting a Range .....	4-67
4.8.3.2	Moving the Cursor with the Numeric Keypad and Selecting a Range .....	4-68
4.9	ENTERING COMMENTS.....	4-69
4.9.1	Text Entry .....	4-69
4.9.2	Deleting Text .....	4-71
4.9.3	Adding Text .....	4-71
4.9.4	Displaying Characters Assigned to the Numeric Keypad .....	4-72
4.10	MOB .....	4-73
4.11	ALARM SETTINGS.....	4-74
4.11.1	Setting Alarms .....	4-74
4.11.2	Setting Alarm Sounds .....	4-77
4.12	NAVIGATION ASSISTANCE .....	4-78
4.12.1	Measuring the Trip Distance and Time During Navigation (Navigation Assistance 1)...	4-78
4.12.2	Measuring the Trip Distance and Time (Navigation Assistance 2) .....	4-79
4.12.3	Measuring the Distance and Bearing Between 2 Points (Navigation Assistance 4).....	4-80
4.13	BEACON INFORMATION .....	4-81
4.14	DISPLAY SETTINGS .....	4-82
4.14.1	Adjusting Contrast.....	4-82
4.14.2	Adjusting Brightness .....	4-82
4.14.3	Setting the Click Sound.....	4-83
4.14.4	Setting Reversed Display.....	4-83
4.14.5	Input Assistance Settings .....	4-84
4.14.6	Selecting the Display Screen .....	4-84
4.15	SYSTEM SETTINGS .....	4-85
4.15.1	Setting the Time Difference.....	4-85
4.15.2	Setting the Date Display .....	4-85
4.15.3	Setting the Time Display .....	4-86
4.15.4	Setting the Geodetic System .....	4-86
4.15.5	Setting Distance and Speed Units .....	4-86
4.15.6	Setting Height and Depth Units.....	4-86
4.15.7	Setting Temperature Units .....	4-87
4.15.8	Setting Magnetic Correction.....	4-87
4.15.9	Setting the Maximum Analogue Speed Meter Value.....	4-88
4.16	GPS/BEACON/SBAS SETTINGS.....	4-89
4.16.1	Setting the GPS Mode .....	4-89
4.16.2	Setting the Fixing Mode .....	4-90
4.16.3	Setting the Elevation Mask .....	4-90
4.16.4	Setting HDOP .....	4-90
4.16.5	Setting Position, Speed, and Course Smoothing.....	4-91
4.16.6	Setting RAIM .....	4-91
4.16.7	Initializing the GPS.....	4-92
4.16.8	Setting Beacon/SBAS .....	4-93
4.16.9	Setting LORAN A/C.....	4-95
4.17	VERSION DISPLAY .....	4-96
4.18	LANGUAGE SETTINGS .....	4-97
4.19	PRINT.....	4-98
4.19.1	Ship information is printed when it is necessary.....	4-98
4.19.2	Setting the output interval.....	4-98
4.20	EQUIPMENT CONFIGURATION .....	4-99
4.20.1	Setting the Display Type .....	4-100
4.20.2	Setting the GPS Sensor Number.....	4-100
4.20.3	Setting Sensor Position / CCRP .....	4-101
4.20.4	Equipment Check.....	4-102
4.20.4.1	Input Port Check.....	4-102

4.20.4.2	Performing Self-diagnosis .....	4-102
4.20.4.3	Displaying and Outputting Error Logs .....	4-103
4.20.4.4	Outputting Settings .....	4-103
4.20.5	Performing a Master Reset (Reset) .....	4-104
4.20.6	Performing a Demo .....	4-104
4.20.7	Data I/O Settings .....	4-105
4.20.7.1	Configuring Data IN/OUT1 .....	4-106
4.20.7.2	Setting Data OUT2 .....	4-111
4.20.7.3	Setting Data OUT3 .....	4-111
4.20.7.4	Setting Data IN/OUT4 .....	4-111
4.20.7.5	Setting Contact Output 1 .....	4-112
4.20.7.6	Setting Contact Output 2 .....	4-112
4.20.7.7	Setting LAN Settings .....	4-113
4.20.7.8	Setting Tidal Current Meter Input .....	4-116
4.20.8	Setting the IP Address .....	4-117
<b>SECTION 5 MAINTENANCE AND INSPECTION .....</b>		<b>5-1</b>
5.1	GENERAL MAINTENANCE AND INSPECTION .....	5-1
5.2	ALARMS .....	5-2
5.3	TROUBLESHOOTING .....	5-3
5.3.1	Troubleshooting .....	5-3
5.3.2	Repair Unit .....	5-4
5.3.3	Regular Replacement Parts .....	5-4
<b>SECTION 6 INSTALLATION .....</b>		<b>6-1</b>
6.1	GPS SENSOR INSTALLATION .....	6-1
6.1.1	Selecting the Position for Installation .....	6-1
6.1.2	Sensor Installation Procedure .....	6-2
6.1.3	Installation of the Sensor on the Mast .....	6-3
6.1.4	Installation of the Sensor to pass a cable through a pole .....	6-4
6.2	DISPLAY UNIT INSTALLATION .....	6-6
6.2.1	Selecting the Position for Installation .....	6-6
6.2.2	Display Installation Procedure .....	6-6
6.2.3	How to Flush Mount the Display .....	6-7
6.3	CABLE CONNECTION .....	6-9
6.4	OPTIONAL PERIPHERAL CONNECTION .....	6-18
6.4.1	Sub Display Connection .....	6-18
6.4.2	Junction Box Connection .....	6-19
6.4.3	Coaxial Cable Kit Connection .....	6-21
6.4.4	Printer Connection .....	6-22
6.4.5	Connecting Two Navigation Devices to a Printer .....	6-23
6.4.6	Connecting 2 GPS Units to an Automatic GPS Select Switch .....	6-24
6.5	LAN and Serial Connection .....	6-25
6.6	CONNECTION DIAGRAM .....	6-26
<b>SECTION 7 AFTER-SALES SERVICE .....</b>		<b>7-1</b>
7.1	WARRANTY .....	7-1
7.2	REPAIR PARTS STOCKING PERIOD .....	7-1
7.3	WHEN REQUESTING SERVICE .....	7-1
7.4	RECOMMENDED CHECKS AND INSPECTION .....	7-1
<b>SECTION 8 DISPOSAL .....</b>		<b>8-1</b>
8.1	DISPOSAL OF THE EQUIPMENT .....	8-1
8.2	DISPOSAL OF USED BATTERIES .....	8-1
<b>SECTION 9 SPECIFICATION .....</b>		<b>9-1</b>
9.1	NWZ-4740 DISPLAY UNIT .....	9-1
9.1.1	Basic .....	9-1
9.1.2	Environment .....	9-1
9.1.3	External Interface .....	9-2
9.2	JLR-4341 DGPS SENSOR .....	9-3
9.2.1	Basic .....	9-3
9.2.2	Environment .....	9-3

9.3	JLR-4340 GPS SENSOR.....	9-4
9.3.1	Basic .....	9-4
9.3.2	Environment.....	9-4
APPENDIX	.....	APPENDIX-1
APPENDIX1	LIST OF GEODETIC SYSTEM.....	Appendix-1
APPENDIX2	LIST OF STANDARD TERMS, UNITS AND ABBREVIATIONS .....	Appendix-2
APPENDIX3	DEFAULT SETTINGS .....	Appendix-7

# Section1 Equipment Overview

## 1.1 Functions

This equipment (JLR-7800/JLR-7500) is a GPS navigator with a JLR-4341 DGPS or JLR-4340 GPS sensor being connected to the NWZ-4740 display unit.

The GPS navigator operates around-the-clock to measure the position with high accuracy anywhere in the world and in all weather conditions. In addition, the GPS navigator can increase the accuracy of position fixing by receiving correction data from the DGPS beacon station and SBAS satellites.

## 1.2 Features

- Registration of up to 100 routes and 10000 waypoints
- Availability of four output ports
- Sharing of a route with the ECDIS by installing a LAN
- High visibility 5.7-inch FSTN LCD
- Installation of multiple graphic display modes
- Mutual acknowledgment through the contact or ALR
- Improvement of operability by using various menus
- Built-in SBAS function
- Built-in RAIM function

### 1.3 Configuration

#### Standard Configuration

##### JLR-7800

No	Name	Model	Code	Q'ty	Notes
1	Display Unit	NWZ-4740	NWZ-4740	1	
1-1	Power Cable	CFQ-7257	CFQ-7257	1	2m/with Fuse holder
1-2	GPS Connection Cable	CFQ-9002	CFQ-9002	1	5m
1-3	Fuse	MF60NR 250V 2	5ZFGD00010	2	2A Fuse
1-4	Clamp Filter	TFC-23-11-14	5MBAT00002	1	5MBAT00002
1-5	Connector	LTWBU-12BFFA-LL7001	5JCDX00049	1	12 cores/Serial data transmission
1-6	Copper Plate	MPAE30207	MPAE30207	1	25W x 2000 x 0.3t
1-7	Model Identification Plate	MPNN45662	MPNN45662	1	
1-8	Installation Screw	MPTG31659	MPTG31659	1	4 tapping screws
1-9	Flush Mounting Screws Kit	MPTG31962	MPTG31962	1	4 screws
1-10	SHIP REGISTRATION FORM	7ZPJD0065	7ZPJD0065	1	
2	DGPS Sensor	JLR-4341	JLR-4341	1	
2-1	Screw Adapter	MTV302007A	MTV302007A	1	
2-2	Mounting Band	MPBP02520	MPBP02520	1	include 2 bands
2-3	Cable guard rubber	MPPK31468	MPPK31468	1	
2-4	Instruction Manual	7ZPNA4162	7ZPNA4162	1	
2-5	Warranty Card Europe North America Asia/Oceania	7ZPBS2901C 7ZPBS2902D 7ZPBS2903C	7ZPBS2901C 7ZPBS2902D 7ZPBS2903C	1 1 1	
3	Instruction Manual	7ZPNA4137	7ZPNA4137	1	

##### JLR-7500

No	Name	Model	Code	Q'ty	Notes
1	Display Unit	NWZ-4740	NWZ-4740	1	
1-1	Power Cable	CFQ-7257	CFQ-7257	1	2m/with Fuse holder
1-2	GPS Connection Cable	CFQ-9002	CFQ-9002	1	5m
1-3	Fuse	MF60NR 250V 2	5ZFGD00010	2	2A Fuse
1-4	Clamp Filter	TFC-23-11-14	5MBAT00002	1	5MBAT00002
1-5	Connector	LTWBU-12BFFA-LL7001	5JCDX00049	1	12 cores/Serial data transmission
1-6	Copper Plate	MPAE30207	MPAE30207	1	25W x 2000 x 0.3t
1-7	Model Identification Plate	MPNN45662	MPNN45662	1	
1-8	Installation Screw	MPTG31659	MPTG31659	1	4 tapping screws

1-10	SHIP REGISTRATION FORM	7ZPJD0065	7ZPJD0065	1	
1-9	Flush Mounting Screws Kit	MPTG31962	MPTG31962	1	4 screws
2	GPS Sensor	JLR-4340	JLR-4340	1	
2-1	Screw Adapter	MTV302007A	MTV302007A	1	
2-2	Mounting Band	MPBP02520	MPBP02520	1	include 2 bands
2-3	Instruction Manual	7ZPNA4008	7ZPNA4008	1	
2-4	Warranty Card Europe North America Asia/Oceania	7ZPBS2901C 7ZPBS2902D 7ZPBS2903C	7ZPBS2901C 7ZPBS2902D 7ZPBS2903C	1 1 1	
3	Instruction Manual	7ZPNA4137	7ZPNA4137	1	


### NWZ-4740

No	Name	Model	Code	Q'ty	Notes
1	Display Unit	NWZ-4740	NWZ-4740	1	
1-1	Power Cable	CFQ-7257	CFQ-7252	1	2m/with Fuse holder
1-2	GPS Connection Cable	CFQ-9002	CFQ-9002	1	5m
1-3	Fuse	MF60NR 250V 2	5ZFGD00010	2	2A Fuse
1-4	Clamp Filter	TFC-23-11-14	5JCDX00049	1	5MBAT00002
1-5	Connector	LTWBU-12BFFA- LL7001	5MBAT00002	1	12 cores/Serial data transmission
1-6	Copper Plate	MPAE30207	MPAE30207	1	25W x 2000 x 0.3t
1-7	Model Identification Plate	MPNN45662	MPNN45662	1	
1-8	Installation Screw	MPTG31659	MPTG31659	1	4 tapping screws
1-9	Flush Mounting Screws Kit	MPTG31962	MPTG31962	1	4 screws
1-10	SHIP REGISTRATION FORM	7ZPJD0065	7ZPJD0065	1	
2	Instruction Manual	7ZPNA4137	7ZPNA4137	1	

Option					
No	Name	Model	Code	Q'ty	Notes
1	AC Power Rectifier	NBG-320	NBG-320	1	AC100/220V input
2	Power Cable	CFQ-7257-10	CFQ7252-10	1	10m
3	Power Cable	CFQ-7257-15	CFQ7252-15	1	15m
4	Data Cable	CFQ-5374	CFQ-5374	1	3m / 12 cores / serial transmission
5	Data Cable	CFQ-5374-15	CFQ5374-15	1	15m / 12 cores / serial transmission
6	Data Cable	CFQ-5374-20	CFQ5374-20	1	20m / 12 cores / serial transmission
7	Data Cable	CFQ-5404	CFQ-5404	1	3m / 14 cores / serial transmission
8	Data Cable	CFQ-5404-15	CFQ5404-15	1	15m / 14 cores / serial transmission
9	Data Cable	CFQ-5404-20	CFQ5404-20	1	20m / 14 cores / serial transmission
10	Ethernet Cable	CFQ-5473A	CFQ-5473A	1	5m / FTP / straight
11	Ethernet Cable	CFQ-5474A	CFQ-5474A	1	5m / FTP / cross
12	Flush Mounting Kit	MPBC43664	MPBC43664	1	For front mounting
13	Printer	DPU-414	DPU-414	1	
14	Printer Cable	7ZCJD0254A	7ZCJD0254A	1	Dual end D-Sub 9 pin 1.5 m
15	Printer Cable	7ZCJD0270B	7ZCJD0270B	1	Dual end D-Sub 9 pin 10 m
16	Printer Cable	7ZCNA4109	7ZCNA4109	1	Single end D-Sub 9 pin 3m
17	Printer Cable	7ZCNA4112	7ZCNA4112	1	Single end D-Sub 9 pin 10 m
18	Printer Connection Kit	7ZXJD0076	7ZXJD0076	1	For printer power cable extension
19	Printer Paper	6ZCAF00252A	6ZCAF00252	1	112 mm x φ50 mm 25m
20	Printer Power Cable	7ZCJD0257B	7ZCJD0257B	1	1.5m
21	Extension Cable	CFQ-9000	CFQ-9000	1	15m / 6 cores / serial transmission
22	Junction Box	NQE-7700A	NQE-7700AA	1	
23	Pole Mounting Kit	MPBP30608	MPBP30608	1	For NQE-7700A
24	Coaxial Cable Kit	NQD-4414	NQD-4414A	1	
25	Output Buffer	NQA-4251A	NQA-4251A	1	
26	GPS Select Switch	NCZ-777	NCZ777A	1	Manual switch
27	GPS Select Switch	NCZ-1573A	NCZ-1537A	1	Automatic switch
28	Junction Box	CQD-10	CQD-10A	1	

## 1.4 Construction


- NWZ-4740 Display Unit



Unit: mm


Mass: Approximately 2.3 Kg

- JLR-4341 DGPS Sensor Unit




Unit: mm  
Mass: Approximately 1.7 Kg  
(Include Cable)

- JLR-4340 GPS Sensor Unit




Unit: mm  
Mass: Approximately 0.7 Kg  
(Include Cable)

- **NBG-320 Power Supply**





- **Flush Mounting Kit**



Unit: mm  
Mass: Approximately 0.2 Kg


- NQE-7700A Junction Box

---




Unit: mm  
Mass: Approximately 0.6 Kg


- **NQD-4414 Coaxial Cable Kit (NQD-4410)**




- **NQD-4414 Coaxial Cable Kit (NQD-4411)**




- NQA-4251A Output Buffer




- **NCZ-777 Select Switch**




- **NCZ-777 Select Switch (Flush Mounting)**



## CQD-10 Junction Box



## 1.5 System Diagram






# Section 2 Names and Functions of Each Unit

## 2.1 NWZ-4740 DISPLAY UNIT

- Unit (Front)



**Display**

Information received from the GPS receiver, the equipment setting screen, etc. are displayed.

### Control Panel

Key	Name	Function
MOB	MOB key	Displays the plotting screen, and stores the location where a crewmember/passenger has fallen in the sea
DISP	Display key	Changes the display contents on the screen.
MENU	Menu key	Displays the main menu screen.
△▽◀▶	Up, Down, Left, and Right keys	These keys scroll the screen and move the cursor.
1/MARK	Numeric keys	Enters 1. This key also displays the symbol at the cursor position on the plotting screen, and stores its position.
2/EVENT		Enters 2. This key also displays the symbol at the present position on the plotting screen, and stores its position.
3/←→		Enters 3. This key also increases the size of the display area on the plotting screen.
4/#		Enters 4. This key also prints to printer and sets the print out interval.
5/GOTO		Enters 5. This key also sets the waypoint.
6/→←		Enters 6. This key also decreases the size of the display area on the plotting screen.
7/CURS		Enters 7. This key also selects whether to display/hide the cursor on the plotting screen.
8/AZI		Enters 8. This key also selects North Up, Course Up, or Relative North Up on the plotting screen.
9/HOME		Enters 9. This key also moves the own ship's position to the center on the plotting screen.
0/*		Enters 0. This key also displays alarm information.
CLR	Clear key	Cancels operation and clears alarm information.
ENT	Enter key	Sets the entries.
DIM	Dimmer key	Adjusts the brightness.
PWR/CONT	Power/contrast key	Turns on the power. This key also adjusts the screen contrast. The power is turned off when the DIM and PWR/CONT keys are pressed at the same time.

## ● Reading the Display

The symbols and characters that appear in fixed locations on the screen are described below.

### ① Navigator number

Main display unit: Displays only the navigator number.  
Sub display unit: **S<sub>1</sub>** and S followed by the subsequent numbers are displayed.

### Time Display

Time is displayed in order of hours: minutes: seconds.  
In 12 hour display mode, "A" or "P" are displayed.  
If a time difference is set, "L" is displayed. Otherwise, UTC: "U" is displayed.

### Date Display

### Screen Title

The title of the open screen is displayed.

### M Equipment setting mode

Displayed when the equipment setting mode is selected

### Preset alarm

If a preset alarm occurs, alarm information is displayed. For ship speed, trip, depth, and temperature alarms, the corresponding preset units are displayed.

Arrival:  Anchor: 

XTD:  Boundary: 

Ship speed: kn  mi 

Trip: NM km mi Depth: m ft fm

Temperature: °C °F

### Geodetic System

### \* Alarm Information

This is displayed when alarm information messages have been updated.

### ※ Beacon Information Reception Display

This is displayed when meteorological information has been received from a beacon. A buzzer is generated when this is displayed.

### M Magnetic correction

Displayed when magnetic correction is set

### Waypoint update

The method for updating the waypoint for the current navigation is displayed.

Automatic update:  Manual update: 

### LAN sharing

Displayed when the active route sharing mode through LAN is selected

Sharing 1  Sharing 2  Sharing3  Sharing4 

### HDOP Alarm Display

Displayed when the number exceeds the configured value.

### Position fixing mode

No position fixing:  2D position fixing:  3D position fixing: 

### Position correction mode

GPS position fixing:  Beacon DGPS position fixing:  SBAS position fixing: 

### S Demo mode

Displayed when the demo mode is active

### RAIM

Displays the preset accuracy level  
In operation:    

RAIM OFF : 


No faulty satellite: 

RAIM impossible: 


Presence of faulty satellite: 



## 2.2 JLR-4341 DGPS Sensor



## 2.3 JLR-4340 GPS Sensor





# Section 3 Display Screen

Each screen is detailed in this section.

## 3.1 Display screen


The screen is switched each time  is pressed. Users are allowed to set the screen displayed when the power is turned on. Users can also determine not to display unnecessary screens. The navigation information screen, CDI screen, and navigation assistance screen are provided with sub-screens which can be selected by pressing  and/or .

### Navigation information screen




DISP

### Plotting screen 1



DISP

### Plotting screen 2



DISP

### Plotting screen 3

This screen displays information such as the own ship's position.

The sub-screens can be displayed by pressing  and/or .

This screen graphically displays the own ship's position.


This screen graphically displays the own ship's position.

### Plotting screen 2




DISP

### Plotting screen 3




This screen graphically displays the own ship's position in full-screen mode.



DISP

### CDI screen




This screen graphically displays the CDI, course, speed, and leg.

The highway screen can be displayed by pressing and/or .




DISP

### GPS information screen



This screen displays GPS satellite information.



DISP

### Waypoint information screen

## GPS information screen



## Waypoint information screen

WPT INFO 001/500 16:00:40 U1  
WPT° 00031 PRE◀▶NEXT  
COMMENT YOKOHAMA  
35° 24. 8000' N 139° 40. 8000' E  
BRG 160. 7° DIST 17. 0NM  
ETA 25 NOV.'09 17:49  
TTG 000 DAY 01 hr 48 min  
WIDTH PORT 1. 00NM  
WIDTH STBD 1. 00NM  
ARRIVAL RAD 1. 00NM  
SPEED 10. 00kn

This screen displays the information of waypoints on the route.

The information of the next waypoint can be displayed by pressing  and/or .

## **Beacon information screen**

BEACON INFO 19:57:22 U11  
25 NOV'09 19:35 1925, izuoshima, 0m, , , . . .  
25 NOV'09 19:30 1925, irosaki, NE, 5m, 1017hPa, , , .  
25 NOV'09 19:30 1925, omaesaki, WNW, 9m, , , .  
25 NOV'09 19:10 1855, sunosaki, ENE, 9m, , , .  
25 NOV'09 19:10 1855, tsurugisaki, N, 6m, , , .

This screen displays information received with the beacon receiver.

## **Navigation assistance screen**

ASSIST 25 NOV.'09 17:10:37 U1	
NAV START/END	RUNNING
35° 52. 0029' N	139° 35. 97154' E
SOG 10. 1kn	COG 231. 9°
START 25 NOV.'09	15:57:23
END . . . . .	. . . . .
TIME 0 DAY	1 hr 13 min
TRIP1 00013.	1NM
TRIP2 00012.	7NM
W84	
WPT AUTO	3G

This screen displays information such as the leg and time.

The sub-screens can be displayed by pressing  and/or .

## **Navigation information screen**

### 3.1.1 Navigation Information Screen

The navigation information screen displays the position, speed, and course of the own ship. If there are waypoints, the target waypoint number and estimated arrival time are displayed.

The sub-screens can be displayed by pressing and/or . The sub-screens vary depending on the presence or absence of waypoints.

#### (1) If there are waypoints:

Main screen ( 3 digit position screen)

NAV	25 NOV, '09 15:57:35	U <small>1</small>
SAFE	100m	
<b>35°41.413'N 139°34.257'E</b>		
Speed		
SOG	10.3 <small>knot</small>	COG 324.3°
W84	<small>WPT AUTO</small>	<small>3G</small>

Own ship's position (latitude and longitude)

Course

Sub-screen 1 ( 4 digit position screen)

Number of the waypoint for which the ship is heading	WPT 00031	ROUTE 005	Route number
Speed	35° 41.2609' N		Own ship's position (latitude and longitude)
Distance from the own ship's position to the waypoint	139° 34.2244' E		
	SOG 9.6 <small>knot</small>	COG 240.9°	Course
	DIST 55.1 NM	BRG 220.1°	Bearing from the own ship's position to the waypoint
	ETA 25 NOV, '09 22:05		
Estimated arrival time at the waypoint	FINAL ETA 03 MAR, '10 05:47		Estimated arrival time at the final waypoint
	W84	<small>WPT AUTO</small>	<small>3G</small>

Sub-screen 2 (Detail screen)

Number of the waypoint for which the ship is heading	WPT 00031	SAFE 10m	Own ship's position (latitude and longitude)
Speed	35° 41.1883' N 139° 34.1358' E		
Distance from the own ship's position to the waypoint	SOG 9.1 <small>knot</small>	COG 222.2°	Course
	DIST 55.0 NM	BRG 220.1°	Bearing from the present position to the waypoint
Speed of the destination component (See Memo.)	VTD 9.1 <small>knot</small>	VEAR 9.1 <small>knot</small>	Speed of the COG component (See Memo.)
Deviation from the route and the steering direction	XTD 0.03L NM	CMG 232.6°	
L: Steered to the left R: Steered to the right	ETA 25 NOV, '09 21:59		Average bearing (See Memo.)
	W84	<small>WPT AUTO</small>	<small>3G</small>

Own ship's position (latitude and longitude)

Course

Bearing from the present position to the waypoint

Speed of the COG component (See Memo.)

Average bearing (See Memo.)

Estimated arrival time at the waypoint

Sub-screen 3 (SOG and COG screen)

Number of the waypoint for which the ship is heading	WPT 00002	SAFE 100m	Own ship's position (latitude and longitude)
Speed	35° 41.5953' N 139° 34.0923' E		
	SOG 10.5 <small>knot</small>		
	COG 323.8°		Course
Estimated arrival time at the waypoint	ETA 25 NOV, '09 16:23		
	W84	<small>WPT AUTO</small>	<small>3G</small>

Memo

VTD (Speed of the destination component)

VTD (An acronym of "Velocity Toward Destination")

This is an index that shows how fast the boat is approaching toward the destination in the unit of knot when it is navigating at a given bearing angle and speed.

VEAR(Speed of the COG component)


VEAR(An acronym of "Velocity Along Route")

This is an index that shows how fast the vessel is approaching along the planned route in the unit of knot when it is navigating at a given course and speed.

CMG(Average bearing)

CMG(An acronym of "Course Made Good")

The bearing angle to the current position when viewed from the starting point.



**(2) If there are no waypoints:**

If there are no waypoints, only the position, speed, and course of the own ship are displayed.

## Main screen ( 3 digit position screen)

NAV 25 NOV. '09 15:57:35 UG  
SAFE 100m  
**35°41.413'N**  
**139°34.257'E**  
SOG 10.3 kn COG 324.3°  
W84 B8G

- Own ship's position  
(latitude and longitude)

Speed

### - Course

#### **Sub-screen 1 ( 4 digit position screen)**

NAV 25 NOV. '09 15:57:44 UG  
SAFE 100m

35° 41.3409' N  
139° 34.2627' E

SOG 10.0 kn COG 9.4°  
W84 B6

- Own ship's position  
(latitude and longitude)

Speed

rse

### **Sub-screen 2 (SOG and COG screen)**

NAV 25 NOV '09 15:58:20 UTM  
SAFE 100m  
35° 41. 4372' N 139° 34. 2953' E  
SOG 10.0 kn  
COG 20.8 °  
W84 BG

- Own ship's position  
(latitude and longitude)


Speed

## - Course

### 3.1.2 Plotting Screen 1

The plotting screen 1 displays the course, speed, bearing, and distance at the bottom of the screen. (Refer to "4.3 PLOT SCREEN OPERATION".)


There are three types of plotting screens, and all the plotting screens display the same information.



### 3.1.3 Plotting Screen 2

The plotting screen 2 displays the course, speed, bearing, and distance on the left side of the screen. (Refer to "4.3 PLOT SCREEN OPERATION".)


There are three types of plotting screens, and all the plotting screens display the same information.



### 3.1.4 Plotting Screen 3

The plotting screen 3 displays information in full-screen mode. (Refer to "4.3 PLOT SCREEN OPERATION".)

There are three types of plotting screens, and all the plotting screens display the same information.




### 3.1.5 CDI Screen


The CDI screen can graphically display the CDI, course, speed, and leg.

The highway screen can be displayed by pressing and/or .

If the heading is input, and heading (HDG) is displayed.



The highway screen displays information in Course Up mode while the own ship's position is fixed, so the route turns when the own ship turns. As a result, the route may not be displayed depending on the course.



The highway screen's scale can be changed by pressing or . The scale width is the same as the plot screen's. Please refer to "4.3.3 Zooming the Screen In and Out".

When GC is selected as the distance calculation method, only one waypoint can be displayed.



### 3.1.9 Navigation Assistance Screen

The navigation assistance screen calculates and displays navigation information such as the navigation start and end, leg distance, and total time. (Refer to "4.12 NAVIGATION ASSISTANCE".)

The trip calculation screen, the external equipment display screen, and the screen for calculating the distance/bearing between two points can be displayed by pressing and/or .

Navigation assistance screen 1 (measurement for navigation)	
Own ship's position (latitude and longitude)	ASSIST 25 NOV, '09 17:10:37 U1
Speed	NAV START/END RUNNING
Measurement start time	35° 52. 0029' N 139° 35. 9754' E
Measurement end time	SOG 10. 1kn COG 231. 9°
	START 25 NOV, '09 15:57:23
	END ... ... . . . . .
	TIME 0 DAY 1 hr 13 min
	TRIP1 00013. 1NM
	TRIP2 00012. 7NM
	W84 WPT AUTO BG
RUNNING: Measurement in progress No display: Measurement complete	
Course	
Total time	
Total distance over ground	
Total distance through water	

Navigation assistance screen 2 (water/ground trip calculation)	
Measurement end time	ASSIST 25 NOV, '09 17:07:25 U1
Total time	SOG NAV START/END
Average speed	START 25 NOV, '09 16:04
Measurement start time	END 25 NOV, '09 17:05
Measurement end time	TIME 0 DAY 1 hr 1 min
Total time	AVG SPD10. 4kn TRIP00010. 7NM
Average speed	STW NAV START/END
Measurement start time	START 25 NOV, '09 15:57
Measurement end time	END 25 NOV, '09 17:05
Total time	TIME 0 DAY 1 hr 8 min
Average speed	AVG SPD10. 1kn TRIP00011. 5NM
W84	WPT AUTO BG
RUNNING: Measurement in progress No display: Measurement complete	
Measurement start time	
Trip data for SOG	
Trip	
RUNNING: Measurement in progress No display: Measurement complete	
Trip data for STW	
Trip	
Bow speed through water	
◀: Leftward ▶: Rightward	

Navigation assistance screen 3 (external equipment display)	
Forward/backward speed through water ▲: Forward ▼: Backward	ASSIST 25 NOV, '09 15:57:25 U1
Water depth	STW ▲ 9. 9kn ▲ 0. 2kn
Current direction	▼ 0. 3kn
Layer A	DPTH 253. 9m TEMP +15. 1°C
Layer B	CURRENT DIR SPD DPTH
Layer C	A 358. 6° 2. 0kn 10. 5m
	B 357. 7° 3. 1kn 51. 0m
	C 359. 8° 2. 9kn 111. 0m
W84	WPT AUTO BG
Stern speed through water ◀: Leftward ▶: Rightward	
Water temperature	
Current speed	
Water depth for current measurement	

Navigation assistance screen 4 (calculation of a distance/bearing between two points)	
Starting point (latitude and longitude)	ASSIST 25 NOV, '09 16:11:27 U1
Terminal point (latitude and longitude)	DISTANCE CALCULATION
Distance	STARTING POINT OWN SHIP
Bearing	LATITUDE 35° 41. 2580' N
	LONGITUDE 139° 34. 2540' E
	TERMINAL POINT LAT/LON
	LATITUDE 35° 51. 1641' N
	LONGITUDE 139° 44. 3822' E
	SAIL GC/RL RL
	DIST 00012. 89NM
	BRG 039. 8°
W84	WPT AUTO BG
Distance calculation method	
GC: Great circle sailing	
RL: Rhumb line sailing	

# Section 4 Operation

## 4.1 Menu List

Main Menu	Sub Menu	Sub Menu	Range	Reference
1.DISPLAY	1.CONTRAST		1-7-13	4.14.1
	2.DIMMER -MAXIMUM-		1-9-10	4.14.2
	3 -TYPICAL-		1-6-10	
	4. -MINIMUM-		1-4-10	
	5.CLICK SOUND		ON/OFF	4.14.3
	6.REVERSING MODE		NORMAL/REVERSE1 / REVERSE2	4.14.4
	7.INPUT ASSIST		ON/OFF	4.14.5
	8.DISPLAY SELECT	1.NAV	ON/START/OFF	4.14.6
		2.PLOT 1	ON/START/OFF	
		3.PLOT 2	ON/START/OFF	
		4.PLOT 3	ON/START/OFF	
		5. CDI	ON/START/OFF	
		6. GPS INFO	ON/START/OFF	
		7.WPT INFO	ON/OFF	
		8.BEACON INFO	ON/OFF	
		9.NAV ASSIST	ON/OFF	
2.PLOT	1.WPT		○ etc.	4.4.3
	2.MARK		● etc.	4.3.9.3
	3.EVENT		□ etc.	
	4.TRACK PERIOD		OFF/TIME/DIST	4.3.8.1
	5.TRACK		▪ etc.	4.3.8.2
	6.LINE		— etc.	4.3.10.3
	7. EVENT/MARKLIST			4.7.1
	8.DELETE EVENT/ MARK/TRACK	1.DELETE EVENT/MARK LIST		4.7.4
		2.DELETE ALL EVENT		
		3.DELETE ALL MARK		
		4.DELETE ALL EVENT/MARK		
		5.DELETE TRACK		
	8.VISIBLE/INVISIBLE	1.WPT	ON/OFF	4.3.12
		2.WPT No.	ON/OFF	
		3.MARK	ON/OFF	
		4.EVENT	ON/OFF	
		5.EVENT/MARK No.	ON/OFF	
		6.TRACK	ON/OFF	
		7.LINE	ON/OFF	
		8.ARRIVAL CIRCLE	ON/LEG/OFF	
		9.XTD	ON/LEG/OFF	
		0.NEXT PAGE		
		1.SCALE BAR	ON/OFF	
		2.SYMBOL INFO	ON/OFF	
		3.CURSOR INFO	ON/OFF	
		4.GRID LINE	ON/OFF	
		5.GRID LAT	ON/OFF	
		6.GRID LON	ON/OFF	
		0.PREVIOUS PAGE		
	0.NEXT PAGE			
	1.CURSOR		LARGE/MIDDLE/SMA LL	4.3.1.4
	2.OWN CIRCLE		OFF/0.1-9.9NM	4.3.11.1
	3.OWN VECTOR		OFF/0.1-9.9 min	4.3.11.2
	0.PREVIOUS PAGE			

Main Menu	Sub Menu	Sub Menu	Range	Reference
3.WPT/ROUTE	1.ENTRY WPT/ WPT LIST			4.4.1/4.4.2
	2.MAKE ROUTE/ ROUTE LIST			4.5.1/4.5.2
	3.ROUTE START/END	1.LEG CHANGE	AUTO/MANUAL	4.6.1/4.6.3.2
		2.DIRECTION	ORDER/REVERSE	
		3.NAVIGATION	START/END	
	4.COPY WPT/ROUTE	1.WPT COPY		4.4.5
		2.ROUTE COPY		4.5.4
	5.DELETE WPT/ROUTE	1.WPT DEL		4.4.6
		2.ROUTE DEL		4.5.5
	6. TRANSFER WPT/ROUTE (LAN)	1.OUT / IN		4.5.6
		2.CONNECT / FROM IP		
		3.TO IP		
		4.PORT No.		
		5.FORMAT		
		6.OUT TYPE		
		0.START		
	7.DEFAULT SETTINGS	1.WIDTH PORT	OFF/0.01-9.99NM	4.5.7
		2.WIDTH STBD	OFF/0.01-9.99NM	
		3.ARRIVAL RAD	OFF/0.01-9.99NM	
		4.SPEED	OFF/0.01-99.99kn	
		5.SAIL GC/RL	GC/RL	
		6.SOG SMOOTHING	OFF/1-99 sec	
4.ALARM	1.ARRIVAL/ANCHOR		OFF/ARV/ANC	4.11.1
	2.XTD/BOUNDARY		OFF/XTD/ BOUNDARY	
	3. DGPS		OFF/ON→OFF/ OFF→ON/ ON ↔ OFF	
	4. HDOP		OFF/1-20	
	5.TEMP		OFF/OVER/UNDER / IN RANGE / OUT RANGE	
	6.DPTH		OFF/OVER/UNDER / IN RANGE / OUT RANGE	
	7.TRIP		OFF/OVER	
	8.SPD		OFF/OVER/UNDER / IN RANGE / OUT RANGE	
	0.ALARM SOUND SET	1.SYSTEM	1/2/3	4.11.2
		2.ARRIVAL/ANCHOR	OFF/1/2/3	
		3.XTD/BOUNDARY	OFF/1/2/3	
		4. DGPS	OFF/4/5/6	
		5. HDOP	OFF/1/2/3/4/5/6	
		6.TEMP	OFF/1/2/3/4/5/6	
		7.DPTH	OFF/1/2/3/4/5/6	
		8.TRIP	OFF/1/2/3/4/5/6	
		9.SPEED	OFF/1/2/3/4/5/6	

Main Menu	Sub Menu	Sub Menu	Range	Reference	
5.SYSTEM	1.TIME DIFF		-13:30—13:30	4.15.1	
	2.DATE DISP		'YY-MM-DD/ DD MM,'YY/ MM DD,'YY	4.15.2	
	3.TIME DISP		24hr/12hr	4.15.3	
	4.DATUM		WGS84 etc.	4.15.4	
	5.UNIT - DIST/SPEED		NM, kn km, km/h mi, mi/h	4.15.5	
	6. HEIGHT, DEPTH		m/ft/fm	4.15.6	
	7. TEMPERATURE		°C/°F	4.15.7	
	8.MAG CORR		OFF/AUTO/MANUAL	4.15.8	
	9.SPEED METER		10-100kn	4.15.9	
	1.GPS MODE		AUTO/GPSALONE / SBAS/BEACON	4.16.1	
6. GPS/BEACON/ SBAS	2.FIX MODE		AUTO/2D/3D	4.16.2	
	3.SAT ELV MASK		5-89 Degrees	4.16.3	
	4. HDOP		4/10/20	4.16.4	
	5.SMOOTHING POSITION		0-99 sec	4.16.5	
	SPEED		0-99 sec		
	COURSE		0-99 sec		
	6. RAIM ACCURACY LEVEL		OFF/10/30/50/100	4.16.6	
	7. GPS INITIALIZATION	1.LATITUDE		4.16.7	
		2.LONGITUDE			
		3.ANT HEIGHT			
		4.DATE			
		5.TIME			
		0.SET			
8.BEACON/SBAS	8.BEACON/SBAS	1.STATION SELECT	AUTO/MANUAL	4.16.8	
		2.FREQUENCY	283.5-325.0kHz		
		3.BIT RATE	50/100/200bps		
		4. BEACON INFORMATION	ON/OFF		
		6.SBAS SEARCH	AUTO/MANUAL		
		7. TYPE0 INFORMATION	ON/OFF		
		8.RANGING	ON/OFF		
		9.LORAN	1.LORAN A/C	4.16.9	
7.VERSION		LORAN A	OFF/LORAN A/ LORAN C		
		1.LORAN A/C			
		2.STN SELECT STN 1			
		3. STN 2			
		4. TD CORR TD1			
		5. TD2			
		LORAN C			
		1.LORAN A/C			
		2. GRI CHAIN			
		3. TD DATA TD1			
8.LANGUAGE	1.LANGUAGE	4. DATA TD2		4.18	
		5. TD CORR TD1			
		6. TD2			

Main Menu	Sub Menu	Sub Menu	Range	Reference
0.EQUIP SET	1.DISPLAY TYPE		MAIN/SUB	4.20.1
	2.SENSOR No.		1-9	4.20.2
	3. CCRP	1.SHIP	ENABLE/DISABLE	4.20.3
		2.BEAM	1.0-70.0m	
		3.LENGTH	1.0-700.0m	
		4SENSOR	ENABLE/DISABLE	
		5.X	-35.0-+35.0m	
		6.Y	0.0-700.0m	
		7.CCRP	ENABLE/DISABLE	
		8.X	-35.0-+35.0m	
9.Y		0.0-700.0m		
4.CHECK		OFF/INPUT DATA / DIAGNOSIS/ERROR LOG / CONFIG OUT	4.20.4	
5.RESET		OFF/ALL/SENSOR/ DISPLAY	4.20.5	
6.DEMO	1.DEMO TYPE	STATIC/ STRAIGHT / RIGHT/LEFT/ ROUTE/AUTO	4.20.6	
	2.DATE			
	3.TIME			
	4.LATITUDE			
	5.LONGITUDE			
	6.SPEED			
	7.COURSE			
	8.RADIUS			
	9.ROUTE			
	0.START			
7.DATA I/O	1.DATA IN/OUT1	NMEA/JRC/IEC/ ROUTE/SWITCH/ PRINTER	4.20.7.1	
	2.DATA OUT2	NMEA/JRC/IEC/ ROUTE/SWITCH	4.20.7.2	
	3.DATA OUT3	NMEA/JRC/IEC/ ROUTE/SWITCH	4.20.7.3	
	4.DATA IN/OUT4	NMEA/JRC/IEC/ ROUTE/SWITCH/ EXT EQUIP	4.20.7.4/ 4.20.7.8	
	5.CONTACT OUTPUT 1	ALARM ACK/SYSTEM /SYS+XTD+ARV/ 200p/NM/400p/NM	4.20.7.5	
	6.CONTACT OUTPUT 2	ALARM ACK/SYSTEM /SYS+XTD+ARV/ 200p/NM/400p/NM	4.20.7.6	
	7. LAN	ACTIVE ROUTE/ DATA ROUTE/ MUTUAL/DATA OUT/ REMOTE MAINTENANCE	4.20.7.7	
8.SOFT UPDATE	1.UPDATE AREA	DISPLAY/ SENSOR		
	2.BIT RATE	SENSOR AUTO DISPLAY 38400/57600/ 115200bps		
	3.UPDATE STANDBY			
9. IP	1. IP ADDR	DEFAULT/INPUT	4.20.8	
	2.SUBNET MASK	DEFAULT/INPUT		
	3.DEFAYLT GATWAY	DEFAULT/INPUT		

## 4.2 Basic Operation

### 4.2.1 Turning the Unit On


Press the  button to turn the unit power on. System initialization will start.

Once initialization has been completed, self-diagnosis will start, and once the equipment's status has been confirmed, the screen will switch to the standard screen.

#### Attention

If the unit cannot be turned on, check the main power supply and the connection of display unit cable.

Unit Initialization



Self-Diagnosis Screen

*SELF DIAGNOSING...	
ROMC1	: OK
ROMC2	: OK
RAM	: OK
S10C0	: OK
S10C1	: OK
S10C2	: OK
S10C3	: OK
S10C4	: OK
LAN	: OK

JLR-7800

(Display Unit Diagnosis)

(Sensor Setting Confirmation)

#### Memo

Press the  key to stop self-diagnosis and return to the standard screen.

### 4.2.1.1 Startup (Standard)

If the self-diagnosis results are all "OK", the unit automatically switches to the standard screen.

Self-Diagnosis

*SELF DIAGNOSING...	
ROMC1	: OK
ROMC2	: OK
RAM	: OK
S10C0	: OK
S10C1	: OK
S10C2	: OK
S10C3	: OK
S10C4	: OK
LAN	: OK

\*CHECKING CONFIG OF SENSOR

JLR-7800

Standard Screen

NAV	25 NOV, '09 15:57:35 UT
	SAFE 100m
35°41.413'N	
139°34.257'E	
SOG	10.3 kn
COG	324.3°
W84	
	③G

#### 4.2.1.2 Startup (Error-1)

If any of the self-diagnosis results are "NG", the results are displayed.

The unit does not switch to the standard screen unless the **CLR** key is pressed.

##### Attention

If any errors (NG) are detected, please contact JRC or an affiliate.

```
*SELF DIAGNOSING...
ROMC1] : OK
ROMC2] : OK
RAM     : OK
SIOC0]  : OK
SIOC1]  : OK
SIOC2]  : OK
SIOC3]  : OK
SIOC4]  : OK
LAN     : NG
```

[PRESS 'CLR' KEY TO EXIT]

#### 4.2.1.3 Startup (Error-2)

Messages shown below may be displayed during sensor diagnostics.

The message appears when display unit and sensor configuration settings do not match, such as when equipment has been replaced.

When this occurs, select one of the items, and press the **ENT** key to perform it.

- [ 1. USE SENSOR CONFIG.]: Replaces display configuration with the sensor configuration.
- [ 2. USE DISPLAY CONFIG.]: Replaces the sensor configuration with the display configuration.

##### Attention

Consult with JRC or its affiliate if this is displayed frequently.


```
*CHECKING CONFIG OF SENSOR
DISPLAY CONFIG DIFFERS
FROM SENSOR.

SELECT ONE OF;
1. USE SENSOR CONFIG.
2. USE DISPLAY CONFIG.
```

JLR-7800

#### 4.2.1.4 Startup (Error-3)

If the following screen is displayed after the unit is turned on, press the **PWR** CONT key and **DIM** key simultaneously to turn off the power.



##### Attention

Contact JRC or its affiliate.

#### 4.2.2 Turning the Unit Off

If the **DIM** key and **PWR** CONT key are pressed and held down simultaneously, the power will be turned off and the screen display will turn off.



### 4.2.3 Adjusting the Backlight

The brightness of the display can be set to one of four levels (bright, medium, dark, off). The brightness is set to medium when the unit is turned on.

The brightness cycles in the following order when the **DIM** button is pressed: Bright → Medium → Dark → Off → Dark → Medium → Bright...



#### Memo

- Level settings can be performed for all brightness levels except "Off". (Refer to "4.14 Display Settings")
- The key panel brightness changes in accordance with the display brightness.

### 4.2.4 Adjusting the Contrast

The contrast of the display can be set to one of 13 levels.

Each time the **PWR/CONT** button is pressed, the current contrast will decrease, and once the minimum contrast is reached, the contrast will increase.



## 4.2.5 Stopping the Alarm Buzzer

The buzzer can be stopped by pressing the **CLR** key.

The buzzer sounds when one of the following occurs.

- Position measurement is interrupted
- An error occurs

### Memo

- Mutual Acknowledgement Function

When positioning is stopped and the buzzer sounds, the mutual acknowledgement function can be used to stop the buzzer from another unit. To use this function, units must be connected via contact input / output or ALR, ACK sentences.


## 4.2.6 Changing the Display

Each time the **DISP** key is pressed, the screen display changes. (Refer to "3.1 Display Screen")

## 4.2.7 Displaying Alarm Information

Each time the **0\*** key is pressed, the screen display changes.

When alarm information is updated, the \* symbol appears on the status bar.




### Memo

- If no alarm has occurred, "NO ALARMS" is displayed.

## 4.3 Plot Screen Operation

### 4.3.1 Cursor Operation



#### 4.3.1.1 Displaying the Cursor

- Cursor display can be turned off and on.
- When the cursor is displayed, cursor information (cursor latitude and longitude, bearing and distance from ship to cursor) will be shown on the top right of the screen.

##### Procedure

1. Press the key on the plot screen to display the cursor.
2. To hide the cursor, press the key again.

To automatically hide cursor information when the cursor has not moved for 10 seconds, set "CURSOR INFO" to "OFF" as directed in "4.3.12 Hiding Plot Screen Symbols". Set it to "ON" to always display cursor information.

#### 4.3.1.2 Moving the Cursor

- The cursor can be moved up, down, left, right, and diagonally.

##### Procedure

1. Use to move the cursor up, down, left, and right.
2. Press , , , or simultaneously to move the cursor diagonally. Holding the buttons down will cause the screen to accelerate while continuing its movement.

### 4.3.1.3 Centering the Cursor Position

- The position of the cursor can be displayed at the center of the screen.

#### Procedure

- Display the cursor.
- Move the cursor to the point on the screen which you want to be centered.
- Press .

The position the cursor was at will be moved to the center of the screen.

### 4.3.1.4 Changing Cursor Size

- The cursor size can be set to one of 3 sizes.

#### Procedure

- Press , then , then  to display the "PLOT SET2" Screen.
-  Press "CURSOR".
- Use   to select the size, and then press .

### 4.3.2 Moving the Screen

- The screen can be moved up, down, left, right, and diagonally

#### Procedure

- If the cursor is displayed, press  to hide the cursor.
- Press     to move the screen up, down, left, or right.  
Press   ,   ,   or   simultaneously to move the screen diagonally. Holding the buttons down will cause the screen to accelerate while continuing its movement.

### 4.3.3 Zooming the Screen In and Out

- The plot screen width can be changed to any of the widths below.  
0.2, 0.5, 1.0, 2.0, 5.0, 10.0, 20.0, 50.0, 100.0, 200.0, 300.0[NM]

#### Procedure

- Each time  is pressed, the screen will zoom in (a narrower area will be displayed).
- Each time  is pressed, the screen will zoom out (a wider area will be displayed).

A scale bar is displayed at the bottom right of the screen.

To turn off the scale bar, turn the "SCALE BAR" "OFF" as described in "4.3.12 Hiding Plot Screen Symbols".

### 4.3.4 Selecting North Up, Course Up, Relative North Up

- The screen mode can be switched between north up, course up, and relative north up.  
North Up: The top of the screen shows north, and own ship moves.  
Course Up: The top of the screen shows the direction of the route of own ship, and the surroundings move.  
Relative North Up: The top of the screen shows north, the ship is fixed, and the surroundings move.

#### Procedure

- Press .

Each time the key is pressed, selection rotates as follows:

"N UP" → "C UP" → "RM N UP"  


The top left of the screen displays the direction of north and the screen mode.

### 4.3.5 Centering the Screen on the Ship

- The ship can be displayed at the center of the screen.

#### Procedure

- If the cursor is displayed, press  to hide the cursor.
- Press .

Own ship will be displayed at the center of the screen.

#### Memo

- When own ship reaches the edge of the screen, the screen will automatically reposition the display such that own ship is at the center of the screen. When Course Up is selected, own ship will be displayed somewhat below the center of the screen.

## 4.3.6 Waypoint Symbol Display

- The symbols and numbers of waypoints registered in the waypoint list are displayed on the plot screen.
- Up to 1000 waypoints can be displayed on one screen.
- To turn off waypoint symbol display, set "WPT" to "OFF" as described in "4.3.12 Hiding Plot Screen Symbols".



### 4.3.6.1 Displaying Waypoint Information

Waypoint information can be displayed by moving the cursor to the waypoint and leaving it in place for 1 second or longer.

If the cursor is moved off of the waypoint, the waypoint information will be hidden.

The following waypoint information is shown.

- For waypoints on route  
Symbol shape, number, comments, latitude, longitude, arrival circle radius, port route width, starboard route width, bearing from own ship, distance, estimated time of arrival.
- For waypoints off route Symbol shape, number, comments, latitude, longitude



#### Procedure


- Press **7 CURS**, and display the cursor.
- Press **▲ ▼ ← →** to move the cursor to the waypoint symbol.  
Leave the cursor in place for 1 second or longer, and the waypoint information will be displayed.

### 4.3.6.2 Editing Waypoint Symbols

- Waypoint symbol shapes and comments can be edited, but the symbols on the active route or sharing route can not be edited.
- Waypoint symbols can also be edited from the menu. Please refer to "4.4.4 Editing Waypoint Information".

#### Procedure

1. Press **7 CURS**, and display the cursor.
2. Press **▲ ▼ ← →** to move the cursor to the waypoint symbol and display the waypoint information.
3. Press **ENT** to display the edit screen.



Edit Screen

#### (1) To Change Symbol Shape

4. Press **1 MARK** "SYMBOL".
5. Press **▲ ▼ ← →** to select the shape, and press **ENT**.



Symbol Shape List

#### (2) To Change Comment

6. Press **2 EVENT** "COMMENT" and enter the comment.  
Please refer to "4.9 Entering Comments" for instructions on how to enter comments.
7. Press **0 \*** "EDIT FIN".

### 4.3.6.3 Deleting Waypoint Symbols

Waypoints can be deleted.

Deleted waypoints will also be deleted from the waypoint list. However, waypoints on the active route will be deleted from the route, but will not be deleted from the waypoint list (skip). For details regarding skipping, refer to "4.3.7.3 Skipping Route Waypoints".

Deletion is also possible from the menu. Please refer to "4.4.6 Deleting Waypoints".

#### Procedure

1. Press  **7 CURS**, and display the cursor.
2. Press  to move the cursor to the waypoint symbol and display the waypoint information.
3. Press .

### 4.3.7 Route Display

- When navigation starts, the active route, arrival circle, and route width are displayed on the plot screen.
- To hide the arrival circle and route width, set "ARRIVAL CIRCLE" and "XTD" to "OFF" as directed in "4.3.12 Hiding Plot Screen Symbols".
- To display only the arrival circle and route width for the LEG, set "ARRIVAL CIRCLE" and "XTD" to "LEG" as described in "4.3.12 Hiding Plot Screen Symbols". If set to "ON", the arrival circles and route widths for each LEG will be displayed.
- Arrival circles and route widths for routes for which navigation is underway cannot be edited.
- Refer to "4.5.2 Creating Routes" for information regarding how to create routes.
- Refer to "4.6 Performing Navigation" for information regarding how to perform navigation.


### 4.3.7.1 Displaying Route Information

If the cursor is moved onto a route, and left in place for 1 second or longer, the route information will be displayed.

If the cursor is moved off the route, the route information will be hidden.

The route information displayed consists of the route number and comments.

Only the active route can be displayed.



#### Procedure

1. Press **7 CURS**, and display the cursor.
2. Press **▲ ▼ ← →** to move the cursor to the route.  
Leave the cursor in place for 1 second or longer, and the route information will be displayed.

### 4.3.7.2 Editing Route Information

Route comments can be edited. However, shared routes cannot be edited.

Editing is also possible from the menu. Please refer to "4.5.3 Editing Routes".

Only the active route can be displayed.

#### Procedure

1. Press **7 CURS**, and display the cursor.
2. Press **▲ ▼ ← →** to move the cursor to the route, and display the route information.
3. Press **ENT** to display the edit screen.



4. Press **1 MARK** "COMMENT" and enter the comment.  
Please refer to "4.9 Entering Comments" for instructions on how to enter comments.
6. Press **0 \*** "EDIT FIN".

### 4.3.7.3 Skipping Route Waypoints

Waypoints on routes can be skipped.

Waypoints on sharing route can not be skipped.

If skipped, they will disappear from the route, and a route connecting the previous and next waypoints will be created, but the waypoint will not be deleted from the route planning.

Skipping is also possible from the menu. Please refer to "4.5.3.1 Changing Waypoint Information".

Waypoints which have already been passed cannot be skipped.


Once skipped, the skipped state will be retained, and the waypoint will be skipped again if the same route is performed. To set a waypoint which has been skipped to no longer be skipped, set the waypoint information "STATE" setting to "USE" as directed in "4.5.3.1 Changing Waypoint Information".

The only route which can be displayed is the active route.

#### Procedure

1. Press **7 CURS**, and display the cursor.
2. Press **▲ ▼ ← →** to move the cursor to the waypoint on the route, and display the waypoint information.
3. Press **CLR**.

A route will be automatically created connecting the waypoints immediately before and after the skipped waypoint.




Route before skipping  
Progressing from 0002 to 0003


Skip current waypoint 0003

Skip 0004

Skipped waypoint




Route change from 0002 to 0004



Route change from 0003 to 0005

## 4.3.8 Track Display

- The own ship's track can be displayed.
- A maximum of 2000 points of track can be stored. Once this number is exceeded, old track points will be automatically deleted.
- To turn off track display, set "TRACK" to "OFF" as described in "4.3.12 Hiding Plot Screen Symbols".



### 4.3.8.1 Setting the Track Period

Memory intervals can be set to units of time or of distance.

The following periods can be set:

Time: Can be set in 1 second increments between 1 and 60 minutes.

Distance: Can be set in 0.01 NM increments between 0.01 and 99.99 NM.

#### Procedure

1. Press **MENU**, **2 EVENT**, and then **4 #** and select "TRACK PERIOD".
2. Press **▲** **▼** to select either "TIME" or "DIST", and press **ENT**.
3. Use the numeric keypad to enter the period, and press **ENT**.

#### Memo


- If the period is set to "OFF", track memory will be deactivated. Previously stored data will be retained.

### 4.3.8.2 Changing Track Line Type

The track line type (dots, line, dotted line) can be selected.

#### Procedure

1. Press **MENU**, **2 EVENT**, and then **5 GOTO** and select "TRACK".
2. Press **ENT** to select the line type, and press **ENT**.



Line Type List

### 4.3.8.3 Deleting Tracks

All tracks can be deleted.

Partial deletion cannot be performed.

#### Procedure

1. Press **MENU**, **2 EVENT**, **8 AZI**, and then **5 GOTO**, and select "DELETE TRACK".

## 4.3.9 Event and Mark Symbol Display

- Events and marks registered in the event/mark list can be displayed on the plot screen.  
Event: When the event key is pressed, a symbol is displayed at the own ship's position, and is registered in the event/mark list.  
Mark: When the mark key is pressed, a symbol is displayed at the cursor position, and is registered in the event/mark list.
- Up to a total of 1000 symbols (including MOB and line change points) can be registered and displayed.
- To disable event and mark display, set "EVENT" and "MARK" to "OFF" as described in "4.3.12 Hiding Plot Screen Symbols".

### 4.3.9.1 Entering Events

Event symbols are displayed at the own ship's position on the plot screen, and are registered to the event/mark list.

They are registered to the event/mark list in ascending numerical order.

#### Procedure

- Press  .

#### Memo

- As long as the menu screen, waypoint information screen, or navigation assistance 4 screen are not displayed, the ship's position can be registered by pressing the  button without exiting the plot screen.

### 4.3.9.2 Entering Marks

Mark symbols are displayed at the cursor position on the plot screen, and are registered to the event/mark list.

They are registered to the event/mark list in ascending numerical order.

#### Procedure

- Press  , and display the cursor.
- Move the cursor to the position you wish to register, and press  .

#### Memo

- If  is pressed without displaying the cursor on the plot screen, an event symbol will be displayed at the own ship's position, and registration will occur.

### 4.3.9.3 Changing Event/Mark Shapes

The default symbol types of events and marks displayed when setting events or marks can be selected. Individually selected symbol types are not changed.


#### Procedure

##### (1) Changing Event Symbol Shape

1. Press **MENU**, **2 EVENT**, and then **3**, and select "EVENT".
2. Press **▲ ▼ ← →** to select the shape, and press **ENT**.

##### (2) Changing Mark Symbol Shape

1. Press **MENU**, **2 EVENT**, and then **2 EVENT**, and select "MARK".
2. Press **▲ ▼ ← →** to select the shape, and press **ENT**.





Symbol Shape List

### 4.3.9.4 Displaying Event/Mark Information

- Event and mark information can be displayed.
- The following event information is displayed.  
Event symbol, event number, comment, latitude, longitude, registration date and time  
When an external unit is connected, the water temperature, depth, and current at the time of registration.
- The following mark information is displayed.  
Mark symbol, mark number, comment, latitude, longitude, registration date and time
- Move the cursor to the event or mark symbol, and leave the cursor there for 1 second or longer to display the event or mark information.
- If the cursor is moved off of the event or mark symbol, the event or mark information will be hidden.

#### Procedure

1. Press **7 CURS**, and display the cursor.
2. Press **▲ ▼ ← →** to move the cursor to the event or mark symbol.  
Leave the cursor in place for 1 second or longer, and the event or mark information will be displayed.



### Memo


- Event and mark information can also be displayed from the event/mark list.  
Please refer to "4.7.3 Editing Event and Mark Information".

#### 4.3.9.5 Editing Event/Mark Information

Event and mark symbol shapes and comments can be edited.

##### Procedure


1. Press **7 CURS**, and display the cursor.
2. Press **▲ ▼ ← →** to move the cursor to the event or mark symbol, and the event or mark information will be displayed.
3. Press **ENT** to display the edit screen.



Event / Mark Editing Screen

##### (1) To Change Symbol Shape

4. Press **1 MARK** "SYMBOL".
5. Press **▲ ▼ ← →** to select the shape, and press **ENT**.



Symbol Shape List

##### (2) To Change Comment

6. Press **2 EVENT** "COMMENT" and enter the comment.  
Please refer to "4.9 Entering Comments" for instructions on how to enter comments.
8. Press **0 \*** "EDIT FIN".

##### Memo


- Event and mark information can also be edited from the event/mark list.  
Please refer to "4.7.3 Editing Event and Mark Information".

#### 4.3.9.6 Registering Event/Mark Positions to the Waypoint List

Event and mark positions can be registered to the waypoint list.  
This enables them to be used as waypoints.

##### Procedure

1. Press **7 CURS**, and display the cursor.
2. Press **▲ ▼ ← →** to move the cursor to the event or mark symbol you wish to register to the waypoint list, and display the event or mark information.
3. Press **ENT** to display the edit screen.



4. Press **3 →** "ENTRY FOR WPT".
  5. The waypoint list will be displayed. Select the number of the waypoint you wish to register, and press **ENT**.
- Please refer to "4.8 List Screen Operation" for details regarding how to select waypoint numbers.

#### 4.3.9.7 Deleting Event/Mark Symbols

Registered events and marks can be deleted.

##### Procedure

1. Press **7 CURS**, and display the cursor.
2. Press **CLR** to move the cursor to the event or mark symbol you wish to delete, and display the event or mark information.
3. Press **CLR**.

##### Memo

- Event and mark symbols can also be deleted from the event/mark list.  
Please refer to "4.7.4 Deleting Event/Mark Information".

## 4.3.10 Line Display

- Lines can be drawn between any two points on the plot screen.
- To turn off line display, set "LINE" to "OFF" as described in "4.3.12 Hiding Plot Screen Symbols".

### 4.3.10.1 Drawing Lines

The cursor is used to set start and end points on the plot screen, and a line is drawn connecting them.


Line start and end points can be registered as marks in the event/mark list.

If **CLR** is pressed before an end point is selected, the previous inflection point is deleted.

#### Procedure

1. Press **7 CURS**, and display the cursor.
2. Press **▲ ▼ ← →** to move the cursor to the start point, and press **ENT**.
3. Press **▲ ▼ ← →** to move the cursor to the end point, and press **ENT**.
4. At the same position as the end point, press **ENT** again.

If steps 2 and 3 are repeated before step 4, a line will be drawn using the end point as an inflection point.




## 4.3.10.2 Deleting Lines

If an inflection point on a line is deleted, the inflection points before and after it will be connected. Entire lines can also be deleted.

### Procedure

1. Press **7 CURS**, and display the cursor.
2. Press **▲ ▼ ← →** to move the cursor to the inflection point you wish to delete, and display the mark information.
3. **CLR** Pressing will display the following. Select one or all points to be deleted, and press **ENT**.




The following is an overview of the display.

ONE: Delete only the selected inflection point, and connect the points immediately before and after it.

ALL: Delete the selected line.


CANCEL: Cancel deletion.

### 1 Point Deletion Selected



### Mark Information

**CLR** Key



Move the cursor to the inflection point.

The inflection point is deleted, and the preceding and following inflection points are connected.

### Memo

- If a line consists of only a start point and an end point, if either are deleted, the entire line will be deleted.
- Inflection points are registered in the event/mark list as marks, and as such can be deleted by deleting the mark. Please refer to "4.7.4 Deleting Event/Mark Symbols" for details regarding how to perform deletion.


### 4.3.10.3 Changing Line Types

The line type can be changed.

Line types can be set for each line, but cannot be changed after the line has been set.

#### Procedure

1. Press **MENU**, **2 EVENT**, and then **6**, and select "LINE".
2. Press **◀ ▶** to select the line type, and press **ENT**.



Line Type List

### 4.3.11 Own Ship Display

- The distance circle from own ship, and the ship's vector, are displayed.
- The own ship symbol cannot be changed.

#### 4.3.11.1 Displaying the Distance Circle

A circle, centered on own ship, is displayed by specifying the radius.  
Settings can be made between 0.1 and 9.9 NM.

#### Procedure

1. Press **MENU**, **2 EVENT**, **0\*** and then **2**, and select "OWN CIRCLE".
2. Press **▲ ▼** to select "SET", and press **ENT**.
3. Use the numeric keypad to enter the distance radius [NM], and press **ENT**.

#### 4.3.11.2 Displaying the Own Ship Vector

Setting the time allows the vector line to the point own ship will arrive at in the set time to be displayed.

Settings can be made between 0.1 and 9.9 minutes.

#### Procedure

1. Press **MENU**, **2 EVENT**, **0\*** and then **3**, and select "OWN VECTOR".
2. Press **▲ ▼** to select "SET", and press **ENT**.
3. Use the numeric keypad to enter the time [min], and press **ENT**.

### 4.3.12 Hiding Plot Screen Symbols

- Individual symbols on the plot screen can be hidden.
- Set symbols to "OFF" to hide them.
- Set symbols to "ON" to display them.
- The following symbols can be set:  
Waypoints, waypoint numbers, marks, events, event / mark numbers, tracks, lines, arrival circles, route widths, scale bars, symbol information, cursor position information, grid lines, grid latitude, grid longitude.

#### Procedure

1. Press  ,  , and then  , and select "VISIBLE/INVISIBLE".  
Press  "NEXT PAGE" for items which are not displayed.
2. Use the numeric keypad to select the item to hide.
3. Press   "OFF", and then press .

#### Memo

- If mark or event are pressed when marks or events are hidden, marks and events will be displayed.
- If GOTO is used to create a temporary route with the cursor when waypoints are hidden, waypoints will be displayed.
- If a line is drawn when lines are hidden, lines will be displayed.


## 4.4 Registering Waypoints

- Waypoints must be registered to the waypoint list to start navigation.
- Up to 10000 waypoints can be registered in this unit.
- The waypoint list is divided into 3 regions, managed via numbering from 1 - 11024.
  - 1 - 10000: Waypoints registered in this unit.
  - 10001 - 10512: Waypoints on shared active routes sent by ECDIS are registered.
  - 10513 - 11024: Waypoints used in temporary routes are registered.
- Numbers 1 - 10512 are saved, and remain even if the power is turned off. 10513 - 11024 are not saved, and will disappear if the power is turned off.
- Waypoints can be set between 89 degrees north and 89 degrees south.

### 4.4.1 Displaying the Waypoint List

Registered waypoints (waypoint number 1 - 10000) can be displayed.

Waypoint number 00001 is registered as "HOME PORT".



#### Procedure

- Press **MENU**, **3**, and then **1 MARK**, and display the waypoint list.

#### Memo

- The position registered as HOME in the waypoint list can be easily set as the waypoint using the GOTO function.  
It is convenient to register a frequently used waypoint (such as the home port) as HOME.  
Please refer to "4.6.2 Starting Navigation with the GOTO Key" for details regarding the GOTO function.
- The waypoint on the route entered from an external device is displayed NEW at the extreme right of the waypoint list and then registered. The NEW is displayed when a waypoint on the next route has been entered or until the power is shut off.

## 4.4.2 Registering Waypoints

The following 5 positions can be registered in the waypoint list.

- (1) Own ship position
  - (2) Specified latitude and longitude
  - (3) Cursor position
  - (4) Position defined by a bearing and distance from a specified point
  - (5) A position registered in the event/mark list
- Up to 10000 points can be registered.

To register, first display the waypoint registration screen.

### Procedure

1. Press **MENU**, **3**, and then **1 MARK**, and display the waypoint list.
2. Move the cursor to the number you wish to register, and press **ENT**.

To move the cursor to the desired number, you can use the following methods:

- (1) Move with the up and down keys
- (2) Enter the desired number with the numeric keypad
- (3) Jump to a number without registered contents

Please refer to "4.8.2 Moving the Cursor to an Unregistered Number" for details.

3. The waypoint registration screen will be displayed.

ENTRY WPT	16:10:05 U1
1. WPT No. : 00001	
2. SYMBOL : ○	
3. COMMENT :	
4. POSITION : OWN SHIP	
5. WPT LAT : 35° 41. 3580' N	
6. WPT LON : 139° 34. 2540' E	
O. ENTRY	
W84	③D



4 #

Select waypoint position

ENTRY WPT	16:10:49 U1
1. WPT No. : 00001	
2. SYMBOL : ○	
3. COMMENT :	
4. POSITION : OWN SHIP	
5. WPT LAT : LAT/LON 0' N	
6. WPT LON : OWN SHIP 0' E	
CURSOR	
BRG/DIST	
O. ENTRY	EVENT LIST
W84	③D

Enter latitude and longitude with numeric keypad and register

Register current own ship position

Register cursor position

Register bearing and distance

Register from event/mark list

#### 4.4.2.1 Registering the Own Ship Position

The own ship position can be registered to the waypoint list.

##### Procedure

1. Please refer to "4.4.2 Registering Waypoints" and display the waypoint registration screen.
2. Press  "POSITION".
3. Press   and move the cursor to "OWN SHIP", and then press .
4. The ship's position is shown in "5. WPT LAT", "6. WPT LON".
5. Press  "ENTRY".

#### 4.4.2.2 Registering Latitude and Longitude

Any desired latitude and longitude can be registered in the waypoint list.

##### Procedure

1. Please refer to "4.4.2 Registering Waypoints" and display the waypoint registration screen.
2. Press  "POSITION".
3. Press   and move the cursor to "LAT/LON", and press .
4. Press  "WPT LAT", enter the latitude with the numeric keypad, and press   
N/S can be selected via  .
5. Press  "WPT LON", enter the longitude with the numeric keypad, and press   
E/W can be selected via    
When "WPT LAT" is entered, the cursor moves automatically to the latitude numerical entry position. If "WPT LON" entry is unnecessary, press .
6. Press  "ENTRY".

#### 4.4.2.3 Registering the Cursor Position

Any cursor position on the plot screen can be registered to the waypoint list.

##### Procedure

1. Please refer to "4.4.2 Registering Waypoints" and display the waypoint registration screen.
2. Press  "POSITION".
3. Press  , move the cursor to "CURSOR", and press .
4. The plot screen will be displayed.  
Press     to move the cursor, and press  at the position you wish to register.  
When the cursor is moved, the cursor position is displayed at the top right of the screen.
5. The cursor position is shown in "5. WPT LAT", "6. WPT LON".
6. Press  "ENTRY".

#### 4.4.2.4 Registering a Bearing and Distance from a Specified Position

A position can be specified as a start point, and then another position defined by its bearing and distance from said start point can be registered to the waypoint list.

Any of the following 6 can be used as a start point.

- |   |                      |
|---|----------------------|
| (1) Specified Longitude Latitude:                                     | Select "LAT/LON".    |
| (2) Own Ship Position:  | Select "OWN SHIP".   |
| (3) Cursor Position on Plot Screen:                                   | Select "CURSOR".     |
| (4) Position Registered in Waypoint List:                             | Select "WPT LIST".   |
| (5) Position Registered in Event/Mark List:                           | Select "EVENT LIST". |
| (6) When Continually Setting Waypoints, the Last Registered Position: | Select "PRE WPT"     |

##### Procedure

1. Please refer to "4.4.2 Registering Waypoints" and display the waypoint registration screen.
2. Press  "POSITION".
3. Press  , move the cursor to "BRG/DIST", and press .
4. The start position setting screen will be displayed.  
Press  "START POINT", press   to select the start point, and press .

##### (1) When "LAT/LON" is Selected

Press  "START LAT", enter the latitude with the numeric keypad, and press .

N/S can be selected via  .

Press  "START LON", enter the longitude with the numeric keypad, and press .

E/W can be selected via  .

When "START LAT" is entered, the cursor moves automatically to the latitude numerical entry position. If "START LON" entry is unnecessary, press .

## (2) When "OWN SHIP" is Selected

The ship's position is shown in "2. START LAT", "3. START LON".

## (3) When "CURSOR" is Selected

The plot screen will be displayed.

Press to move the cursor, and press at the position you wish to register.

When the cursor is moved, the cursor position is displayed at the top right of the screen.

The cursor position is shown in "2. START LAT", "3. START LON".

## (4) When "WPT LIST" is Selected

The waypoint list will be displayed. Move the cursor to the position you wish to use as the start point, and press .

The cursor can be moved to the number you wish to use as the start point in the following ways:

- (1) Move with the up and down keys
- (2) Enter the desired number with the numeric keypad

Please refer to "4.8.1 Moving the Cursor within a List" for more details.

The waypoint list position is shown in "2. START LAT", "3. START LON".

## (5) When "EVENT LIST" is Selected

The event/mark list will be displayed. Move the cursor to the position you wish to use as the start point, and press .

The cursor can be moved to the number you wish to use as the start point in the following ways:

- (1) Move with the up and down keys
- (2) Enter the desired number with the numeric keypad

Please refer to "4.8.1 Moving the Cursor within a List" for more details.

The event/mark list position is shown in "2. START LAT", "3. START LON".

## (6) When "PRE WPT" is Selected

When waypoints are continuously registered, selection can be performed from the second or later registered waypoint.

The last registered position is shown in "2. START LAT", "3. START LON".

5. Press "BEARING", enter the bearing with the numeric keypad, and press .
  6. Press "DISTANCE", enter the distance with the numeric keypad, and press .
- When "BEARING" is entered, the cursor moves automatically to the distance numerical entry position. If "DISTANCE" entry is unnecessary, press .
- The latitude and longitude of the position calculated from the start point, bearing, and distance will be displayed.
7. Press "ENTRY".

#### 4.4.2.5 Registering from the Event/Mark List

Positions registered in the event/mark list can be registered as waypoints.

##### Procedure

1. Please refer to "4.4.2 Registering Waypoints" and display the waypoint registration screen.
  2. Press  "POSITION".
  3. Press   , move the cursor to "EVENT LIST", and press .
  4. The event/mark list will be displayed. Move the cursor to the number you wish to register, and press .
- Refer to "4.8.1 Moving the Cursor within a List" for details regarding cursor movement.  
The event/mark list position is shown in "5. WPT LAT", "6. WPT LON".
5. Press  "ENTRY".

#### 4.4.3 Changing the Waypoint Symbol Shape

- The default symbol shape displayed when a waypoint is registered can be changed.
- The shapes of symbols which have been selected and specified individually for waypoints are not changed.
- Please refer to "4.3.6.2 Editing Waypoint Symbols" and "4.4.4 Editing Waypoint Information" for details regarding individual changes.

##### Procedure

1. Press  ,  , and then  , and select "WPT".
2. Press     to select the shape, and press .




Waypoint Symbol Shape List

#### 4.4.4 Editing Waypoint Information

- Registered waypoint information (symbol shape, comment, waypoint position) editing can be performed.
- Waypoints on routes which are currently being executed cannot be edited.

##### Procedure

- Press **MENU**, **3**, and then **1 MARK**, and display the waypoint list.
- Move the cursor to the waypoint number you wish to edit.  
The cursor can be moved in the following ways:
  - Move with the up and down keys
  - Enter the desired number with the numeric keypad  
Please refer to "4.8.1 Moving the Cursor within a List" for more details.
- Press **ENT** and display the waypoint registration screen.



Waypoint Registration Screen

##### (1) To Edit the Waypoint Number

- Press **1 MARK** "WPT No.".
- Use the numeric keypad to enter the waypoint number.  
The information will change to the entered waypoint number.

##### (2) To Edit the Symbol Shape

- Press **2 EVENT** "SYMBOL".
- Press **▲ ▼ ← →** to select the shape, and press **ENT**.

##### (3) To Edit a Comment

- Press **3** "COMMENT" and enter the comment.  
Please refer to "4.9 Entering Comments" for instructions on how to enter comments.

##### (4) To Edit the Waypoint Position


- Press **4 #** "POSITION", and enter the waypoint position.  
Refer to "4.4.2 Registering Waypoints" for details regarding entering the waypoint position.
- Press **0 \*** "ENTRY".

#### 4.4.5 Copying Waypoint Information

- Waypoint information can be copied to another waypoint number. Event and mark information can also be copied to the waypoint list. HOME is treated as number 1 on the waypoint list.
- The waypoints used by the shared active routes received from ECDIS, which are stored in number 10001 - 10512, are automatically overwritten when the next route is received. Waypoints which you wish to retain must be copied to a number between 1 and 10000.
- The temporary route waypoints stored in numbers 10513 to 11024 disappear when a different temporary route is created or the power is turned off. Waypoints which you wish to retain must be copied to a number between 1 and 10000.
- When there is no more space available, entries can be overwritten. However, waypoints used by a route cannot be overwritten.
- Select the source to copy from, and specify the number to which the information is to be copied.

##### Procedure

- Press **MENU**, **3**, and then **4 #**, and display the waypoint/route copy screen.
- Press **1 MARK** "WPT COPY".
- The cursor will move to the "COPY ORG", so press **ENT**.



- Press **▲** **▼** to select the copy source, and then press **ENT**.

The following is an overview of the copy source submenu.

- (1) WPT LIST: From the waypoint list, choose 1 waypoint number, or a string of contiguous waypoint numbers.  
Any number can be selected, from 1 to 11024.
- (2) EVENT LIST: From the event/mark list, choose 1 event/mark number, or a string of contiguous event/mark numbers.
- (3) WPT No.: Use the numeric keypad to enter the waypoint number.
- (4) FROM TO: Use the numeric keypad to enter the start and end numbers from the waypoint list.

##### (1) When "WPT LIST" is Selected

The range to be copied is confirmed when **ENT** is pressed after selecting the start and end point.

Please refer to "4.8.3 Selecting a Range within a List" for details regarding range selection.

##### (2) When "EVENT LIST" is Selected

The range to be copied is confirmed when **ENT** is pressed after selecting the start and end point.

Please refer to "4.8.3 Selecting a Range within a List" for details regarding range selection.


### (3) When "WPT No." is Selected

Use the numeric keypad to select the waypoint number to be copied, and press **ENT**.

### (4) When "FROM TO" is Selected

Multiple waypoint numbers can be copied. Use the numeric keypad to enter the start and end point waypoint numbers, and press **ENT**.

4. The cursor will move to the "COPY DEST", so press **ENT**.



5. Press **▲** **▼** to select the copy destination, and then press **ENT**.

The following is an overview of the copy destination submenu.

- (1) WPT LIST: Select the waypoint number from the waypoint list to copy information to.
- (2) WPT NO.: Use the numeric keypad to enter the waypoint number to copy information to.

When multiple numbers are selected as the copy source, the information will be pasted sequentially starting from the selected copy destination number.

#### (1) When "WPT LIST" is Selected


Numbers 1 - 10000 of the waypoint list will be displayed. Move the cursor and press **ENT**.

Please refer to "4.8.2 Moving the Cursor to an Unregistered Number" for more details.


#### (2) When "WPT No." is Selected

Use the numeric keypad to select the waypoint number to be copied to, and press **ENT**.

6. The cursor will move to the "COPY", so press **ENT**.



If there is insufficient continuous free space at the copy destination, the following will be displayed. Press **▲** **▼** to select the copy method, and press **ENT**.



The following is an overview of the display.

**ALL OVER WRITE** :Overwrites from selected copy destination.

Waypoints which are used by routes cannot be overwritten.

In this case, "ALL OVER WRITE" is not displayed.

**TO EMPTY AREA** : Copying is performed to a different empty area.

When there are no empty area in list, "TO EMPTY AREA" is not displayed.

**CANCEL** : Copying is cancelled.

### Memo


- When multiple contiguous numbers are selected as the copy source, selections which span registration group boundaries (10000 and 10512) cannot be made.  
Ex.) 9999 - 10001 and 10511 - 10513 cannot be selected.

#### 4.4.6 Deleting Waypoints

- Waypoints registered between 1 and 10000 can be deleted.
- Waypoints on routes which are currently being executed cannot be deleted.
- When a waypoint on a route which is not currently being performed is deleted, it will be deleted from the route as well.

##### Procedure

- Press **MENU**, **3**, and then **5 GOTO**, and the "DELETE WPT/ROUTE" Screen will be displayed.
- Press **1 MARK** "WPT DEL".



The following is an overview of the delete waypoint submenu.

- (1) ALL: Delete all waypoints from 1 to 10000.
- (2) WPT LIST: Specify the range to be deleted on the waypoint list.
- (3) WPT NO.: Specify the waypoint number to be deleted with the numeric keypad.
- (4) FROMTO: Enter the start and end points of the range to be deleted with the numeric keypad.

3. Press **▲** **▼** to select the waypoint to be deleted, and then press **ENT**.

##### (1) When "FROM TO" is Selected

Enter the start point and end point with the numeric keypad, and press **ENT**.

##### (2) When "WPT LIST" is Selected


The waypoint list will be displayed. Move the cursor to the start and end points, and press **ENT** to select the range.

Please refer to "4.8.3 Selecting a Range within a List" for more details.

##### (3) When "WPT No." is Selected

Enter the waypoint number with the numeric keypad, and press **ENT**.

4. The following will be displayed. Press **◀** **▶** to select "YES", and press **ENT**.




## 4.5 Route Planning

- Routes can be made from registered waypoints.
- A maximum of 100 routes can be created with this unit, with each route having up to 512 waypoints. Route widths, arrival circle radii, GC/RL, and other waypoint information can be set for each LEG. Please refer to "4.5.1 Displaying the Route List" for details regarding what waypoint information can be set.
- Created routes can be shared with external equipment such as ECDIS.
- Created routes are registered in the route list.
- The route list is divided into 3 regions, managed via numbering from 1 - 102.
  - 1 - 100: Routes created on this unit can be registered here.
  - 101: A shared active route received from ECDIS can be registered here.
  - 102: A temporary route can be registered here.
- Routes 1 - 101 are saved, so they remain even if the power is turned off. Route 102 is not saved, and will disappear if the power is turned off.

### 4.5.1 Displaying the Route List

Created routes can be displayed in the route list. LEG information for each LEG of the route, and waypoint information for each LEG, can also be displayed.

TTG (required time) cannot be calculated for routes containing LEGs for which no planned speed has been set.




#### Procedure

1. Press **MENU**, **3**, and then **2** to display the route list.
2. Move the cursor to the route number whose LEG information you wish to display, and press **ENT**.

Refer to "4.8.1 Moving the Cursor within a List" for details regarding cursor movement. The LEG information screen will be displayed.

On the LEG information screen, the route waypoints are listed in order.



3. Move the cursor to the waypoint whose waypoint information you wish to display, and press **ENT**.

Refer to "4.8.1 Moving the Cursor within a List" for details regarding cursor movement.

The diagram shows two screens illustrating route plan settings:

WROUTE PLAN 16:00:16 U1	
WPT No. :00006	
1. WIDTH PORT	: 1.00NM
2. WIDTH STBD	: 1.00NM
3. ARRIVAL RADIUS	: 1.00NM
4. SPEED	: 10.00kn
5. SAIL GC/RL	: RL
6. STATE	: USE
7. DETAIL	
0. ENTRY	
W84	③D

An arrow labeled "7 CURS" points from the first screen to the second screen.

WROUTE PLAN 16:02:38 U1	
WPT No. :00006	
1. 1. TURN RATE	: 30.0°/min
2. 2. TURN RADIUS	: 0.50NM
3. 3. TIME ZONE	: +000min
4. 4. RETURN	
5. SAIL GC/RL	: RL
6. STATE	: USE
0. ENTRY	
W84	③D

An arrow labeled "4#" points from the second screen back to the first screen.

**WPT Info** and **WPT Info (Details)** are labels below their respective screens.

The following items can be set.

- (1) WIDTH PORT: The port route width can be set.
- (2) WIDTH STBD: The starboard route width can be set.
- (3) ARRIVAL RAD: The arrival circle radius can be set.
- (4) SPEED: The planned speed of the LEG can be set.
- (5) SAIL GC/RL:
  - GC: Distance is calculated using the great circle method.  
Even if GC is set, RL is shown on plot screen.
  - RL: Distance is calculated using the rhumb line method.
- (6) STATUS:
  - USED: The waypoint is used.
  - SKIP: The waypoint remains on the route, but is skipped.  
All waypoints cannot be skipped.
  - DELETE: Delete from the route. The waypoint will remain on the waypoint list.  
The waypoint on the active route cannot be deleted.
- (7) DETAILS:
  - ROT, turn radius, and time zone settings can be performed.
  - (7-1) TURN RATE: The rate of turn when passing a waypoint can be set.
  - (7-2) TURN RADIUS: The turn radius when passing a waypoint can be set.
  - (7-3) TIME ZONE: The time difference with the waypoint can be set.

## Memo

- Great-Circle Sailing: The shortest distance from the current position to the waypoint can be used, but the bearing will be different from that determined on a nautical chart, and will change during movement.
- Rhumb line Sailing: Sailing can be performed directly from the current position to the waypoint, without changing bearing.  
The ship bearing will match that obtained by drawing a straight line on a nautical chart between the current position and the waypoint.
- Great-Circle sailing is generally used for long distance sailing, as it results in a shorter route than that obtained in Rhumb line sailing.

### 4.5.2 Creating Routes

- To create a route, decide the route number and select, in order, the waypoints to be used as way points.
- The same waypoint cannot be selected in a continuous manner.
- Up to 100 routes can be created.
- Up to 512 waypoints can be set on 1 route.


#### Procedure

1. Press **MENU**, **3**, and then **2** to display the route list.
2. Move the cursor to the number you wish to register, and press **ENT** to switch to the waypoint entry screen.

Please refer to "4.8.2 Moving the Cursor to an Unregistered Number" for more details.

ROUTE LIST 003 16:06:46 U0	
TOTAL001/102	
WPT DIST NM TTG	
001.	005H1.19 002 DAY 06 hr 07 min
TOKYO-KAGOSHIMA	
002.	
003.	
004.	
W84	BD

Move cursor to number you wish to register



ROUTE003 16:07:35 U0	
TOTAL000/512	
001 DIST----- NN ---DAY--hr--min	
001.	
W84	BD

Waypoint Entry Screen

Enter First  
Waypoint


3. Press **ENT** to display the waypoint list.
4. Move the cursor to the waypoint number you wish to register, and press **ENT**.  
Refer to "4.8.1 Moving the Cursor within a List" for details regarding cursor movement.
5. The waypoint information screen will be displayed. Select the item you wish to enter with the numeric keypad, and enter the waypoint information.  
Please refer to "4.5.1 Displaying the Route List" for details.  
Select "7. DETAIL" to set the TURN RATE, turn radius, or time zone. This is only used for routes shared with ECDIS.
6. Press **0\*** "ENTRY".
7. The screen will return to the route information screen where the waypoint is registered. To continue setting waypoints, repeat steps 4 to 6 above.

- Enter a comment.

Use the up and down keys to move the cursor to the comment entry field, and press **ENT**.

The unit will enter comment entry mode. Enter the comment.

Please refer to "4.9 Entering Comments" for instructions on how to enter comments.



Move the cursor to the comment entry field

Comment Entry Mode

- When you have completed route creation, press **CLR**, **DISP** or **MENU** to exit the route information screen.

### 4.5.3 Editing Routes

- Route waypoint information can be changed, and waypoints can be skipped, added, or deleted.

#### 4.5.3.1 Changing Waypoint Information

##### Procedure


- Refer to "4.5.1 Displaying the Route List", and select the waypoint information you wish to change.
- Use the numeric keypad to select the item number you wish to change, and change the waypoint information.  
Please refer to "4.5.1 Displaying the Route List" for details.  
Select "7. DETAILS" to set the TURN RATE, turn radius, and time zone. This is only used for routes shared with ECDIS.  
If "SKIP" is selected for "6. STATE", the waypoint will be skipped. Please refer to "4.3.7.3 Skipping Route Waypoints" for details regarding skip operation.  
If "DELETE" is selected for "6. STATE", the waypoint will be deleted from the route.
- To change a comment, move the cursor to the comment field on the LEG information screen and perform changes.
- When you have completed route editing, press **CLR**, **DISP**, or **MENU** to exit the route information screen.

### 4.5.3.2 Adding Route Waypoints

Waypoints can be added at any position along routes.

#### Procedure

1. Please refer to "4.5.1 Displaying the Route List", select the route to which you wish to add a waypoint, and display the LEG information.



LEG Information Screen

2. Move the cursor to the position where you wish to perform addition.  
Ex 1) To add a waypoint between 3 and 4, move the cursor to waypoint 4.  
Ex 2) To add a waypoint before 1, move the cursor to waypoint 1.  
Ex 3) To add a waypoint after the final waypoint, move the cursor past the final waypoint.

Refer to "4.8.1 Moving the Cursor within a List" for details regarding cursor movement.


To make an addition, press **ENT** after the final waypoint.

To make an addition between waypoints, or before the first waypoint, press and hold **\*** and **ENT**.

The waypoint list will be displayed.

- Ex 1) Adding a waypoint between 3 and 4

Move cursor to fourth waypoint




Waypoint List

Ex 2) Adding a waypoint at the start

Move cursor to first waypoint

ROUTE001	16:47:54 U1
TOKYO-KAGOSHIMA	TOTAL001/512
001 DIST00001. 69NM	000DAY23hr59min
001. 00002. 35° 17. 747' N 139° 42. 622' E	
○ YOKOSUKA	
BRG ---- DIST ----- NM	
002. 00003. 35° 15. 712' N 139° 47. 958' E	
○ Uraga	
BRG 114. 9° DIST 00004. 83NM R	
003. 00004. 34° 53. 290' N 139° 31. 332' E	
○ OOSHIMA	
BRG 211. 4° DIST 00026. 26NM R	
W84	3D




WPT LIST	HOME 16:14:32 U1
	TOTAL00008/10000
▲ HOME	35° 33. 0060' N 139° 49. 2954' E
○ HANEDA	
00002.	35° 17. 7474' N 139° 42. 6228' E
○ YOKOSUKA	
00003.	35° 15. 7122' N 139° 47. 9580' E
○ Uraga	
00004.	34° 53. 2908' N 139° 31. 3320' E
○ OOSHIMA	
00005.	34° 52. 9530' N 139° 17. 2032' E
▼ ○ HIGASHI IZU	
W84	3D

Waypoint List

Ex 3) Adding a waypoint at the end

Move cursor to after last waypoint

ROUTE001	16:47:09 U1
TOKYO-KAGOSHIMA	TOTAL001/512
008 DIST----. --NM ---DAY--hr--min	
006. 00008. 33° 10. 460' N 135° 51. 415' E	
○ SHIONOMISAKI	
BRG 241. 9° DIST 00170. 05NM R	
007. 00010. 30° 54. 415' N 130° 40. 942' E	
○ SATAMISAKI	
BRG 242. 8° DIST 00297. 36NM R	
008.	
W84	3D



WPT LIST	HOME 16:14:32 U1
	TOTAL00008/10000
▲ HOME	35° 33. 0060' N 139° 49. 2954' E
○ HANEDA	
00002.	35° 17. 7474' N 139° 42. 6228' E
○ YOKOSUKA	
00003.	35° 15. 7122' N 139° 47. 9580' E
○ Uraga	
00004.	34° 53. 2908' N 139° 31. 3320' E
○ OOSHIMA	
00005.	34° 52. 9530' N 139° 17. 2032' E
▼ ○ HIGASHI IZU	
W84	3D

Waypoint List

- Move the cursor to the waypoint number you wish to register, and press **ENT**.

Refer to "4.8.1 Moving the Cursor within a List" for details regarding cursor movement.

- The waypoint information screen will be displayed. Select the item number you wish to enter with the numeric keypad, and enter the waypoint information.  
Please refer to "4.5.1 Displaying the Route List" for details.  
Select "7. DETAIL" to set the "TURN RATE", "TURN RADIUS", or "TIME ZONE". This is only used for routes shared with ECDIS.

- Press **0\*** "ENTRY".


- When you have completed waypoint addition, press **CLR**, **DISP**, or **MENU** to exit the route information screen.

#### 4.5.4 Copying Routes

- Routes which have been created can be copied to different route numbers.
- The waypoints used by the shared active routes received from ECDIS in number 101 are automatically overwritten when the next route is received. Routes which you wish to retain must be copied to a number between 1 and 100.
- The temporary route waypoints stored in number 102 disappear when a different temporary route is created or the power is turned off. Routes which you wish to retain must be copied to a number between 1 and 100.
- Multiple waypoints can be copied, as long as their numbers are contiguous.
- When there is no more space available, entries can be overwritten. Overwriting cannot be performed for active routes.
- Select the source to copy from, and specify the number to which the information is to be copied.
- In the case a temporary route and sharing route are copied, the waypoint need also be copied.

##### Procedure

1. Press  ,  , and then  to display the waypoint/route copy screen.
2. Press  "ROUTE COPY".
3. The cursor will move to the "COPY ORG", so press  .



4. Press   to select the copy source, and then press  .

The following is an overview of the copy source submenu.

- (1) ROUTE LIST: From the route list, choose 1 route number, or a string of contiguous route numbers.  
Any number can be selected, from 1 to 102.
- (2) ROUTE NO.: Enter the route number with the numeric keypad.
- (3) FROM TO: Enter the start and end numbers from the route list with the numeric keypad.

##### (1) When "ROUTE LIST" is Selected

The range to be copied is confirmed when  is pressed after selecting the start and end point.

Please refer to "4.8.3 Selecting a Range within a List" for details regarding range selection.

##### (2) When "ROUTE No." is Selected


Enter the route number you wish to copy with the numeric keypad, and press  .

#### (4) When "FROM TO" is Selected

Multiple route numbers can be copied.

Enter the start point and end point with the numeric keypad, and press **ENT**.

4. The cursor will move to the "COPY DEST", so press **ENT**.



5. Press **▲** **▼** to select the copy destination, and then press **ENT**.

The following is an overview of the copy destination submenu.

- (1) ROUTE LIST: Select the destination route number to copy to from the route list.  
(2) ROUTE NO.: Use the numeric keypad to enter the route number to copy information to.

When multiple numbers are selected as the copy source, the information will be pasted sequentially starting from the selected copy destination number.

##### (1) When "ROUTE LIST" is Selected

The route list, from 1 to 100, will be displayed, so move the cursor and press **ENT**.


Please refer to "4.8.2 Moving the Cursor to an Unregistered Number" for more details.

##### (2) When "ROUTE No." is Selected


Use the numeric keypad to select the route number to be copied to, and press **ENT**.

6. In the case a temporary route and sharing route are copied, select the copy destination of waypoint. Please refer to "4.4.5 Copying Waypoint Information" procedure 5 for selection of copy destination.

7. The cursor will move to the "COPY", so press **ENT**.



If there is insufficient continuous free space at the copy destination location, the following will be displayed. Press **▲** **▼** to select the copy method, and press **ENT**.



The following is an overview of the display.

ALL OVERWRITE: Overwrites from selected copy destination.

Overwriting cannot be performed for active routes.

In this case, "ALL OVER WRITE" is not displayed.

TO EMPTY AREA: Copying is performed to a different empty area:

When there are no empty area in list, "TO EMPTY AREA" is not displayed.

CANCEL: Copying is cancelled.

### Memo


- The boundary of 100 cannot be crossed when selecting multiple numbers as the copy source.  
Ex) A selection such as "99 - 101" is invalid.

## 4.5.5 Deleting Routes

- Routes registered between 1 and 100 can be deleted.
- The waypoint on the route to be deleted can be deleted at the same time.
- In the case the waypoint is also deleted, the waypoint used on the different route is not deleted.
- Active routes cannot be deleted.

### Procedure

1. Press **MENU**, **3**, and then **5 GOTO** to display the waypoint/route deletion screen.
2. Press **2 EVENT** "ROUTE DEL".



The following is an overview of the route deletion submenu.

- (1) ALL: Delete all routes between 1 and 100.
- (2) FROM TO: Enter the start and end points of the range to be deleted with the numeric keypad.
- (3) ROUTE LIST: Specify the range to be deleted on the waypoint list.
- (4) ROUTE No.: Specify the route number to be deleted with the numeric keypad.

3. Press **▲** **▼** to select the route to be deleted, and then press **ENT**.

### (1) When "FROM TO" is Selected

Enter the start point and end point with the numeric keypad, and press **ENT**.

### (2) When "ROUTE LIST" is Selected

The route list will be displayed. Move the cursor to select the start and end points, and press **ENT** to select the range.

Please refer to "4.8.3 Selecting a Range within a List" for more details.

### (3) When "ROUTE No." is Selected


Enter the route number with the numeric keypad, and press **ENT**.

4. Press **▲** **▼** to select whether the waypoint is deleted, and then press **ENT**.

The following is an overview of the waypoint deletion submenu.

- (1) ROUTE: Only the route is deleted.  
(2) ROUTE + WPT: The route as well as the waypoint used on the route are deleted.  
The waypoint used on the different route is not deleted.  
(3) CANCEL: Deleting is cancelled.

5. The following will be displayed. Press **◀** **▶** to select "YES", and press **ENT**.



## 4.5.6 Sharing Routes with ECDIS

This unit can be used to send routes to ECDIS or radars, and also to receive routes created by ECDIS (data route sharing). Routes which are underway (active routes) can be shared.

If a route is switched on this unit or on ECDIS when sharing the active route, the connecting equipment's route will also switch.

In order to share routes, the equipment must support sharing (ECDIS, radar), and be connected in a LAN.

### 4.5.6.1 Sharing Data Routes

This unit can be used to send routes to ECDIS, and also to receive routes created by ECDIS. If data route sharing is configured, data route reception will occur automatically.

First, configure data route sharing.

If data routes are not shared, configure sharing as directed in "4.20.7.7 Setting LAN Settings".

To send a data route, follow the procedures below to select and send the desired route.

#### Procedure

1. Press **MENU**, **◀**, **▶**, and **ENT**, and select "TRANSFER WPT / ROUTE (LAN)".
2. **MARK** Press "OUT / IN".
3. Press **▲** **▼** to select "OUT", and then press **ENT**.
4. **EVENT** Press "CONNECT".
5. Select the connection destination with **▲** **▼**, and press **ENT**.

Normally, "MULTICAST" should be selected for the destination.  
To send to a specific unit, select "UNICAST".

6. When "UNICAST" is selected, press  and  to select the Destination IP "TO IP" and "PORT No.".

7.  Press "FORMAT".

8. Press   to select "SHARE ROUTE", and press .

9.  Press "OUT TYPE".

10. Press   to select the output data, and press .


The following is an overview of the output data submenu.

- (1) ALL: Output all routes between 1 and 101.
- (2) ROUTE LIST: Select a range on the route list to be output.
- (3) ROUTE No.: Specify the route number to be sent with the numeric keypad.
- (4) FROM TO: Enter the start and end points of the range to be sent with the numeric keypad.

Please refer to "4.8.3 Selecting a Range within a List" for details regarding range selection.

11.  Press "START".

12. The following will be displayed. Select "YES", and press .



## 4.5.6.2 Sharing Active Routes

If a route is switched on this unit or on ECDIS when sharing the active route, the connecting equipment's route will also switch.

Sharing must be enabled to share active routes.

The following is an overview of the active route sharing configuration submenu.

- (1) SHARE1: If the active route is switched on the unit, the route will automatically be sent out to connected equipment.  
When a shared route is received, the route is automatically switched.
- (2) SHARE2: If the active route is switched on the unit, a request is made to the user of the unit before the route is sent. Transmission of the route to the connected equipment is dependant on the permission of the user.  
If the user has not authorized sending, the active route will only be executed on the local unit.  
When a shared route is received, the route is automatically switched.
- (3) SHARE3: If the active route is switched on the unit, the route will automatically be sent out to connected equipment.  
When a shared route is received, the user is asked whether or not they want to switch routes.  
If the user does not authorize route switching, the route will not be switched.
- (4) SHARE4: If the active route is switched on the unit, a request is made to the user of the unit before the route is sent. Transmission of the route to the connected equipment is dependant on the permission of the user.  
If the user has not authorized sending, the active route will only be executed on the local unit.  
When a shared route is received, the user is asked whether or not they want to switch routes.  
If the user does not authorize route switching, the route will not be switched.

If the active route is configured for sharing, an icon will be displayed on the status bar at the bottom of the screen.

If the icon is not displayed, refer to "4.20.7.7 Setting LAN Settings" and configure sharing.

SHARE1 Icon:  SHARE2 Icon:  SHARE3 Icon:  SHARE4 Icon: 

### Procedure

#### (1) SHARE 1 Active Route Sharing

##### Route Start / Output

1. Start the route as directed in "4.6 Performing Navigation".  
LAN route output starts automatically.


##### Route Reception

Route switching occurs automatically.

#### (2) SHARE 2 Active Route Sharing

##### Route Start / Output

1. Start the route as directed in "4.6 Performing Navigation".
2. When the route is started, the following will be displayed.  
Select "YES" to output the active route externally.  
Select "NO" to not output the active route externally. If no external output is performed, the active route is performed only on the local unit.



### **Route Reception**

Route switching occurs automatically.

## **(3) SHARE 3 Active Route Sharing**

### **Route Start / Output**

1. Start the route as directed in "4.6 Performing Navigation".  
LAN route output starts automatically.

### **Route Reception**

When an active route is received, the following is displayed.

Select "YES" to switch the active route.

Select "NO" to not switch the active route. If the active route is not switched, the unit will not switch routes and will stop sharing route navigation.

RECEIVED ACTIVE ROUTE
DO YOU START IT?
<b>NO    YES</b>

## **(4) SHARE 4 Active Route Sharing**

### **Route Start / Output**

1. Start the route as directed in "4.6 Performing Navigation".
2. When the route is started, the following will be displayed.  
Select "YES" to output the active route externally.  
Select "NO" to not output the active route externally. If no external output is performed, the active route is performed only on the local unit.

EXTERNAL OUTPUT
A ROUTE
ARE YOU SURE?
<b>NO    YES</b>

### **Route Reception**

When an active route is received, the following is displayed.

Select "YES" to switch the active route.

Select "NO" to not switch the active route. If the active route is not switched, the unit will not switch routes and will stop sharing route navigation.

RECEIVED ACTIVE ROUTE
DO YOU START IT?
<b>NO    YES</b>

#### 4.5.7 Setting Route Default Settings

- The route default value is applied to routes created via GOTO.
- The following is an overview of the route default settings submenu.
  - (1) WIDTH PORT: The port route width can be set.
  - (2) WIDTH STBD: The starboard route width can be set.
  - (3) ARRIVAL RAD: The arrival circle radius can be set.
  - (4) SPEED: The planned speed can be set.
  - (5) SAIL GC/RL: GC or RL can be selected as the sail calculation method.
  - (6) SOG SMOOTHING: Smoothing can be applied to ship speed when calculating expected arrival time and expected time required.  
Up to 99 seconds of smoothing can be set. When the estimated arrival time has a large degree of variance, use a large smoothing value.

M DEFAULT SET 16:37:18 U1	
1. WIDTH PORT	: 1.00NM
2. WIDTH STBD	: 1.00NM
3. ARRIVAL RAD	: 1.00NM
4. SPEED	: 10.00kn
5. SAIL GC/RL	: RL
6. SOG SMOOTHING	: OFF

#### Procedure

- Press **MENU**, **3**, and then **7 CURS** to display the route default setting screen.
- Select the number of the item you wish to set.
- Select "SET" with **▲** **▼** and press **ENT**.  
If you do not wish to set an item, select "OFF" and press **ENT**.
- Enter values with the numeric keypad, and press **ENT**.

## 4.6 Performing Navigation


- Registered and temporary routes can be started.
- Navigation can be performed via the following methods.
  - (1) Selecting a route from the route list
  - (2) Selecting a waypoint with the GOTO key
  - (3) Selecting a route with the GOTO key
  - (4) Creating a route with the GOTO key
- Navigation cannot be performed above 89 degrees north or south.
- Temporary routes created with GOTO use the route widths, arrival circle radiiuses, and planned speeds set as route default setting values.  
Please refer to "4.5.7 Setting Route Default Settings" for details regarding setting route default setting values.
- Waypoint switching occurs when the arrival circle is reached.

### 4.6.1 Selecting a Route from the Route List

Routes can be selected from the route list and started.

#### Procedure

1. Press **MENU**, , and then  to display the route start/end screen.
  2. The route list will be displayed. Move the cursor to the route number you wish to start, and press **ENT**.
- Refer to "4.8.1 Moving the Cursor within a List" for details regarding cursor movement.
3. The route start/end screen will be displayed, so perform route settings.



The following is an overview of each submenu.

- (1) LEG CHANGE: You can set whether LEG change is performed automatically or manually when own ship arrives within the waypoint arrival circle.

AUTO: The waypoint automatically changes to the next waypoint.  is displayed in the status bar.

When the arrival circle is reached, the alarm of the unit will be sounded, and the waypoint will be updated, displaying the following. The display will disappear automatically in 5 seconds.

When the final waypoint is reached, the arrival alarm sound configured in the alarm settings will be sounded.

**WPT IS CHANGED**

**MANUAL:** Switching to the next waypoint is performed manually.  is displayed in the status bar. When the arrival circle is reached, the arrival alarm sound configured in the alarm settings will be sounded, and the following will be displayed. Press  to stop the alarm and update the waypoint.

PLEASE PUSH ► AND  
CHENGE A WPT

- (2) **DIRECTION:** You can set whether to navigate in the order of the waypoints, or to navigate starting from the final waypoint.  
**ORDER:** Navigation is performed in the order of the waypoints.  
**REVERSE:** Navigation is performed starting with the final waypoint.
- (3) **NAVIGATION:** Starts and stops navigation.  
**START:** Navigation is started.  
**END:** Navigation is stopped.

#### (1) Setting the LEG CHANGE Method

-  1 Press "LEG CHANGE", press   to select the LEG change method, and then press .


#### (2) Setting the DIRECTION

-  1 Press "DIRECTION", press   to select the direction, and then press .

4. Press  3 "NAVIGATION" to start navigation.

## 4.6.2 Starting Navigation with the GOTO Key

- If a waypoint or route is selected with the GOTO key, navigation starts to that waypoint.
  - If a waypoint on the active route is selected with the GOTO key, navigation restarts from that waypoint.
  - Routes created with GOTO are stored as a temporary route with route number 102.
  - The GOTO key can be used from any screen other than the menu screen, waypoint information screen, or Navigation Assistance 4 screen.
  - The following methods can be used to select the waypoint.
- (1) Set HOME PORT as the waypoint.
  - (2) Enter the waypoint number.
  - (3) Enter the route number.
  - (4) Enter the event / mark number.
  - (5) Set the cursor position as the waypoint (Up to 512 waypoints can be set, allowing temporary route creation)
  - (6) Select from each list (waypoint list, route list, event / mark list).
  - (7) Enter the waypoint number on the active route to restart the navigation.



### Procedure

#### (1) Set HOME PORT as the waypoint

HOME sets the HOME PORT registered at the start of they waypoint list as the waypoint. If a waypoint is set as HOME, it can be easily set as a waypoint.

If no HOME PORT is registered, "1. HOME" will not be displayed.

1. Press 5 GOTO and then 1 MARK .

Navigation will start with the HOME PORT as the destination waypoint.

#### (2) Enter the waypoint number

If you know the waypoint number, you can enter the number to set the waypoint.

1. Press 5 GOTO and then 2 EVENT .

2. Enter the waypoint number, and press ENT to start navigation.

### (3) Select a route number

If you know the route number, you can enter the number to set the route.

1. Press **5 GOTO** and then **3 ↗**.
2. Enter the route number, and press **ENT**.
3. The route start / end screen will be displayed, so perform route settings.  
Please refer to "4.6.1 Selecting a Route from the Route List" for details regarding each submenu and configuration methods.
4. **3 ↙** Press "NAVIGATION" to start navigation.

### (4) Select from the event / mark number


If you know the event / mark number, you can enter the number to set the waypoint.

1. Press **5 GOTO** and then **4 #**.
2. Enter the event / mark number, and press **ENT** to start navigation.

### (5) Set the cursor position as the waypoint


Any cursor position on the plot screen can be set as waypoints. Multiple waypoints can be selected and a temporary route created. Temporary routes can also be added to the route list as a permanent route.

1. Press **5 GOTO**, and then **5 GOTO**, and display the plot screen.
2. Move the cursor to the waypoint position, and press **ENT**.  
For multiple waypoints, move the cursor again, and press **ENT**.  
Pressing **CLR** deletes the previous waypoint.



At point you wish to make waypoint,  
press **ENT**

Move cursor →



At point you wish to make waypoint,  
press **ENT** twice.

3. Press **ENT** again at the final waypoint to start navigation.
4. The following will be displayed.

DOES IT ENTRY WITH  
A ROUTE LIST?  
NO YES

- If you don't wish to register the route in the route list, select "No" and press **ENT**. Navigation will start without route registration.
- If you wish to register the route in the route list, select "Yes" and press **ENT**. The route list will be displayed.
- Move the cursor to the number you wish to register, and press **ENT**. The route will be registered in the route list, and navigation will start.
- Please refer to "4.8.2 Moving the Cursor to an Unregistered Number" for more details.
- The waypoints selected with the cursor will also be registered in the waypoint list. Registered waypoint numbers will be displayed as waypoint symbols on the plot screen.

#### **(6) Select from the waypoint list**

A waypoint can be selected from the waypoint list.

- Press **5 GOTO**, **6 ←→**, and then **1 MARK**, and display the waypoint list.
  - Move the cursor to the waypoint number you wish to set as the waypoint, and press **ENT** to start navigation.
- For details regarding moving the cursor, please refer to "4.8.1 Moving the Cursor Within a List".

#### **(7) Select from the event / mark list**

A waypoint can be selected from the event / mark list.

- Press **5 GOTO**, **6 ←→**, and then **2 EVENT**, and display the event / mark list.
  - Move the cursor to the number you wish to set as the waypoint, and press **ENT** to start navigation.
- Refer to "4.8.1 Moving the Cursor within a List" for details regarding cursor movement.

#### **(8) Select a route from the route list**

The GOTO key can be used to select and execute a route.


- Press **5 GOTO**, **6 ←→**, and then **3 ←→**, and display the route list.
  - Move the cursor to the number you wish to execute, and press **ENT**.
- Refer to "4.8.1 Moving the Cursor within a List" for details regarding cursor movement.
- The route start / end screen will be displayed, so perform route settings.
  - Please refer to "4.6.1 Selecting a Route from the Route List" for details regarding each submenu and configuration methods.
- Press **3 ←→** "NAVIGATION" to start navigation.

#### **(9) Enter the waypoint number on the active route.**

If a waypoint number on the active route is entered, navigation will restart from the configured waypoint after discarding the route currently executed.

- Press **5 GOTO** and then **2 EVENT**.
- Enter the waypoint number, and press **ENT** to start navigation.

Ex) To restart the route from waypoint number 0004.



### 4.6.3 Stopping Navigation

- Navigation currently underway can be stopped.
- To end the navigation, there are two methods: selecting in the menu and holding down 

#### 4.6.3.1 Ending Navigation with GOTO key

- Operation can be performed on any screen other than the menu, waypoint information, navigation assistance 4 screen.

##### Procedure


- Press and hold down  (over 3 seconds).
- The following will be displayed, and then select "YES".

ROUTE END  
ARE YOU SURE?  
**NO**   **YES**

#### 4.6.3.2 Ending Navigation in Menu

##### Procedure

- Press  ,  , and then  to display the route start/end screen.



- Press  "NAVIGATION" to stop navigation.
- The following will be displayed. Select "YES".

ROUTE END  
ARE YOU SURE?  
**NO**   **YES**

## 4.7 Events/Marks

- Events, marks, MOB, and lines are all registered in the event/mark list.

### 4.7.1 Displaying Events/Marks

- A list of all registered events and marks can be displayed.
- MOB is registered as event number 000.

Event/Mark number selected by cursor	Number of Entries
Up/Down Scroll	EVENT LIST 000 16:00:00 U1 TOTAL 0011/1000
Entry Position	001. 35° 30. 1590' N 139° 55. 9116' E E 10 AUG.'08 01:45
Event/Mark Number	002. 35° 41. 2643' N 139° 34. 7306' E ML ▲ 25 NOV.'09 15:59
Symbol	003. 35° 28. 7306' N 139° 51. 2131' E E TOKYO-BAY 03 JAN.'08 21:10
Comment	004. 35° 29. 1499' N 139° 55. 1064' E M → SODEGAURA 30 JAN.'08 16:04
	005. 35° 25. 4248' N 139° 43. 1170' E E YOKOHAMA 09 FEB.'08 08:05
	W84 BD

Event/Mark List

#### Procedure

- Press **MENU**, **2 EVENT**, and **7 CURS** in order to display the event / mark list.

### 4.7.2 Event and Mark Information Display

- Registered event and mark information can be displayed.

#### Procedure

- Press **MENU**, **2 EVENT**, and **7 CURS** in order to display the event / mark list.
- Move the cursor to the number of the event or mark you wish to display, and press **ENT** to display the event or mark information.  
Refer to "4.8.1 Moving the Cursor within a List" for details regarding cursor movement.

No. 014	15:59:48 U1
1. SYMBOL :	□
2. COMMENT : YOKOHAMA	
35° 25. 4240' N 139° 43. 1170' E	
31 DEC.'06 23:59	
WATER TEMP: +15. 0°C	
WATER DPTH: 252. 1m	
CURRENT	
A: 2. 2° 0. 9kn 10. 3m	
B: 1. 4° 2. 0kn 50. 1m	
C: 3. 4° 1. 8kn 109. 2m	
O. ENTRY	
W84	BD

Event/Mark Information

If there are no externally connected devices, and for mark information, water temperature, water depth, and current information is not displayed.

### 4.7.3 Editing Event and Mark Information

- Registered event (including MOB) and mark information (symbol, comment) can be edited.

#### Procedure

- Display the event or mark information to be displayed using the procedure given in "4.7.2 Event and Mark Information Display".

##### (1) To Change the Symbol Shape

- Press "SYMBOL".
- Press to select the shape, and press .

##### (2) To Change Comment

- Press "COMMENT" and enter the comment.  
Please refer to "4.9 Entering Comments" for instructions on how to enter comments.
- Press "ENTRY".

### 4.7.4 Deleting Event/Mark Information

- Registered events and marks can be deleted.  
Deletion can be performed using one of the methods below.
  - Specify a range on the event/mark list for deletion
  - Delete all events
  - Delete all marks
  - Delete all events and marks

#### Procedure

- Press , , and in order to display the delete screen.  
To specify a range on the event/mark list for deletion
- Press "DELETE EVENT/MARK LIST" to display the event/mark list.
- Select the range you wish to delete.  
The range to be copied is confirmed when is pressed after selecting the start and end point.  
Please refer to "4.8.3 Selecting a Range within a List" for details regarding range selection.

#### To delete all

- To delete all events, press "DELETE ALL EVENT".  
To delete all marks, press "DELETE ALL MARK".  
To delete all events and marks, press "DELETE ALL EVENT/MARK".

## 4.8 List Screen Operation

- This unit displays waypoints, events, marks, and routes in list form.
- All lists use the same operating procedures.

### 4.8.1 Moving the Cursor within a List

- The cursor can be moved within a list in the following ways:
    - The cursor can be moved via the directional keys
    - The cursor can be moved by entering a number with the numeric keypad
- These function for cursor operation in all lists.

#### 4.8.1.1 Moving the Cursor with the Directional Keys

The operation examples show cursor movement within the waypoint list, but the instructions provided apply to operation within all lists.


The up and down keys can be used to move the cursor up and down, while the left and right keys can be used to advance to the next page.

##### Procedure

- Display the list.
- Press to move the cursor up or down, and to move to the next page.


WPT LIST		HOME	15:59:42	U1
TOTAL		00008	/10000	
▲	HOME	35° 33. 0060' N	139° 49. 2954' E	
○	HANEDA			
00002.	35° 11. 7474' N	139° 42. 6228' E		
○	YOKOSUKA			
00003.	35° 15. 7122' N	139° 47. 9580' E		
○	URAGA			
00004.	34° 53. 2908' N	139° 31. 3320' E		
○	OOSHIMA			
00005.	34° 52. 9530' N	139° 17. 2032' E		
▼	○ HIGASHI IZU			
W84				③D

Waypoint List



WPT LIST		00005	16:00:18	U1
TOTAL		00008	/10000	
▲	HOME	35° 33. 0060' N	139° 49. 2954' E	
○	HANEDA			
00002.	35° 11. 7474' N	139° 42. 6228' E		
○	YOKOSUKA			
00003.	35° 15. 7122' N	139° 47. 9580' E		
○	URAGA			
00004.	34° 53. 2908' N	139° 31. 3320' E		
○	OOSHIMA			
00005.	34° 52. 9530' N	139° 17. 2032' E		
▼	○ HIGASHI IZU			
W84				③D

Move up / down



WPT LIST		00006	16:00:57	U1
TOTAL		00008	/10000	
▲	HOME	34° 30. 5291' N	138° 51. 2010' E	
○	IROUZAKI			
00001.				
00008.	33° 10. 4604' N	135° 51. 4158' E		
○	SHIONOMISAKI			
00009.				
00010.	30° 54. 4158' N	130° 40. 9422' E		
▼	○ SATAMISAKI			
W84				③D

Move to next page

#### 4.8.1.2 Using the Numeric Keypad to Enter a Number and Move the Cursor


The operation examples show selection of waypoint 5 in the waypoint list, but the instructions provided apply to operation within all lists.

##### Procedure

1. Display the list.
2. Enter the destination number "5" with the numeric keypad, and press  .  
The cursor moves to number 5.

The number entered with the numeric keypad is displayed

WPT LIST	00005 16:01:43 U1
TOTAL 00008 / 10000	
▲ HOME	35° 33. 0060' N 139° 49. 2854' E
○ HANEDA	00002. 35° 11. 7474' N 139° 42. 6228' E
○ YOKOSUKA	00003. 35° 15. 1122' N 139° 41. 9580' E
○ URAGA	00004. 34° 53. 2908' N 139° 31. 3320' E
○ OOSHIMA	00005. 34° 52. 9530' N 139° 11. 2032' E
▼ ○ HIGASHI IZU	
W84	BD



WPT LIST	00005 16:02:13 U1
TOTAL 00008 / 10000	
▲ HIGASHI IZU	00005. 34° 52. 9530' N 139° 11. 2032' E
○ IROUZAKI	00006. 34° 30. 5291' N 138° 51. 2010' E
○ SHIONOMISAKI	00007.
○ SHIONOMISAKI	00008. 33° 10. 4604' N 135° 51. 4158' E
○ SATAMISAKI	00009.
▼ ○ SATAMISAKI	
W84	BD

Enter move destination, "5", with numeric keypad

Cursor moves to number entered, "5"

##### Memo

- In the list that displays only the registered number, when the input number with numeric keypad doesn't exist, the cursor moves to a number that is the nearest the input number.

#### 4.8.2 Moving the Cursor to an Unregistered Number


- The cursor can be moved within a list in the following ways:
  - (1) The cursor can be moved via the up and down keys
  - (2) You can jump to an unregistered number.
  - (3) The cursor can be moved by entering a number with the numeric keypad
- This is used when registering waypoints, selecting copy destinations for waypoints, creating routes, and selecting copy destinations for routes.

#### 4.8.2.1 Moving the Cursor with the Directional Keys

##### Procedure

1. Display the list.
2. Press  to move the cursor.

WPT LIST	HOME 16:06:16 U1
TOTAL 00008 / 10000	
▲ HOME	35° 33. 0060' N 139° 49. 2854' E
○ HANEDA	00002. 35° 11. 7474' N 139° 42. 6228' E
○ YOKOSUKA	00003. 35° 15. 1122' N 139° 41. 9580' E
○ URAGA	00004. 34° 53. 2908' N 139° 31. 3320' E
○ OOSHIMA	00005. 34° 52. 9530' N 139° 11. 2032' E
▼ ○ HIGASHI IZU	
W84	BD



WPT LIST	00007 16:08:06 U1
TOTAL 00008 / 10000	
▲ IROUZAKI	00006. 34° 30. 5291' N 138° 51. 2010' E
○ SHIONOMISAKI	00007.
○ SHIONOMISAKI	00008. 33° 10. 4604' N 135° 51. 4158' E
○ SATAMISAKI	00009.
▼ ○ SATAMISAKI	00010. 30° 54. 4158' N 130° 40. 9422' E
W84	BD

Waypoint List

The cursor moves

Press  to move the cursor to the next page.

#### 4.8.2.2 Jumping to an Unused Number


The cursor can jump to the nearest unused number (unregistered number) in a list. This can be used when you want to register an item, but do not know of an unused number.

##### Procedure

1. Display the list.
2. Each time  is pressed while pressing  , the cursor will jump to the start of the unused field.

WPT LIST		HOME 16:06:16 U <small>1</small>
TOTAL00008/10000		
	HOME	35° 33. 0060' N 139° 49. 2954' E
	HANEDA	
	YOKOSUKA	00002. 35° 17. 7474' N 139° 42. 6228' E
	URAGA	00003. 35° 15. 7122' N 139° 47. 8580' E
	OOSHIMA	00004. 34° 53. 2908' N 139° 31. 3320' E
	HIGASHI IZU	00005. 34° 52. 8530' N 139° 11. 2032' E
	W84	
		③④

Waypoint List




WPT LIST		00007 16:11:12 U <small>1</small>
TOTAL00008/10000		
	00001.	
	SHIONOMISAKI	00008. 33° 10. 4604' N 135° 51. 4158' E
	SATAMISAKI	00009.
	W84	00010. 30° 54. 4158' N 130° 40. 8422' E
		00011.
		③④

Move to waypoint number 7

3. Each time  is pressed while pressing  , the cursor will jump to the end of the unused field.

WPT LIST		HOME 16:06:16 U <small>1</small>
TOTAL00008/10000		
	HOME	35° 33. 0060' N 139° 49. 2954' E
	HANEDA	
	YOKOSUKA	00002. 35° 17. 7474' N 139° 42. 6228' E
	URAGA	00003. 35° 15. 7122' N 139° 47. 8580' E
	OOSHIMA	00004. 34° 53. 2908' N 139° 31. 3320' E
	HIGASHI IZU	00005. 34° 52. 8530' N 139° 11. 2032' E
	W84	
		③④

Waypoint List



WPT LIST		10000 16:11:48 U <small>1</small>
TOTAL00008/10000		
	10000.	
	HANEDA	HOME 35° 33. 0060' N 139° 49. 2954' E
	YOKOSUKA	00002. 35° 17. 7474' N 139° 42. 6228' E
	URAGA	00003. 35° 15. 7122' N 139° 47. 8580' E
	OOSHIMA	00004. 34° 53. 2908' N 139° 31. 3320' E
	W84	
		③④

Move to waypoint number 10000


### 4.8.2.3 Using the Numeric Keypad to Enter a Number and Move the Cursor

The operation examples show selection of waypoint 7 in the waypoint list, but the instructions provided apply to operation within all lists.

#### Procedure

1. Display the list.
2. Enter the destination number "7" with the numeric keypad, and press **ENT**.

The cursor moves to number 7.



Enter move destination number  
"7" with numeric keypad

Cursor moves to number entered,  
"7"

### 4.8.3 Selecting a Range within a List


- The following methods can be used to select a range in a list:
  - (1) The cursor can be moved via the up and down keys to select the start and end points
  - (2) The cursor can be moved by entering a number with the numeric keypad to select the start and end points
- The two methods can be combined, such as selecting the start point with the up and down keys, and the end point with the numeric keypad.
- This function is used when selecting a range of waypoint copy sources, route copy sources, waypoints to be deleted, routes to be deleted, and events/marks to be deleted.

#### 4.8.3.1 Moving the Cursor with the Directional Keys and Selecting a Range

The operation examples show selection of waypoints 2 to 5 in the waypoint list, but the instructions provided apply to operation within all lists.

##### Procedure

- Display the list.
- Press to move the cursor to "2", and press to set the start point.
- Press to move the cursor to "5", selecting the range from 2 to 5.  
Press to move the cursor to the next page.
- Press to set the range.




### 4.8.3.2 Moving the Cursor with the Numeric Keypad and Selecting a Range

The operation examples show selection of waypoints 2 to 5 in the waypoint list, but the instructions provided apply to operation within all lists.

#### Procedure

1. Display the list.
2. Use the numeric keypad to enter number "2" and press **ENT** to move the cursor to "2".
3. Press **ENT** to establish the start point.
4. Use the numeric keypad to enter number "5" and press **ENT** to move the cursor to "5" and select the range.
5. Press **ENT** to establish the range.



## 4.9 Entering Comments


- Comments of up to 16 characters can be added to waypoints, events, marks, and routes.
- Characters are assigned to the numeric keypad, and can be entered by pressing the keypad keys.
- If the display language is set to Japanese, katakana entry can be performed.
- The characters assigned to the numeric keypad can be displayed onscreen.

### 4.9.1 Text Entry


- The entry example will show how to input "Tokyo" on the waypoint entry screen.
- Katakana is only available when the display language is set to Japanese.

#### Procedure

- Please refer to "4.4.2 Registering Waypoints" and display the waypoint registration screen.
- Press  "COMMENT" to enter comment entry mode.



- Press  to set "MODE" to "ABC".  
Press   to change modes as follows: Numbers → Alphabet → Symbols.
- The "T" in "Tokyo" is assigned to numeric keypad number 8, so press  .  
The characters assigned to the numeric keypad are printed on the key tops.
- Press  until a "T" is displayed at the cursor position in the comment field.  
All characters assigned to numeric keypad key 8 are displayed onscreen.  
Press  to select the next letter.



6. The "o" in "Tokyo" is assigned to numeric keypad number 6, so press  .  
Press  until an "o" is displayed at the cursor position in the comment field.
7. The "k" in "Tokyo" is assigned to numeric keypad number 5, so press  .  
Press  until a "k" is displayed at the cursor position in the comment field.
8. The "y" in "Tokyo" is assigned to numeric keypad number 9, so press  .  
Press  until an "o" is displayed at the cursor position in the comment field.
9. The "o" in "Tokyo" is assigned to numeric keypad number 6, so press  .  
Press  until an "o" is displayed at the cursor position in the comment field.
10. Press  .

List of Characters Assigned to Numeric Keypad for Each Mode

Numeric Keypad	MODE	123	ABC	@\&
	Number	Alphabet	Symbol	
1	1	1+-*/() %	1+-*/() % space	
2	2	2ABCabc	2 ▲▼◀▶□■ →←	
3	3	3DEFdef	3 I II III IV V VI <b>123</b>	
4	4	4GHIghi	4 ; <=> {} ± 「」、。[] ·	
5	5	5JKLjkl	5#@＼& ?,. ' " _ : !	
6	6	6MNOmno	6	
7	7	7PQRSpqrs	7	
8	8	8TUVtuv	8	
9	9	9WXYZwxyz	9	
0	0	0#@＼& ?,. ' " _ : !	0	


## 4.9.2 Deleting Text

- Letters and characters in comments can be deleted.

### Procedure

- Use to move the cursor to the letter or character which you wish to delete.
- Press .

ENTRY WPT 16:35:55 U1	
1. WPT No.	: 00007
2. SYMBOL	: ○
3. COMMENT	: Tokyo
4. POSITION	: OWN SHIP
5. WPT LAT	: 35° 25. 4240' N
6. WPT LON	: 139° 43. 1170' E
MODE : 123	
▼ MODE CHANGE	
W84	BD



ENTRY WPT 16:37:19 U1	
1. WPT No.	: 00007
2. SYMBOL	: ○
3. COMMENT	: Toky
4. POSITION	: OWN SHIP
5. WPT LAT	: 35° 25. 4240' N
6. WPT LON	: 139° 43. 1170' E
MODE : 123	
▼ MODE CHANGE	
W84	BD

Move the cursor to the "r" position

The "r" is deleted

## 4.9.3 Adding Text

- Letters and characters can be added to comments.

### Procedure

- Move the cursor to the position where you wish to insert a letter or character.
- Refer to "4.9.1 Text Entry", and enter the desired letter(s) or character(s).


To add "y"

Move cursor to position where you  
wish to make an addition

"y" is displayed

ENTRY WPT 16:51:37 U1	
1. WPT No.	: 00007
2. SYMBOL	: ○
3. COMMENT	: Toko
4. POSITION	: OWN SHIP
5. WPT LAT	: 35° 25. 4240' N
6. WPT LON	: 139° 43. 1170' E
MODE : ABC	
▼ MODE CHANGE	
W84	BD

Press 9  
Select "y"



ENTRY WPT 16:52:10 U1	
1. WPT No.	: 00007
2. SYMBOL	: ○
3. COMMENT	: Tokyo
4. POSITION	: OWN SHIP
5. WPT LAT	: 35° 25. 4240' N
6. WPT LON	: 139° 43. 1170' E
MODE : ABC	
▼ MODE CHANGE	
9WXYZwxyz	
W84	BD

Set MODE to "ABC"

#### 4.9.4 Displaying Characters Assigned to the Numeric Keypad


- Characters assigned to numeric keypad keys can be displayed on screen.
- The characters are displayed onscreen in the same positions as they are on the numeric keypad, allowing you to match their positions.

##### Procedure

- Press **MENU**, **1 MARK**, and then **7 CURS** to select "INPUT ASSIST".
- Press **▲** **▼** to select "ON", and then press **ENT**.


When input assistance is turned "ON", the following is displayed onscreen during comment entry in accordance with the MODE.

To hide this display, turn input assistance "OFF".



## 4.10 MOB

- The MOB (Man Overboard) function is used to save the position at which a person or object has fallen overboard. This allows rapid return to that location.
- The MOB function is valid on all screens.
- When MOB is performed, the plot screen is automatically displayed, a MOB mark is displayed at the point where the man overboard occurred, and the distance and direction from the current position to the man overboard position is displayed.



### Procedure

- Press **MOB**.

A 5 second countdown will start at the bottom right of the screen. If **MOB** is pressed again within 5 seconds, the MOB function will be cancelled.

To stop the MOB function, press and hold **MOB** for 3 or more seconds.

### Memo

- The following are not available during MOB.  
Waypoint registration, route creation, navigation start, navigation stop, waypoint copy, route copy, waypoint deletion, route deletion, event/mark deletion, data route sharing, active route sharing
- The route number displayed during MOB operation is 103.
- MOB is registered as number 0 in the event/mark list.

## 4.11 Alarm Settings

9 types of alarms can be configured. The can be individually turned off or on, and the alarm sounds can be set individually.

The following alarms can be configured.

- (1) SYSTEM: An alarm sounds when positioning is stopped. This cannot be set to Off.
- (2) ARRIVAL/ANCHOR: An alarm sounds when own ship reaches or leaves the arrival circle.  
Alarms cannot be set for both arrival and departure.
- (3) XTD/BOUNDARY: An alarm sounds when own ship leaves or enters the route.  
Alarms cannot be set for both leaving and entering.
- (4) DGPS: An alarm sounds when switching from GPS positioning to DGPS positioning, or from DGPS positioning to GPS positioning.
- (5) HDOP: An alarm sounds when the GPS positioning HDOP value exceeds the set value.
- (6) TEMP: An alarm sounds when the water temperature matches the set parameters.
- (7) DPTH: An alarm sounds when the water depth matches the set parameters.
- (8) TRIP: An alarm sounds when the trip exceeds the set value.
- (9) SPEED: An alarm sounds when the speed matches the set parameters.

Externally connected equipment is needed for water temperature or depth alarms to function.

When an alarm occurs, the alarm will sound, and a blinking icon will be displayed on the status bar.

The alarm sound can be pressed by **CLR**, but the icon will continue appearing until the alarm has been resolved.

If you do not want an alarm to sound, set it to "OFF".

### 4.11.1 Setting Alarms

Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

#### Procedure

1. Press **MENU**, and then **4 #** to display the alarm screen.

MALAR		16:03:11 U1
1. ARRIVAL/ANCHOR	: ARV	♪
2. XTD/BOUNDARY	: XTD	♪
3. DGPS	: ON-OFF	♪
4. HDOP	: 4	♪
5. TEMP	: +20°C OR OVER	♪
6. DPTH	: 20m OR UNDER	♪
7. TRIP	: 40.0NM OR OVER	♪
8. SPD	: WITHIN 5.0-15.0kn	♪
0. ALARM SOUND SET		
W84		BD

♪: Alarm sound set


2. Select the alarm you wish to set.

## (1) ARRIVAL/ANCHOR

3. Press  **1 MARK** "ARRIVAL/ANCHOR".
4. Press  to select "ARV", "ANC", or "OFF", and press .

An alarm will sound when own ship enters or exits the arrival circle set for the course. If no arrival circle is set, then an alarm will sound when own ship enters or exits the default course value arrival circle radius.

Alarms cannot be set for both "ARRIVAL" and "ANCHOR".




## (2) XTD/BOUNDARY

5. Press  **2 EVENT** "XTD/BOUNDARY".
6. Press  to select "XTD", "BOUNDARY", or "OFF", and press .

If the ship leaves or enters the set route, the alarm will sound. If no route is set, then an alarm will sound when the ship enters or exits the default route width.

Alarms cannot be set for both "XTD" and "BOUNDARY".



### (3) DGPS

7. Press "DGPS".
8. Press to select "OFF" or the alarm trigger state, and press .

ON → OFF: An alarm will sound when DGPS positioning switches to GPS positioning.  
OFF → ON: An alarm will sound when GPS positioning switches to DGPS positioning.  
ON ↔ OFF An alarm will sound when DGPS positioning switches to GPS positioning, or when GPS positioning switches to DGPS positioning.

### (4) HDOP

9. Press "HDOP".
10. Press to select "OFF" or "SET", and press .
11. Enter the HDOP value with the numeric keypad, and press .

An alarm sounds when the GPS positioning HDOP value exceeds the set value.

### (5) TEMP

12. Press "TEMP".
  13. Press to select "OFF" or "RANGE", and press .
  14. Enter the water temperature with the numeric keypad, and press .
- OVER: An alarm will sound when the water temperature exceeds the set value.  
UNDER: An alarm will sound when the water temperature falls below the set value.  
IN RANGE: An alarm will sound when the water temperature is within the set range.  
OUT RANGE: An alarm will sound when the water temperature is outside the set range.  
Water temperature data must be obtained from externally connected equipment for the water temperature alarm to be used.

### (6) DEPTH

15. Press "DEPTH".
  16. Press to select "OFF" or "RANGE", and press .
  17. Enter the water depth with the numeric keypad, and press .
- OVER: An alarm will sound when the water depth exceeds the set value.  
UNDER: An alarm will sound when the water depth falls below the set value.  
IN RANGE: An alarm will sound when the water depth is within the set range.  
OUT RANGE: An alarm will sound when the water depth is outside the set range.  
Water depth data must be obtained from externally connected equipment for the water depth alarm to be used.

### (7) TRIP

18. Press "TRIP".
  19. Press to select "OFF" or "SET", and press .
  20. Use the numeric keypad to enter the trip distance, and press .
- An alarm will sound if the set trip distance value is exceeded. The trip distance is calculated using the total distance over ground from Navigation Assistance 1 screen.

## (8) SPD

21. Press "SPD".
22. Press to select "OFF" or "RANGE", and press .
23. Enter the speed with the numeric keypad, and press .

OVER: An alarm will sound when the speed exceeds the set value.

UNDER: An alarm will sound when the speed falls below the set value.

IN RANGE: An alarm will sound when the speed is within the set range.

OUT RANGE: An alarm will sound when the speed is outside the set range.

### 4.11.2 Setting Alarm Sounds

- Individual alarm sounds can be set for each item.
- If the alarm is set to "OFF" in the alarm settings, the alarm sound cannot be set, but even if the alarm is set to "ON", the alarm sound itself can be set to "OFF". In that case, when the alarm occurs, no alarm sound will play, but a blinking alarm icon will appear.
- When an alarm sound is set, the "♪" icon will appear on the alarm screen.
- You can preview the alarm sound when setting it.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

#### Procedure

1. Press , , and then to display the alarm sound screen.

Only items whose alarms have been set will be displayed.

MALARM SOUNDS		16:04:17 U①
1. SYSTEM	:	ALARM2
2. ARRIVAL/ANCHOR	:	ALARM1
3. XTD/BOUNDARY	:	ALARM1
4. DGPS	:	ALARM6
5. HDOP	:	ALARM2
6. TEMP	:	ALARM3
7. DPTH	:	ALARM3
8. TRIP	:	ALARM3
9. SPEED	:	ALARM3

2. Select the alarm you wish to set with the numeric keypad.

3. Press to select the alarm sound, and then press .

The following will be displayed. Press to hear the alarm sound.

Press again to stop the alarm sound.

Play alarm sound with

MALARM SOUNDS		16:05:24 U①
1. SYSTEM	:	ALARM2
2. ARRIVAL/ANCHOR	:	ALARM1
3. XTD/BOUNDARY	:	ALARM2
4. DGPS	:	ALARM3
5. HDOP	:	ALARM2
6. TEMP	:	ALARM3
7. DPTH	:	ALARM3
8. TRIP	:	ALARM3
9. SPEED	:	ALARM3

## 4.12 Navigation Assistance

### 4.12.1 Measuring the Trip Distance and Time During Navigation (Navigation Assistance 1)

- Navigation Assistance 1 shows the time when measurement started, the time measurement ended, the total time, and the total distance over ground. If the speed through water is input from external equipment, the distance through water is also displayed.
- When measurement is started, the time that measurement was started is displayed, and the total time and total distance will gradually increase.
- When measurement is stopped, the time that measurement was stopped is displayed, as well as the total time and total distance.
- To start measurement, start navigation, or start measurement from the Navigation Assistance 1 screen.
- Stop measurement from the Navigation Assistance 1 screen.
- Measurement does not stop even if navigation is stopped. This allows total time and distance to be measured even when routes are changed during navigation.

ASSIST 25 NOV, '09 17:10:37 U1
NAV START/END RUNNING
35° 52. 0029' N 139° 35. 9754' E
SOG 10. 1kn COG 231. 9°
START 25 NOV, '09 15:57:23
END . . . . . . . . . .
TIME 0 DAY 1 hr 13 min
TRIP1 00013. 1NM
TRIP2 00012. 7NM

W84 WPT AUTO BG

Navigation Assistance 1 Screen  
(Refer to "3.1.9 Navigation Assistance Screen" for screen details)

#### Procedure

##### (1) Starting Measurement

1. Press  several times to display the Navigation Assistance screen.
2. Press   several times to display the Navigation Assistance 1 screen.
3. The cursor will move to "NAV START/END", so press .

##### (2) Ending Measurement

1. Press  several times to display the Navigation Assistance screen.
2. Press   several times to display the Navigation Assistance 1 screen.
3. The cursor will move to "NAV START/END", so press .

#### Memo

- Measurement starts automatically when navigation is started.
- In order to perform distance through water, speed through water must be input from externally connected equipment.

## 4.12.2 Measuring the Trip Distance and Time (Navigation Assistance 2)

- Navigation Assistance 2 shows the time when measurement started, the time measurement ended, the total time, the average speed during measurement, and the distance over ground. If the speed through water is input from external equipment, the speed through water is also displayed.
- When measurement is started, the time that measurement was started is displayed, and the total time, the average speed and total distance will gradually increase.
- When measurement is stopped, the time that measurement was stopped is displayed, as well as the total time and distance.
- To start measurement, start measurement from the Navigation Assistance 2 screen.
- Stop measurement from the Navigation Assistance 2 screen.

ASSIST 25 NOV, '09 17:07:25 U1
SOG NAV START/END
START 25 NOV, '09 16:04
END 25 NOV, '09 17:05
TIME 0 DAY 1 hr 1 min
AVG SPD10. 4kkn TRIP00010. 7NM
STW NAV START/END
START 25 NOV, '09 15:57
END 25 NOV, '09 17:05
TIME 0 DAY 1 hr 8 min
AVG SPD10. 1knn TRIP00011. 5NM
W84
MPT AUTO
3G

Navigation Assistance 2 Screen  
(Refer to "3.1.9 Navigation Assistance Screen" for screen details)

### Procedure

#### (1) Starting Measurement

1. Press  several times to display the Navigation Assistance screen.
2. Press   several times to display the Navigation Assistance 2 screen.
3. The cursor will move to the "SOG NAV START/END", so press  to start measurement of distance over ground.
4. Pressing  will cause the cursor to move to "STW NAV START/END", so press  to start measurement of distance through water.

#### (2) Ending Measurement


1. Press  several times to display the Navigation Assistance screen.
2. Press   several times to display the Navigation Assistance 2 screen.
3. The cursor will move to "SOG NAV START/END", so press  to end measurement of distance over ground.
4. Pressing  will cause the cursor to move to "STW NAV START/END", so press  to end measurement of distance through water.

### Memo

- In order to perform distance through water, speed through water must be input from externally connected equipment.

### 4.12.3 Measuring the Distance and Bearing Between 2 Points (Navigation Assistance 4)

- Navigation Assistance 4 allows you to specify a start point and an end point, and calculate the distance and bearing between the two points.
- The start and end points can be selected from the following 5 items.
  - (1) Own ship's position
  - (2) Specified latitude and longitude
  - (3) Cursor position
  - (4) Waypoint list:
  - (5) Event/mark list



Navigation Assistance 4 Screen  
(Refer to "3.1.9 Navigation Assistance Screen" for screen details)

#### Procedure

1. Press several times to display the Navigation Assistance screen.
2. Press several times to display the Navigation Assistance 4 screen.
3. The cursor will move to "STARTING POINT", so press .
4. Press to select the start point selection method, and press
  - (1) If you select "OWN SHIP", the latitude and longitude of your ship position will be displayed.
  - (2) If you select "LAT/LON", the cursor will move to the latitude and longitude position, so please enter your desired latitude and longitude values.
  - (3) If you select "CURSOR", the plot screen will be displayed, so move the cursor to select the desired position.
  - (4) If you select "WPT LIST", the waypoint list will be displayed, so move the cursor to select the desired waypoint.
  - (5) If you select "EVENT LIST", the event/mark list will be displayed, so move the cursor to select the desired event/mark.
5. The cursor will move to "TERMINAL POINT", so press .
6. Press to select the end point selection method, and press .  
Select the end point using the same procedures provided for selecting start points.
7. The cursor will move to "SAIL GC/RL", so press .
8. Press to select the distance measurement method, and press .  
For distance calculation, select RL for "RHUMB LINE" measurement, and GC for "GREAT CIRCLE" measurement.
9. The distance and bearing between the specified start and end points will be displayed.  
When GC is selected as the distance measurement method, bearing is not displayed.

## 4.13 Beacon Information

When the beacon information is set to "ON" based on "4.16.8 Setting Beacon/SBAS", the beacon information (Type 16 message) from the beacon broadcast stations can be displayed. Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

## **Procedure**

1. Press  ,  , and then  .
  2. Press  "BEACON INFORMATION", press   to select "ON", and press  .
  3. Press  several times to display the beacon information screen.

BEACON INFO	18:41:12 U
25 NOV, '09 19:35 1925, izuoshima, Om, , . . . . .	
25 NOV, '09 19:30 1925, irosaki, NE, 5m, 1017hPa, , . . . . .	
25 NOV, '09 19:30 1925, omaesaki, WNW, 9m, , . . . . .	
25 NOV, '09 19:10 1855, sunosaki, ENE, 9m, , . . . . .	
25 NOV, '09 19:10 1855, tsurusasaki, N, 6m, , . . . . .	
W84	BD

## Memo

- The beacon information is not limited to information obtained from every beacon broadcast station.

## 4.14 Display Settings

If "1.DISPLAY" is selected on the main menu, the display menu will be displayed. On the display menu, you can set the contrast, dimmer, click sound, reversed display, input assistance, and screen display.

DISPLAY		15:57:32 U1
1. CONTRAST	:	7
2. DIMMER	-MAXIMUM-	9
3.	-TYPICAL-	6
4.	-MINIMUM-	4
5. CLICK SOUND	:	ON
6. REVERSING MODE	:	NORMAL
7. INPUT ASSIST	:	ON
8. DISPLAY SELECT	:	NAV

The following is an overview of each submenu.

- The following is an overview of each submenu:

  - (1) CONTRAST: You can set the LCD contrast.
  - (2) DIMMER: You can set the LCD's brightness levels.
  - (3) CLICK SOUND: You can turn the click sound when keys are pressed on or off.
  - (4) REVERSING MODE: You can switch the display's black/white setting.
  - (5) INPUT ASSIST: You can turn screen display of the characters assigned to the numeric keypad on or off.
  - (6) DISPLAY SELECT: You can set which screen is displayed, and which screen is shown on startup.

### 4.14.1 Adjusting Contrast

- You can set the LCD contrast.
  - Contrast value 1 is the highest amount of contrast, while 13 is the least amount of contrast.
  - The default value is 7.

## **Procedure**

1. Press  ,  , and then  to select "CONTRAST".
  2. Press   to adjust the contrast, and press  .

#### 4.14.2 Adjusting Brightness

- Brightness adjustment can be performed by pressing  to select bright, medium, dark, or off.  
Here, you can set the levels for each brightness level.

## **Procedure**

1. Press **MENU**, **1 MARK**, and then **2 EVENT** and select "DIMMER".
  2. Press **▲** **▼** to increase or decrease the value by one. The screen brightness will change at the same time.
  3. Press **ENT**. (Medium and Dark can be adjusted the same way.)

### Memo

- Set the highest value for "Bright", and the smallest value for "Dark".
- The key brightness setting changes in accordance with the dimmer setting.

### 4.14.3 Setting the Click Sound

- You can turn the key operation click sound on or off.

ON: The click sound is enabled

OFF: The click sound is disabled

### Procedure

1. Press **MENU**, **1 MARK**, and then **5 GOTO** to select "CLICK SOUND".
2. Press **▲** **▼** to select "ON" or "OFF" and press **ENT**.

### 4.14.4 Setting Reversed Display

- The black/white display can be reversed.


NORMAL: The letters are black. (The background is white)

REVERSE1: The letters are white. (The background is black)

REVERSE2: The letters are white, and the letters on the status bar are black.

### Procedure

1. Press **MENU**, **1 MARK**, and then **6** to select "REVERSING MODE".
2. Select the reversal mode with **▲** **▼**, and press **ENT**.



Normal



Reverse1



Reverse2

#### 4.14.5 Input Assistance Settings

- Input assistance display can be turned on or off.  
ON: Input assistance display enabled  
OFF: Input assistance display disabled

##### Procedure

1. Press **MENU**, **1 MARK**, and then **7 CURS** to select "INPUT ASSIST".
2. Press **▲** **▼** to select "ON" or "OFF", and press **ENT**.

#### 4.14.6 Selecting the Display Screen

- You can select which screen is displayed.
- Set screens which you wish to display to "ON", and screens which you do not wish to display to "OFF".
- You can set the navigation information , PLOT1, PLOT2, PLOT3, CDI, or GPS information screens to be displayed when the unit is started. Set the screen you wish to display on startup to "START".
- Only one screen can be set to "START". To change the "START" screen, change the value of the currently set "START" screen to something other than "START" before setting the new "START" screen.

DISPLAY SELECT 16:19:44 U1	
1. NAV	: START
2. PLOT1	: ON
3. PLOT2	: ON
4. PLOT3	: ON
5. CDI	: ON
6. GPS INFO	: ON
7. WPT INFO	: ON
8. BEACON INFO	: ON
9. NAV ASSIST	: ON
W84	
③D	

##### Procedure

1. Press **MENU**, **1 MARK**, and then **8 AZI** to select "DISPLAY SELECT".
2. Enter the number of the screen you wish to set with the numeric keypad.
4. Press **▲** **▼** to select "START", "OFF", or "ON", and press **ENT**.

## 4.15 System Settings

- Select "5. SYSTEM" on the main menu to display the system settings screen.

SYSTEM 25 NOV, '09 17:24:02 U1	
1. TIME DIFF	: +00:00
2. DATE DISP	: DD MM, 'YY
3. TIME DISP	: 24hr
4. DATUM	: WGS-84
5. UNIT-DIST/SPEED	: NM, kn
6. HEIGHT/DEPTH	: m
7. TEMPERATURE	: °C
8. MAG CORR	: OFF
9. SPEED METER	: 50kn
W84	
BD	

The following is an overview of each submenu.

- (1) TIME DIFF: To display the time at the current location, enter the difference between the local time and UTC.
- (2) DATE DISP: Select "YY-MM-DD", "DD MM, 'YY", or "MM DD, 'YY".
- (3) TIME DISP: You can select 24 hour or 12 hour display.
- (4) DATUM: You can select a geodetic system from the list in "Appendix 1 Geodetic Systems".
- (5) UNIT - DIST/SPEED: You can choose units of "NM, kn", "km, km/h", or "mi, mi/h".
- (6) UNIT - HEIGHT/DEPTH: You can select m, ft, or fm.
- (7) UNIT - TEMPERATURE: You can select °C or °F.
- (8) MAG CORR: You can select automatic or manual magnetic correction, or turn magnetic correction off.
- (9) SPEED Meter: You can set the maximum value of the analogue speed meter on the CDI screen.

### 4.15.1 Setting the Time Difference

- You can set the time difference between your current location and UTC.  
An YY denotes a year, an MM denotes a month, and a DD denotes a day.
- For Japan, the time difference is +9 hours, so you would input +09:00.
- When a time difference is set, the local time will be displayed (shown with an "L").
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

#### Procedure

1. Press **MENU**, **5 GOTO**, and then **1 MARK** to select "TIME DIFF".
2. Select + or - with **▲** **▼**, enter the time with the numeric keypad, and press **ENT**.

### 4.15.2 Setting the Date Display

- You can set the date display format to "YY-MM-DD", "DD MM, 'YY", or "MM DD, 'YY".
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

#### Procedure

1. Press **MENU**, **5 GOTO**, and then **2 EVENT** to select "DATE DISP".
2. Select the display format with **▲** **▼**, and press **ENT**.

### 4.15.3 Setting the Time Display

- You can select 24 hour or 12 hour time display.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

#### Procedure

1. Press **MENU**, **5 GOTO**, and then **3 ↺** to select "TIME DISP".
2. Select the display format with **▲** **▼**, and press **ENT**.

### 4.15.4 Setting the Geodetic System

- You can select the geodetic system to use.
- You can choose between 46 types of geodetic systems. Please refer to "Appendix 1 Geodetic Systems" for details.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

#### Procedure

1. Press **MENU**, **5 GOTO**, and then **4 #** to select "DATUM".
2. Select the geodetic system with **▲** **▼**, and press **ENT**.

### 4.15.5 Setting Distance and Speed Units

You can select "NM, kn", "km, km/h", or "mi, mi/h" for distance and speed units. Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

#### Procedure


1. Press **MENU**, **5 GOTO**, and then **5 GOTO** to select "UNIT - DIST/SPEED".
2. Select the units with **▲** **▼**, and press **ENT**.

### 4.15.6 Setting Height and Depth Units

- You can select m, ft, or fm for height and depth units.
- If you select fm, enter the conversion value from "m". The default value is 1 fm = 1.8288 m.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

#### Procedure

1. Press **MENU**, **5 GOTO**, and then **6 ↺** to select "HEIGHT/DEPTH".
2. Select the units with **▲** **▼**, and press **ENT**.  
If you select fm, you must enter the conversion value from "m".
3. Press **▲** **▼** to select "SET", enter the conversion value with the numeric keypad, and press **ENT**.



To keep the default value, or restore the unit to the default value, select "DEFAULT".

#### 4.15.7 Setting Temperature Units

- You can set the temperature unit to °C or °F.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

##### Procedure

1. Press **MENU**, **GOTO**, and then **CURS** to select "TEMPERATURE".
2. Select the units with **▲** **▼**, and press **ENT**.

#### 4.15.8 Setting Magnetic Correction


- You can set the method of magnetic correction to be automatic or manual, or turn magnetic correction off.
- If you select automatic, correction is automatically calculated for the correction value from the GPS position.
- If you select manual, correction is performed using a manually entered value.
- If you turn magnetic correction off, no correction is performed.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

##### Procedure

1. Press **MENU**, **GOTO**, and then **AZI** to select "MAG CORR".
2. Select the correction method with **▲** **▼**, and press **ENT**.  
When Manual is selected
3. Select E/W using **▲** **▼**, enter the correction value with the numeric keypad, and press **ENT**.

#### 4.15.9 Setting the Maximum Analogue Speed Meter Value

- You can set the maximum value of the CDI screen analogue speed meter.
- Set the value to one appropriate for the ship in which the unit is installed. The maximum value is 100 kn.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.



##### Procedure

1. Press **MENU**, **5 GOTO**, and then **9 HOME** to select "SPEED METER".
2. Enter the speed with the numeric keypad, and press **ENT**.

## 4.16 GPS/Beacon/SBAS Settings

- Select "6. GPS/BEACON/SBAS" on the main menu to display the GPS/beacon/SBAS settings screen.

The items which can be set will vary depending on the connected sensor.

GPS/BEACON/SBAS	
1. GPS MODE	: AUTO
2. FIX MODE	: AUTO
3. SAT ELV MASK	: 5°
4. HDOP	: 4
5. SMOOTHING POSITION	: 10sec SPEED : 4sec COURSE : 4sec
6. RAIM ACCURACY LEVEL	: 100m
7. GPS INITIALIZATION	
8. BEACON/SBAS	
9. LORAN	

W84

③ \$b

The following is an overview of each submenu.

- (1) GPS MODE: You can select AUTO (JLR-7800 only), GPS Alone, Beacon, or SBAS.
- (2) FIX MODE: You can select AUTO, 3D, or 2D.
- (3) SAT ELV MASK: You can limit which satellite(s) you use based on the angle.
- (4) HDOP: You can set the measured HDOP.
- (5) SMOOTHING - POSITION: You can set position smoothing.
- (6) SMOOTHING - SPEED: You can set speed smoothing.
- (7) SMOOTHING - COURSE: You can set course smoothing.
- (8) RAIM ACCURACY LEVEL: You can set the RAIM accuracy level used.
- (9) GPS INITIALIZATION: You can perform sensor initialization.
- (10) BEACON/SBAS: You can perform beacon and SBAS settings.
- (11) LORAN: You can display a position based on the time difference (Loran A/C).

### Memo

- RAIM

Abbreviation of Receiver Autonomous Integrity Monitoring. This system automatically detects failed satellites and deselects their positioning data from calculations. Including data from failed satellites will result in a decrease in positioning accuracy; the RAIM accuracy standard indicates the accuracy degradation base for removal of failed satellites from positioning calculations.

### 4.16.1 Setting the GPS Mode

- You can set the GPS mode to AUTO, GPS alone, beacon, or SBAS.
- The sensor must support SBAS to use SBAS positioning mode.

The selections are as follows:

- (1) AUTO: The best method is selected from GPS alone, SBAS, and beacon.
- (2) GPS Alone: Positioning is performed using only the GPS. SBAS positioning and beacon-based DGPS positioning is not performed.
- (3) BEACON: Beacon based DGPS or GPS only positioning is performed. SBAS positioning is not performed.
- (4) SBAS: SBAS or GPS only positioning is performed. Beacon-based DGPS positioning is not performed.

- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

### Procedure

1. Press  ,  , and then  to select "GPS MODE".
2. Select the GPS mode with  , and press .

## 4.16.2 Setting the Fixing Mode

- You can set Fix mode to AUTO, 3D, or 2D.
- The selections are as follows:
  - (1) AUTO: Positioning mode is automatically switched between 3D and 2D, with the optimal method being used.
  - (2) 3D: 3D positioning is performed.
  - (3) 2D: 2D positioning is performed.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

### Procedure

1. Press  ,  , and then  to select "FIX MODE".
2. Select the positioning mode with   , and press .

## 4.16.3 Setting the Elevation Mask

- If the elevation mask is set, satellites at an elevation lower than the set value will not be used in positioning.
- The elevation mask can be set between 5 and 89 degrees.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

### Procedure

1. Press  ,  , and then  to select "SAT ELV MASK".
2. Use the numeric keypad to enter the elevation mask, and press .

## 4.16.4 Setting HDOP

- If HDOP is set, positioning is only performed if HDOP is lower than the set value.
- HDOP can be set to 4, 10, or 20.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

### Procedure

1. Press  ,  , and then  to select "HDOP".
2. Press   to select the HDOP value, and then press .

## 4.16.5 Setting Position, Speed, and Course Smoothing

- Smoothing can be applied to measured positions, speeds, and courses.
- The higher the smoothing value, the smoother the results will be, but the greater the time lag. Conversely, if the smoothing value is set low, a great number of changes will occur, but there will be little time lag. As such, it is important to choose the optimal value for your own usage situation.
- Smoothing values can be set between 0 and 99 seconds.
- Smoothing can be set individually for position, speed, and course on the JLR-4341.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

### Procedure

1. Press  ,  , and then  to select "SMOOTHING".

#### (1) When Position, Speed, and Course can be Individually Set

2. Press   to select position, speed, or course, and then press  .
3. Use the numeric keypad to enter the smoothing value, and press  .

#### (2) When Position, Speed, and Course can not be Individually Set

2. Use the numeric keypad to enter the smoothing value, and press  .

### Attention

- Setting a high smoothing level to position and speed, can cause the receiver to react slowly to fast turns and sudden speed changes.  
A setting of less than 10 seconds is recommended for normal circumstances, default is 10 seconds. Higher settings must be used in caution.

## 4.16.6 Setting RAIM


- Receiver autonomous integrity monitoring (RAIM) is an integrity monitoring which determine if GPS accuracy is within the performance standards to provide an integrity indication. The integrity indications with a confidence level above 95% for different position accuracy levels are expressed in two states: "safe" and "unsafe".  
In the case of the confidence level under 95%, the indication is expressed "caution".
  - Safe: position error is within the selected accuracy level.
  - Caution: insufficient information to reliably calculate for the selected accuracy level.  
the probability of false alarms is large or the probability of not detecting an error condition is large.
  - Unsafe: position error exceeds the selected accuracy level.
- You can set the RAIM accuracy level.
- You can choose "OFF", "10m", "30m", "50m", or "100m" as accuracy levels.  
Set to 30 m or greater when GPS positioning is used alone. If GPS-only positioning is used with a setting of 10 m, then the 95% reliability condition will not be met, and a "CAUTION" may occur.
- If you choose accuracy level "OFF", "RAIM OFF" displays on the screen and the RAIM function will turn off. During "OFF" status, no calculations as to the integrity status of satellites are made.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

## Procedure

1. Press **MENU**, **6**, and then **6** to select "RAIM ACCURACY LEVEL".
2. Press **▲** **▼** to select the accuracy level value, and then press **ENT**.

### 4.16.7 Initializing the GPS

- GPS initialization can be performed.



- The submenus on the GPS initialization screen are as described below.
  - (1) LATITUDE: Enter the approximate ship latitude.
  - (2) LONGITUDE: Enter the approximate ship longitude.
  - (3) ANT HEIGHT: Enter the height above the draft line of the sensor. This height is used in 2D positioning. It is not used in 3D positioning.
  - (4) DATE: Enter the current date in UTC.
  - (5) TIME: Enter the current time in UTC.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.


## Procedure

1. Press **MENU**, **6**, and then **7 CURS** to display the GPS initialization screen.
2. Select the item you wish to set with the numeric keypad, enter each value using the numeric keypad, and press **ENT**.
3. Press **0 \*** "SET".

## 4.16.8 Setting Beacon/SBAS

Beacon and SBAS settings can be performed.

The sensor must support SBAS to perform SBAS settings.



- The submenus on the beacon/SBAS settings screen are as follow.

- (1) STATION SELECT: Set the beacon station selection method.
  - AUTO: The best beacon station is selected automatically from the GPS position.
  - MANUAL: You can set the frequency and bit rate manually.
- (2) FREQUENCY: Set the frequency when station selection is set to manual.
- (3) BIT RATE: Set the bit rate when station selection is set to manual.
- (4) BEACON INFORMATION: Set to "ON" to display received beacon information.
- (5) SBAS SEARCH: The SBAS satellite can be set.
  - AUTO: The SBAS satellite is automatically set.
  - MANUAL: The SBAS satellite number is set manually.
- (6) TYPE O INFORMATION: Set whether test broadcast data is used.
  - ON: Used.
  - OFF: Not used. (default)
- (7) RANGING: You can set whether SBAS satellite information are used like GPS satellites in positioning.
  - ON: Used.
  - OFF: Not used. (default)

- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

### Procedure

- Press **MENU**, **6**, and then **8 AZI** to display the Beacon/SBAS setting screen.

#### (1) Setting Beacon station

- Press **1 MARK** "STATION SELECT".
- Press **2 EVENT** "FREQUENCY".

If set to Manual, "2. FREQUENCY" and "3. BIT RATE" can be selected.

Press **3** "BIT RATE".

Enter the frequency with the numeric keypad, and press **ENT**.

Press **4** "BIT RATE".

Press **5** to select the bit rate, and press **ENT**.

#### (2) Setting Beacon Information

Refer to "4.13 Beacon Information".

### (3) Setting SBAS Satellites

4. Press  "SBAS SEARCH".
5. Press   to select the search method, and press  .  
If set to Manual, the SBAS satellite number can be selected.  
Press   to select the SBAS satellite number, and press  .

### (4) Setting Type 0 Information

6. Press  "TYPE 0 INFORMATION".
7. Press   to select "ON" or "OFF" and press  .

### (5) Setting Ranging

8. Press  "RANGING".
9. Press   to select "ON" or "OFF", and press  .

#### 4.16.9 Setting LORAN A/C

- Position displays and settings can be performed based on time differences.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

##### Procedure

- Press  ,  , and then  to display the LORAN setting screen.
- Press  "LORAN A/C".
- Press   to set the time difference display, and press .

The time difference display settings are as follow.

- (1) OFF: Latitude and longitude is displayed.
- (2) LORAN A: Switches to the LORAN A setting screen.
- (3) LORAN C: Switches to the LORAN C setting screen.

LORAN		18:10:23 U <small>01</small>
1. LORAN A/C	:	LORAN A
2. STN SELECT	STN1:	1S1
3.	STN2:	1S1
4. TD CORR	TD1	:+0.0μs
	TD2	:+0.0μs

LORAN A

LORAN		18:09:09 U <small>01</small>
1. LORAN A/C	:	LORAN C
2. GRI CHAIN	:	4990
3. TD DATA	TD1	: 0
	TD2	: 0
5. TD CORR	TD1	:+0.0μs
	TD2	:+0.0μs

LORAN C

4. The LORAN A or LORAN C setting screens are displayed.
5. Select the item you wish to set with the numeric keypad.
6. Enter each value with the numeric keypad or   , and press .

##### Memo

- Configurable LORAN A stations:  
1S1 1S2 1S3 1S4 1S6 1L0 1L1 1L4 1L5 2S0 2S1 2S2 2S3 2S4 2S5 2S6 2S7 2H4 2H5  
2H6
- Configurable LORAN C chains:  
4990 5930 5970 5980 5990 6730 6731 6780 7001 7030 7170 7270 7430 7499 7930  
7950 7960 7970 7980 7990 8000 8290 8390 8830 8930 8970 8990 9007 9610 9930  
9940 9960 9970 9980 9990

## 4.17 Version Display

- The GPS sensor and display version number can be displayed.
- The details of each submenu are shown below.
  - (1) SENSOR
    - (1-1) SERIAL No.: The serial number of the GPS sensor is displayed.
    - (1-2) BARCODE: The GPS sensor barcode number is displayed.
    - (1-3) VERSION: The GPS core version number is displayed.
    - (1-4) CONTROLLER: The controller version number is displayed.
  - (2) DISPLAY
    - (2-1) SERIAL No.: The serial number of the display is displayed.
    - (2-2) BARCODE: The display barcode number is displayed.
    - (2-3) VERSION: The display version number is displayed.
    - (2-4) IP: The display IP address is displayed.

### Procedure

1. Press  and then  , select "VERSION".

## 4.18 Language Settings

- Select "8. LANGUAGE" on the main menu to display the language settings screen.
- You can select English or Japanese.
- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.

### Procedure

1. Press  ,  , then  to select "LANGUAGE".
2. Select the language with   , and press .

## 4.19 Print

- When # key is pressed to print, ship information is printed on DPU-414 Printer.
- To print with the # key is DPU-414 printer exclusive use. Please operate the printer when printing on NKG-84 Printer.
- The # key can be used from any screen other than the menu screen, waypoint information screen, or Navigation Assistance 4 screen.
- To print, please switch DATA IN/OUT1 setting to "PRINTER".

### 4.19.1 Ship information is printed when it is necessary

#### Procedure

- Press .
- The following will be displayed. Press to select "YES", and press .

PRINT OUT  
ARE YOU SURE?  
**NO**    **YES**


Ship information is printed.

### 4.19.2 Setting the output interval

- The output interval is set, and it is possible to print regularly.
- You can choose "1 min", "3 min", "5 min", "10 min", "20 min", "30 min", "60 min", "OFF" and "ONCE" as interval time.
- If "OFF" is selected, data is not output. If "ONCE" is selected, data is output one time.

#### Procedure

- Press and hold for 3 seconds.
- Press "INTERVAL".




- Press to select interval time and press .

## 4.20 Equipment Configuration

- In order to change settings or perform installation configuration, you must switch the unit to equipment configuration mode.
- When the unit is in equipment configuration mode, " **M** " will be displayed at the top left of the title bar.

### Procedure

1. Press and hold **0\*** and **MENU** for 3 seconds, and " **M** " will appear at the top left of the title bar, indicating that the unit is now in equipment configuration mode.  
"0. EQUIP SET" will appear on the main menu screen. Press **0\*** to display the equipment configuration menu.



### Memo

- Pressing **CLR** or **◀** on the equipment configuration menu will return to the main menu.
- Equipment configuration mode will end when one of the following occurs:
  - when **MENU** is pressed again on the main menu screen.
  - when the power is turned off
- When making settings, check that the unit is in equipment configuration mode.

#### 4.20.1 Setting the Display Type

- You can set whether the display is the main display connected to the GPS sensor, or a sub-display.
- Set the display connected to the GPS sensor as "MAIN".
- Set the display used as a sub-display as "SUB".

##### Procedure

1. Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
2. Press  **1 MARK** "DISPLAY TYPE".
3. Press   to select "MAIN" or "SUB", and press .

If the unit is set to be the sub-display, " **S1** " will appear at the top right of the title bar.

##### Memo

- Settings cannot be performed for the GPS sensor from the sub-display.

#### 4.20.2 Setting the GPS Sensor Number

- A number can be assigned to each GPS when there is more than one GPS sensor.
- This number is used for IP address management of each display, and for GPS identification when outputting data, so always perform GPS number configuration.
- When only 1 GPS is used, set the number to No1.
- Set a number for each display type, main and sub. Sub-displays are not connected to GPS sensors, but must be set.
- Always set numbers in order starting from No1.


##### Procedure

1. Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
2. Press  **2 EVENT** "SENSOR No.".
3. Enter the number with the numeric keypad, and press .

The number will appear at the top right of the title bar.

### 4.20.3 Setting Sensor Position / CCRP

- You can set the ship size, CCRP position, and GPS sensor position.
- The CCRP position and GPS position are set on a coordinate system with the center of the ship as the point where the axes cross.
- Set the ship size (ship length and width), and set the CCRP position and GPS sensor position.
- The set CCRP position can be output to externally connected equipment. For output, refer to "4.20.7 Data I/O Settings ", and select "CCRP" as the output sentence.
- To output to external equipment, the equipment must have CCRP send / receive functionality.
- CCRP cannot be set from a sub-display. Set CCRP from the main display.



The CCRP position can be received. If the set position and received position differ, the following alert will occur, so please perform the settings again. A "\*" will appear on the status bar until the settings have been redone.



#### Procedure

1. Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
2. Press "CCRP" to display the CCRP settings screen.
3. Press "SHIP".
4. Press to set the value to "ENABLE", and press .
5. Select the ship width and length, enter the values with the numeric keypad, and press .
6. The SENSOR and CCRP x and y values are set in the same way.

#### Memo

- If the sensor position does not fit within the ship, the sensor position will change to "DISABLE". Perform settings again such that the position is within the ship, and change the setting to "ENABLE". The same is true for the CCRP position.

## 4.20.4 Equipment Check

- An equipment check can be performed for the GPS sensor and the display.
  - (1) Input port check
  - (2) Self-diagnosis
  - (3) Error log display and output
  - (4) Setting value output

### 4.20.4.1 Input Port Check

The display has 4 input ports (input from sensor, data IN1, IN4, and LAN).  
The data being received by each port can be displayed.

#### Procedure

1. Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
2. Press  "CHECK".
3. Press   to select "INPUT DATA" and press .
4. Press   "PORT SELECTION".
5. Press   to select the port you wish to display, and press  to confirm the port.
6. Press  to display the input data, and  to stop the data display.


### 4.20.4.2 Performing Self-diagnosis

- Self-diagnosis can be performed for the display, sensor, and LCD display.  
The submenus are outlined below.
  - (1) DISPLAY: Self-diagnosis is performed for the buzzer after completion of self-diagnosis for ROM, RAM, serial ports, and LAN ports.
  - (2) SENSOR: Self-diagnosis is performed for the antenna, ROM, and RAM within the sensor. This function only available on JLR-7800
  - (3) LCD: Self-diagnosis is performed for the LCD display.

#### Procedure

1. Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
2. Press  "CHECK".
3. Press   to select "DIAGNOSIS".
4. Select the diagnosis target with the numeric keypad.
5. Press   to select "START", and then press .

- The diagnosis results will be displayed.



After self-diagnosis has been performed for the screen, the entire screen is highlighted repeatedly such as black to white, white to black. Check if some dots are omitted.

If you wish to stop the operation, press **CLR**.

#### Attention

If the results were not good, contact JRC or its affiliate.

#### 4.20.4.3 Displaying and Outputting Error Logs

- Up to 100 recent errors can be displayed. They can also be output externally.

##### Procedure

- Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
- Press **4 #** "CHECK".
- Press **▲** **▼** to select "ERROR LOG", and then press **ENT**.  
The error log will be displayed.
- If you want to output the log, press **ENT** and set output settings.
- Set the output port and bit rate, and press **0 \*** "SEND" to output the log in text format.

#### 4.20.4.4 Outputting Settings

- Current setting values can be output. This function is for use by service engineer.

##### Procedure

- Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
- Press **4 #** "CHECK".
- Press **▲** **▼** to select "CONFIG OUT", and then press **ENT**.
- Set the output port and bit rate, and press **0 \*** "SEND" to output the log in binary format.

#### 4.20.5 Performing a Master Reset (Reset)

- The GPS sensor, display, or both can be reset.
- Resetting will restore all settings to their default values.
- To reset the display, select "ALL" or "EXCEPT FOR LISTS".  
If "EXCEPT FOR LISTS" is selected, everything except the waypoint list, the route list, and the event / mark list will be reset.  
If "ALL" is selected, the display will be reset, and the waypoint list, route list, and event / mark list will be deleted.

##### Procedure

1. Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
  2. Press  **5 GOTO** "RESET".
  3. Press  to select the equipment to reset, and then press .
- (1) If "SENSOR" is selected, a master reset of the GPS sensor will be performed.  
(2) If "DISPLAY" is selected, the display will be reset. Select "ALL" or "EXCEPT FOR LISTS", and press .
- (3) If "ALL" is selected, a master reset of the GPS sensor will be performed, and the display will also be reset.  
The display lists will also be reset.

#### 4.20.6 Performing a Demo

- The unit can perform a demo, where it behaves as if it is actually functioning, even without GPS reception.
- The following is an overview of the demo type submenu.
  - (1) STATIC: Keeps at set position.
  - (2) STRAIGHT: Goes in set straight line at constant speed.
  - (3) RIGHT: Turns right at set turn radius.
  - (4) LEFT: Turns left at set turn radius.
  - (5) ROUTE: Performs selected route. Moves at set speed from set position to route start point.
  - (6) AUTO: Moves in set direction a set distance from set position.

##### Procedure

1. Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
2. Press  **6**, and then  **1 MARK** to select "DEMO TYPE".
3. Select demo type with , and press .
4. Enter the demo type operation base values with the numeric keypad.
5. Press  and the demo will start.

##### Memo

- To stop the demo, display the demo screen again, and press  **0 \*** "STOP", or turn the power off.
- When the demo is being performed, "S" will blink at the bottom right of the screen.
- When the demo is being performed, "MOB" does not operate.
- After end of demo, the setting performed during in the demo is not available.

## 4.20.7 Data I/O Settings

- You can confirm settings for connection with external connected equipment.
- Data input and output data consists of serial data, contact data, and LAN data.
- Output sentences, bit rate, and output intervals can be set for each port. However, some combinations of bit rates, intervals, and numbers of sentences cannot be made. In this case, set the sentence to the minimum needed value.
- To connect a Current, Temperature and Depth meter, use a input port in DATA IN/OUT4.

- The following is an overview of the serial data.

NMEA:	NMEA format data output.
IEC:	IEC format data output.
JRC:	JRC format data output. Fixed at 1200 bps.
ROUTE:	Output or input of memory route and waypoint data. Route and waypoint data can be sent to / from externally connected computers and equipment.
SWITCH:	Outputs automatic switch (NCZ-1537A) control data.
PRINTER:	Outputs printer formatted data (Data IN/OUT1 only).
EXT EQUIP:	Input configuration for tidal current meter (Data IN/OUT4 only).

- The following is an overview of contact data.

SYSTEM:	A contact is made when the positioning stopped alarm occurs.
SYS+XTD+ARV:	Generates contact when positioning is not performed, when entering or leaving a route, or when arriving at or departing from a waypoint. The XTD / Boundary and Arrival / Anchor alarms are those set in " <a href="#">4.11 Alarm Settings</a> ".
200p/NM:	200 pulse/NM LOG pulse is output.
400p/NM:	400 pulse/NM LOG pulse is output.
ALARM ACK:	Acknowledgment output for externally input alarm.

- The following is an overview of the LAN data.


ACTIVE ROUTE:	The current active route is shared with other equipment.
DATA ROUTE:	Route(s) in memory are shared with other equipment.
DATA OUT:	NMEA and/or IEC data output is performed.
MUTUAL:	Mutual monitoring is performed when two of this unit are connected. When GPS positioning is not being performed, the GPS positioning information from other units can be used.
REMOTE MAINT:	Remote maintenance data output is performed.

#### 4.20.7.1 Configuring Data IN/OUT1

- NMEA, JRC, IEC, route WPT, automatic switch control data, and printer data can be output via data IN/OUT1.
- To connect a DPU-414 printer, use a D-sub9 pin connector.

##### Procedure

- Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
- Press **7 CURS**, and then **1 MARK**, and select "DATA IN/OUT1".
- Select the data type with **▲** **▼** and press **ENT**.



##### (1) When "NMEA" is Selected

Select the version, bit rate, output sentence, and interval.

The screen shows the 'DATA OUT1' configuration menu for NMEA. It lists VERSION (Ver.2.3), BITRATE (4800bps), and SENTENCE (GGA RMC VTG DTM ZDA ACK). The bottom of the screen shows 'W84' and 'BD'.

The screen shows the 'Sentence and Interval Setting Screen' for NMEA. It lists various sentences with their output intervals: GGA (1s), RMC (1s), GLL (1s), VTG (OFF), GSA (GSV), GRS (GRS), DTM (1sec), ZDA (1s), GNS (GNS), GST (2sec), VDR (VHW), APB (4sec), BOD (BWC), BWR (5sec), RMB (XTE), ZTG (6sec), AAM (MTW), and TPG (7sec), TPE (8sec). The bottom of the screen shows 'W84' and 'BD'.

The selected sentence is displayed.  
If no sentence has been selected, no sentence is displayed.

Sentence and Interval Setting Screen

If no sentence is displayed, the output sentence has not been selected.

- Press "SENTENCE".
- Move the cursor to the sentence you wish to output, and press **ENT**.
- The output interval is displayed. Select the interval and press **ENT**.

## (2) When "IEC" is Selected

Select the bit rate, output sentence, and interval.

<b>M</b> DATA OUT1      16:08:28 U <small>1</small> 1. BITRATE : 4800bps 2. SENTENCE  GGA RMC VTG DTM ZDA ACK  W84                    ③D	<b>2</b> EVENT	<b>M</b> DATA OUT1      16:10:26 U <small>1</small> GGA: 1s RMC: 1s GLL: VTG: OFF GSA: GSV: DTM: 1sec GBS: GRS: GST: 2sec ZDA: 1s GNS: MSS: 3sec VDR: UHW: APB: 4sec BOD: BWC: BWR: 5sec RMB: XTE: ZTG: 6sec AAM: MTW: 7sec 8sec W84                    ③D
--	-------------------	---

The selected sentence is displayed.  
If no sentence has been selected, no sentence is displayed.

Sentence and Interval Setting Screen

If no sentence is displayed, the output sentence has not been selected.

4. **2** EVENT Press "SENTENCE".
5. Move the cursor to the sentence you wish to output, and press **ENT**.
6. The output interval is displayed. Select the interval and press **ENT**.


## (3) Selecting "ROUTE" and sending data

Saved routes and waypoints are output as RTE and WPL sentences.  
Select the version, bit rate, and output type.

<b>M</b> DATA OUT1      16:11:07 U <small>1</small> 1. DATA IN/OUT : OUT 2. BITRATE : 4800bps 3. FORMAT : NMEA Ver2.3 4. OUT TYPE : ROUTE+WPT ROUTE 001  0. START  W84                    ③D
---

3. **1** MARK Press "DATA IN/OUT".
  4. Press **▲** **▼** to select "OUT", and then press **ENT**.
  5. **2** EVENT Press "BITRATE", and select the bit rate.
  6. **3** Press "FORMAT", and select the format.
- "NMEA Ver1.5", "NMEA Ver2.1", and "NMEA Ver2.3" can be chosen as data formats.


7.  Press "OUT TYPE", and select the data you wish to output.



Output data types:

- **ALL WPT**  
All waypoint data in the waypoint list is output as WPL sentences.
- **ALL ROUTE**  
All route data in the route list is output as RTE sentences.
- **ALL WPT + ROUTE**  
All waypoint data in the waypoint list, and all route data in the route list, is output as WPL and RTE sentences.
- **ROUTE**  
The specified route data is output as an RTE sentence.  
Route specification can be performed from the "ROUTE LIST", "ROUTE No.", or "FROM TO".
- **ROUTE + WPT**  
The specified route data and route waypoint data is output as RTE and WPL sentences.  
Route specification can be performed from the "ROUTE LIST", "ROUTE No.", or "FROM TO".

Select "ROUTE" or "ROUTE + WPT" as the output type, and the route selection method will be displayed. Select one and set the route to be output.



• **ROUTE LIST**

The route list will be displayed. Select the route you wish to output, and press .

Multiple contiguous route numbers can be selected.

Please refer to "4.8.3 Selecting a Range within a List" for details regarding range selection.


• **ROUTE No.**

Enter the route number and press .

• **FROM TO**

Multiple contiguous route numbers can be selected. Enter the route numbers you want to output from the first route to the last, and press .


8.  Press "START" to display the following, and press "YES" to start data output.



<b>M</b> DATA OUT1 16:13:17 U <small>1</small>	<b>M</b> DATA OUT1 16:13:40 U <small>1</small>
1. DATA IN/OUT : OUT	1. DATA IN/OUT : OUT
2. BITRATE : 4800bps	2. BITRATE : 4800
3. FORMAT	3. ● SENDING... . 3
4. OU DATA OUTPUT ARE YOU SURE? NO YES	4. CLR: CANCEL
O. START	
W84	W84
③④	③④


#### (4) Selecting "ROUTE" and receiving data

Routes and waypoints are received from external sources as RTE and WPL sentences.  
Select the bit rate.



<b>M</b> DATA OUT1 16:14:14 U <small>1</small>
1. DATA IN/OUT : IN
2. BITRATE : 4800bps
O. START
W84
③④

3.  Press "DATA IN/OUT".
4.  Press  to select "IN", and then press .
5.  Press "BITRATE", and select the bit rate.
6.  Press "START" to display the following, and press "YES" to enter data receiving mode.



<b>M</b> DATA OUT1 16:14:32 U <small>1</small>	<b>M</b> DATA OUT1 16:14:49 U <small>1</small>
1. DATA IN/OUT : IN	1. DATA IN/OUT : IN
2. BITRATE : 4800bps	2. BITRATE : 4800
DATA INPUT ARE YOU SURE? NO YES	● RECEIVE WAITING CLR: CANCEL ENT: FINISH
O. START	O. START
W84	W84
③④	③④

7. Once the unit is awaiting data reception, send RTE or WPL sentences from externally connected equipment.

Received data is stored in the internal memory.

8. When all data transmission has been completed, press .

The unit will continue awaiting data until  is pressed.

## (5) When "JRC" is Selected

The bit rate is fixed at 1200 bps.

MDATA I/O 16:15:28 U①	
1. DATA IN/OUT1	: JRC
2. DATA OUT2	: NMEA
3. DATA OUT3	: NMEA
4. DATA IN/OUT4	: NMEA
5. CONTACT OUT1	: SYSTEM
6. CONTACT OUT2	: SYSTEM
7. LAN DATA OUT	: NMEA Ver1.5
ACTIVE ROUTE	: OFF
DATA ROUTE	: SHARE
MUTUAL	: OFF
REMOTE MAINTENANCE	: OFF
W84	BD

## (6) When "PRINTER" is Selected

Data is output in dedicated printer format.

Select the bit rate and output interval.

The bit rate is selected at 4800bps for DPU-414 Printer.

Select the interval. If "OFF" is selected, data is not output. If "ONCE" is selected, data is output one time.

MDATA OUT1 16:16:01 U①	
1. BITRATE	: 4800bps
2. INTERVAL	: OFF
W84	BD

## (7) When "SWITCH" is Selected

The bit rate is fixed at 4800 bps, and data is output for automatic switching control (NCZ-1573A).

MDATA I/O 16:16:35 U①	
1. DATA IN/OUT1	: SWITCH
2. DATA OUT2	: NMEA
3. DATA OUT3	: NMEA
4. DATA IN/OUT4	: NMEA
5. CONTACT OUT1	: SYSTEM
6. CONTACT OUT2	: SYSTEM
7. LAN DATA OUT	: NMEA Ver1.5
ACTIVE ROUTE	: OFF
DATA ROUTE	: SHARE
MUTUAL	: ON
REMOTE MAINTENANCE	: OFF
W84	BD

If "SWITCH" is selected when the LAN mutual monitoring mode is set to "OFF", the screen at right will be displayed and the mutual monitoring mode will be set to "ON".

MDATA I/O 16:17:17 U①	
1. DATA IN/OUT1	: SWITCH
2. DATA OUT2	: NMEA
3. DATA OUT3	: NMEA
4. DATA OUT4	: MUTUAL SETTING
5. CONTACT OUT1	: WAS TURNED ON
6. CONTACT OUT2	: WAS TURNED ON
7. LAN DATA OUT	: NMEA Ver1.5
ACTIVE ROUTE	: OFF
DATA ROUTE	: SHARE
MUTUAL	: OFF
REMOTE MAINTENANCE	: OFF
W84	BD

Mutual monitoring mode is "ON"

If you do not need automatic switching control, do not set this field to "SWITCH".

#### **4.20.7.2 Setting Data OUT2**

- NMEA, JRC, IEC, route WPT, and automatic switch control data can be output via data OUT2.

##### **Procedure**

1. Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.
2. Press  , and then  to select "DATA OUT2".

From this point on, operation is identical as that described for "DATA IN/OUT1". However, routes and waypoints can not be received from external sources as RTE and WPL sentences.

#### **4.20.7.3 Setting Data OUT3**

- NMEA, JRC, IEC, route WPT, and automatic switch control data can be output via data OUT3.

##### **Procedure**

1. Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.
2. Press  , and then  to select "DATA OUT3".

From this point on, operation is identical as that described for "DATA IN/OUT1". However, routes and waypoints can not be received from external sources as RTE and WPL sentences.

#### **4.20.7.4 Setting Data IN/OUT4**

- NMEA, JRC, IEC, route, and switch data can be output via data IN/OUT4.
- To connect Current, temperature and Depth meter, set to only bit rate and use a Pin No.1,2 in DATA IN/OUT connector.
- The layer and data number for displaying tidal current data can be set by setting externally connected equipment. Please refer to "4.20.7.8 Setting Tidal Current Meter Input" for setting method.

##### **Procedure**

1. Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.
2. Press  , and then  to select "DATA IN/OUT4".

From this point on, operation is identical as that described for "DATA IN/OUT1".

#### 4.20.7.5 Setting Contact Output 1


- The following contact outputs can be set for contact output 1: System, System + XTD + ARV, Log Pulse (200 pulse/NM), Log Pulse (400 pulse/NM), and Alarm ACK.
- Please refer to "6.3 Cable Connection" for connection.

The following is an overview of the contact output 1 submenu.

- SYSTEM: A contact is made when the No positioning fixing alarm occurs.
- SYS+XTD+ARV: A contact is made when No positioning fixing, XTD / boundary, or arrival / anchor alarms occur.
- 200p/NM: 200 pulse/NM LOG pulse is output.
- 400p/NM: 400 pulse/NM LOG pulse is output.
- ALARM ACK: Operates as an ACK when an alarm has been generated by externally connected equipment.

##### Procedure

- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.
- Press **7 CURS**, and then **5 GOTO** to select "CONTACT OUT1".
- Select the state for which you want contact operation with **▲** **▼**, and then press **ENT**.



#### 4.20.7.6 Setting Contact Output 2

- The following contact outputs can be set for contact output 2: System, System + XTD + ARV, Log Pulse (200 pulse/NM), Log Pulse (400 pulse/NM), and Alarm ACK.
- Please refer to "6.3 Cable Connection" for connection.

- Please refer to "4.20 Equipment Configuration" and switch the unit to equipment configuration mode.
- Press **7 CURS**, and then **6 ←→** to select "CONTACT OUT2".

From this point on, operation is identical as that described for "CONTACT OUT1".

#### 4.20.7.7 Setting LAN Settings

- LAN configuration can be performed for active route sharing, data route sharing, data output, mutual monitoring, and remote maintenance output.
- In data output, the output NMEA sentence can be selected.
- To share active or data routes, sharing route configuration must be performed.

Set the route sharing setting to "SHARE" for data routes.

When set to "SHARE", data route reception will occur automatically.

For active routes, set the route sharing setting to "SHARE 1", "SHARE 2", "SHARE 3", or "SHARE 4".

- (1) SHARE1: If the active route is switched on the unit, the route will automatically be sent out to connected equipment.  
When a shared route is received, the route is automatically switched.
- (2) SHARE2: If the active route is switched on the unit, a request is made to the user of the unit before the route is sent. Transmission of the route to the connected equipment is dependant on the permission of the user.  
If the user has not authorized sending, the active route will only be executed on the local unit.  
When a shared route is received, the route is automatically switched.
- (3) SHARE3: If the active route is switched on the unit, the route will automatically be sent out to connected equipment.  
When a shared route is received, the user is asked whether or not they want to switch routes.  
If the user does not authorize route switching, the route will not be switched.
- (4) SHARE4: If the active route is switched on the unit, a request is made to the user of the unit before the route is sent. Transmission of the route to the connected equipment is dependant on the permission of the user.  
If the user has not authorized sending, the active route will only be executed on the local unit.  
When a shared route is received, the user is asked whether or not they want to switch routes.  
If the user does not authorize route switching, the route will not be switched.

The following icon is displayed when active routes are shared.

SHARE1 Icon:    SHARE2 Icon:    SHARE3 Icon:    SHARE4 Icon:

- To perform mutual monitoring, mutual monitoring mode must be configured. With mutual monitoring mode, when GPS positioning is not being performed, the GPS positioning information from other units can be displayed.
- Remote maintenance output configuration can be used to regularly output data for use in remote maintenance.

<b>M</b> DATA I/O	16:18:43 U①	LAN setting pull-down
1. DATA IN/OUT1 : NMEA		
2. DATA OUT2	<b>DATA OUT</b>	Data output setting
3. DATA OUT3	<b>ACTIVE ROUTE</b>	ACTIVE route sharing setting
4. DATA IN/OUT	<b>DATA ROUTE</b>	DATA route sharing setting
5. CONTACT OUT	<b>MUTUAL</b>	Mutual monitoring mode setting
6. CONTACT OUT	<b>REMOTE MAINT</b>	Remote maintenance output setting
7. <b>LAN</b>	DATA OUT : NMEA Ver 1.5	
	ACTIVE ROUTE : OFF	
	DATA ROUTE : SHARE	
	MUTUAL : OFF	
	REMOTE MAINT : OFF	
W84	③D	


LAN Selection Screen

## Procedure

1. Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
2. Press  <sup>7</sup>, then  <sup>7</sup>, and select "LAN".

### (1) Data route sharing setting



3. Press   to select "DATA ROUTE", and press .
  4. Press   to select "SHARE", and press .
- Select "OFF" to disable sharing.



Data Route Selection Screen

### (2) Active route sharing setting

3. Press   to select "ACTIVE ROUTE", and press .
  4. Press   to select "SHARE1", "SHARE2", "SHARE3", or "SHARE4", and press  to display the connection destination screen.
- Select "OFF" to disable sharing.




Connection Destination Screen

5. Press  <sup>1</sup> "CONNECT", select the destination, and press .
- Normally, "MULTICAST" should be selected for the destination.  
To send to a specific unit, select "UNICAST".
6. When "UNICAST" is selected, press  <sup>2</sup> and  <sup>3</sup> to select the destination IP "2.TO IP" and "3.PORT No.".

### (3) Data output setting

3. Press to select "DATA OUT", and press .




4. Press <sup>1</sup> "CONNECT".
5. Select the connection destination with , and press .
- "MULTICAST", "UNICAST", or "BROADCAST" can be set as connection destinations. Normally, "MULTICAST" should be selected.
- When "UNICAST" is selected, destination IP "2. To IP" and "3. Port No." can be set.
6. Press "FORMAT".
7. Press , select the data format, and press .
- "IEC", "NMEA Ver1.5", "NMEA Ver2.1", and "NMEA Ver2.3" can be chosen as data formats.
8. Press <sup>5</sup> "SENTENCE".
9. Press to select the output sentence, and press .
10. Press to select the sentence output interval, and press .
11. After you have selected all sentences you wish to output, press .

### (4) Mutual monitoring mode setting

3. Select "MUTUAL" with , and press .
4. Press to select "ON", and then press .

To stop mutual monitoring, select "OFF".

When "ON" is selected, and select "CONNECT". Normally, "MULTICAST" should be selected.



## (5) Remote maintenance data output setting

3. Use to select "REMOTE MAINT", and press .
  4. Press to select "ON", and then press .
  5. Press "CONNECT".
  6. Select the connection destination with , and press .
- "MULTICAST", "UNICAST", or "BROADCAST" can be set as connection destinations. Normally, "MULTICAST" should be selected.
- When "UNICAST" is selected, destination IP "2. To IP" and "3. Port No." can be set.
7. Press "INTERVAL".
  8. Press to select the output period, and press .

### 4.20.7.8 Setting Tidal Current Meter Input

- You can perform tidal current meter input settings.
- Data need to be entered starting with DATA IN4.

#### Procedure

1. Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
2. Press , and then to select "DATA IN/OUT4".
3. Select "EXT EQUIP" with , and press .
4. The tidal current meter input screen will be displayed.  
You can select the layer and data number you wish to display.

<b>MEXT EQUIP</b>	18:13:47 U1
1. CURRENT	
LAYER-A	
LAYER :003	DATA No : 1
LAYER-B	
LAYER :003	DATA No : 2
LAYER-C	
LAYER :003	DATA No : 3
W84	3D

## 4.20.8 Setting the IP Address

- The display's IP address, subnet mask, and default gateway can be set. The MAC address can be displayed.

### Procedure

- Refer to "4.20 Equipment Configuration" and display the equipment configuration menu.
- Press "IP".

#### (1) IP ADDRESS Configuration

- Press "IP ADDR".
- Press to select "INPUT", and press .
- Enter the IP address with the numeric keypad, and press .  
To return the value to the default value, select "DEFAULT" and press .

#### (2) SUBNET MASK Configuration

- Press "SUBNET MASK".
- Press to select "INPUT", and press .
- Enter the subnet mask with the numeric keypad, and press .  
To return the value to the default value, select "DEFAULT" and press .

#### (3) DEFAULT GATEWAY Configuration

- Press "DEFAULT GATEWAY".
- Press to select "INPUT", and press .
- Enter the default gateway with the numeric keypad, and press .  
To return the value to the default value, select "DEFAULT" and press .



# Section 5 Maintenance and Inspection

Proper maintenance may greatly affect the lifespan of the equipment. In order to maintain the equipment in peak state, perform the following regularly.

## **WARNING**



Do not perform internal inspections or modifications of the equipment. Inspection or modification by unauthorized personnel may result in fire, electric shock, or equipment failure. Please consult with JRC or an affiliate to perform internal inspections or repair.

## **CAUTION**



Use only the specified fuse.  
Failure to do so may result in fire or equipment failure.



Use only the specified batteries.  
Failure to do so may result in equipment failure or malfunction.

## **5.1 General Maintenance and Inspection**

- Operate the equipment under standard power voltage levels (DC 10.8 - 31.2 V).
- The following shows general maintenance and inspection methods using standard tools.

No.	Item	Maintenance and Inspection
1	Cleaning	Clean the panel screen, knobs, and switches with a soft cloth. There are no gears in the unit, so oil lubrication is unnecessary.
2	Parts Securing	Check for loose screws, nuts, and connectors, and connect securely any that have loosened.

Perform inspection of the displayed items when the equipment is functioning normally. Compare operating results to the normal operation values in order to detect problems quickly.

## 5.2 Alarms

Refer to 4.2.7 and check if any alarm is given or not. If it is, check the details referring to the list shown below.

**Alarm List**

Message Number	Message Contents	Alarm Causes
001	No Fix	No Fix
002	HDOP OVER	HDOP value has been exceeded setting level
003	GPS Antenna Open	GPS Antenna Open(Sensor)
004	GPS Antenna Short	GPS Antenna Short(Sensor)
005	Core ROM Error	Memory Error(GPS core of Sensor)
006	Core RAM Error	Memory Error(GPS core of Sensor)
007	Core RTC Error	RTC(Real Time Clock) Error(GPS core of Sensor)
008	Controller ROM Error	Memory Error(Processing Unit of Sensor)
009	Controller RAM Error	Memory Error(Processing Unit of Sensor)
010	Controller FPGA Error	FPGA Error(Processing Unit of Sensor)
011	Controller Backup Error	Data Buck up Error(Processing Unit of Sensor)
012	Flash ROM Access Error	Flash ROM Deletion, Write Error(ROM[1])
013	Flash ROM2 Access Error	Flash ROM Deletion, Write Error(ROM[2])
014	RAM Access Error	RAM Read, Write Error
015	SIO(0) Error	Serial Port Error(GPS/DGPS)
016	SIO(1) Error	Serial Port Error(DATA OUT1)
017	SIO(2) Error	Serial Port Error(DATA OUT2)
018	SIO(3) Error	Serial Port Error(DATA OUT3)
019	SIO(4) Error	Serial Port Error(DATA OUT4)
020	LAN Error	LAN Port Error
021	No Sensor Data	Sensor periodic input not possible (Position measurement data unobtainable)
030	Temperature Alarm	Temperature alarm is occurred
031	Depth Alarm	Depth alarm is occurred
032	Dist Alarm	Trip alarm is occurred
033	Speed Alarm	Speed alarm is occurred
040	Sensor Data Invalid	Sensor data is invalid(Position, Time, etc.)
041	Sensor IF error	Sensor unconfigurable (Configuration not possible)
042	No Mutual Data	Unable to obtain mutual data
043	CCRP Discrepancy	CCRP disagreement with other equipment
050	Arrival Wpt	Arrival at final waypoint
051	Anchor Out	Anchor alarm is occurred
052	Boundary	Boundary alarm is occurred
053	Xtd	XTD alarm is occurred
060	Inner Error	Display inside Error

## 5.3 Troubleshooting

### 5.3.1 Troubleshooting

#### WARNING



Do not perform internal inspections or modifications of the equipment. Inspection or modification by unauthorized personnel may result in fire, electric shock, or equipment failure. Please consult with JRC or an affiliate to perform internal inspections or repair.

The following is reference information concerning identification of problems.

Problem Behavior	Possible Causes	Troubleshooting Measures
The power does not turn on when the power switch is pressed.	Power is not being supplied by the ship junction box.	Check the cabling from the junction box.
	Power is not being supplied by the power supply equipment (option).	Check the power supply unit cabling.
	The fuse connected to the power cable has blown.	If there are no problems in the cabling, replace the fuse.
	The power supply equipment (option) fuse has blown.	If there are no problems in the cabling, replace the fuse.
	The display unit switch is broken.	Consult with JRC or an affiliate.
The LCD display does not display anything.	The LCD display is broken.	Consult with JRC or an affiliate.
The display does not light up.		
The alarm sound. Is not generated	The buzzer is broken.	Consult with JRC or an affiliate.
	The alarm sound is turned off.	Refer to 4.11.2 for setting the alarm sound.
The click does not sound.	The key press sound is turned off.	Refer to 4.14.3 for setting the Click sound.
There is no reception. (from sensor)	The sensor connection cable is cut.	Check the connection cable.
	The sensor is broken.	Consult with JRC or an affiliate.
There is no reception. (from external devices)	The polarity of the serial cable is incorrect.	Check the polarity of the cable.
	The interface does not match.	Check the interface.
	An unsupported sentence has been entered.	Check the entered commands and version.
There is no transmission. (to external devices)	Output settings have not been configured.	Refer to 4.20.
	The configured channel is incorrect.	Refer to 4.20.
	The DISP-DPU or connector board is broken.	Consult with JRC or an affiliate.

### **5.3.2 Repair Unit**

Repair units and their models are shown below.

No	Name	Model	Notes
1	DISP-DPU	CMJ-551	NWZ-4740 Display Unit
2	LCD Unit	CCN-392A	NWZ-4740 Display Unit
3	Keyboard Unit	CMD-953T	NWZ-4740 Display Unit
4	Connector Board	CMH-2292	NWZ-4740 Display Unit
5	Beacon Antenna	CAW-1	For JLR-4341 Sensor
6	Beacon Controller	CMA-920	For JLR-4341 Sensor

Fuse

No	Name	Model	Notes
1	2A Fuse	MF60NR 250V 2	NWZ-4740 Display Unit

If Beacon Controller or Sensor is replaced, then a Sensor shall be reset.

### **5.3.3 Regular Replacement Parts**

Parts which should be regularly replaced are shown below.

Contact JRC or an affiliate to order.

Replace the radome and packing when replacing the lithium batteries.

Please refer to "4.3 Entering Serial No./Barcode No." in Service Manual and enter the Serial No. or Barcode No. , when replacing the lithium batteries.

No	Name	Model	Life	Notes
1	LCD Unit (Inside display unit)	CCN-392A	40000 hours	Approximately 5 years of continuous use
2	Lithium Battery (Inside Sensor)	CR2354-1VC	Approximately 5 years	Reception is possible even without battery power. (It will takes 30 to 60 seconds longer to fix the position)
3	Radome Kit (JLR-4341 Sensor Radome and Packing)	MPAE30534	Battery replacement	Opening the radome decreases waterproofing effectiveness, so replace the radome and packing as well when performing battery replacement.

# Section 6 Installation

## ⚠ Caution



Please consult with JRC or an affiliate to perform installation.  
Installation by unauthorized personnel may result in malfunction.

### 6.1 GPS Sensor Installation

#### 6.1.1 Selecting the Position for Installation

## ⚠ Caution



When connecting the cable attached to the equipment, do not bend it acutely, twist it, or impart excessive force. Doing so sometimes causes cracks or damage to the coating, resulting in fire or electrocution.



Do not install the sensor where there is excessive vibration.  
Vibration may cause sensor failure.



Do not paint the sensor.  
Doing so may result in reception problems.



The junction box rubber gaskets fit  $\phi$  10 - 20 cables.



Install the sensor where there are no obstacles, in order to ensure that GPS signals can be directly received from satellites without interference or reflection of signals from surrounding objects.

Whenever possible, select a place with the following characteristics.


- 1. An open space, which allows uniform reception of satellite signals.**
- 2. Far away from any high power transmission antennas.**
- 3. Outside radar beams.**
- 4. Away from the INMARSAT antenna by at least 5 meters and outside the INMARSAT beam.**
- 5. Away from the antenna of a VHF transmitter and a direction finder by at least 3 meters.**
- 6. Away from a Magnetic Compass by at least 1 meters.**
- 7. 3 meter or more away from amateur radio antennas.**

If it is difficult to find an ideal site, select a place temporarily and install the equipment. Conduct a test to make sure that the proper performance can be obtained and then fix the equipment in position. If it is installed at an improper place, reception accuracy may be impaired.


## 6.1.2 Sensor Installation Procedure

The sensor base contains 1 inch-14UNS-2B screw holes. It can be attached to poles with cut male screws, or off-the-shelf adapters.

- (1) When performing attachment, always hold and turn the sensor base. Holding and turning the radome may result in a large amount of force applied at the junction of the base and the radome, resulting in damage to the sensor. The diagram shows the JLR-4341, but these instructions apply equally to the JLR-4340 as well.




- (2) Secure the sensor cable in position with a clamp band as shown below to protect it against damage due to vibration.






- (3) When connecting an extension cable to the DGPS sensor, always seal with self-bonding tape in order to waterproof the connector, and wrap this section with vinyl tape to protect it.

### 6.1.3 Installation of the Sensor on the Mast

Use a screw adapter (optional component or equivalent) to connect the sensor to the mast. The diagram shows the JLR-4341, but these instructions apply equally to the JLR-4340 as well.



1. Loosen the fitting belt screw with a screwdriver to remove the clamp.
2. Coil the fitting belt around the mast as shown below.
3. Tighten the clamp screw with the screwdriver.




How to Install the Sensor on the Mast

## 6. 1. 4 Installation of the Sensor to pass a cable through a pole


It is possible to pass a cable through a pole, when DGPS sensor attached to poles with cut male screws. (1inch-14 UNS-2A). In this case, Cable guard rubber (attached article) used.

(1) The cable is installed as following figure.

Do not bend the cable acutely. Doing so may result in damage to the cable.




Do not bend it acutely




Cable installation figure

(2) Cable guard rubber is set in DGPS sensor.




Cable guard rubber  
(attached article)




Push all the way in

(3) When DGPS sensor attached to poles with cut male screws, round off the corners.



(4) When performing attachment, always hold and turn the sensor base. Holding and turning the radome may result in a large amount of force applied at the junction of the base and the radome, resulting in damage to the sensor.



Do not apply force to the joint.

Hold and turn the base.

## 6.2 Display Unit Installation

### 6.2.1 Selecting the Position for Installation

#### ! Warning



Install this unit at least 1 m away from any magnetic compasses.  
Installation near a magnetic compass may result in interference with the magnetic compass, and may result in an accident.

#### ! Caution





Use the indicated screws when installing the display unit to a stable wooden surface. Failure to do so may result in the display unit falling over, causing injury or property damage.

The installation stand (trestle) allows this display to be set up on table-tops, walls, ceilings, etc. Select an installation location that meets the following conditions.

### 6.2.2 Display Installation Procedure

Mount the unit as described below.

- (1) Loosen the unit knob, and disconnect the mount from the unit.
- (2) Use the included screws to secure the mount where desired.
- (3) Return the unit to the mount, and tighten it with the knob.




### 6.2.3 How to Flush Mount the Display




- **Flush Mount** (Connection with standard included components)

Refer to the flush mount overview diagram to perform flush mount installation.

Refer to the diagrams shown below for mount hole and installation space details.




● **Flush Mount** (Connection with optional component)




## 6.3 Cable Connection

### ● Unit (Rear Connectors)



## [Power Supply Connector]


DC12/24V



Power Cable: CFQ-7257 (Included)


Terminal Number (CFQ-7252)	Name		Explanation
1 (Black)	DC12/24V	DCIN -	Connect the included power cable.
2 (Red)		DCIN +	The voltage shall be 10.8 - 31.2 V DC.

## Connection Cable Appearance




### ● Noise Filtering

Make a loop with the cable and clamp it with the included Clamp Filter as shown below.




### [GPS/DGPS Connector]




Terminal Number (CFQ-9000/ CFQ-9002)	Name		Explanation
1 (Red)	GPS/DGPS Power	13V	Power to the sensor is supplied by the display unit.
2 (Black)		GND	
3 (White)	RXD0	B	Receives data from the sensor.
4 (Green)		A	
5 (Yellow)	TXD0	A	Sends configuration data to the sensor.
6 (Brown)	Unused		

#### ● Cable Extension

- (1) For cable lengths of less than 15 m  
Use the extension cable (CFQ-9000).




- (2) For cable lengths of more than 15 m  
Use the junction box (NQE-7700A).




- **Coaxial Cable Kit Connection**

When using a pre-existing coaxial cable, such as when switching from a JLR-6800, use a coaxial cable kit (NQD-4414).





## [Data IN/OUT Connector]



Data Cable: CFQ-5374 (Option)


Terminal Number (CFQ-5374)	Name		Explanation
1 (Brown)	RXD4	A	Receives tide, water temperature, and water depth data, as well as alarm ACK. (Data IN4) (Refer to "5.19.7.8 Setting Tidal Current Meter Input" for details regarding tidal current display configuration)
2 (Red)		B	
3 (Orange)	TXD1	A	Performs output in accordance with "Data IN/OUT1" configured specifications. (Refer to "5.19.7.1 Configuring Data IN/OUT1" for details)
4 (Yellow)		B	
5 (Green)	TXD3	A	Performs output in accordance with "Data OUT3" configured specifications. (Refer to "5.19.7.3 Setting Data OUT3" for details)
6 (Blue)		B	
7 (Purple)	TXD2	A	Performs output in accordance with "Data OUT2" configured specifications. (Refer to "5.19.7.2 Setting Data OUT2" for details)
8 (Grey)		B	
9 (White)	TXD4	A	Performs output in accordance with "Data OUT4" configured specifications. (Refer to "5.19.7.4 Setting Data IN/OUT4" for details)
10 (Black)		B	
11 (Pink)		GND ISO	GND connection for serial transmission cable.
12 (Light Blue)		GND	Chassis earth

## Connection Cable Appearance




## ● Connector Assembly

(1) Prepare the cable to the following dimensions.




(2) Assemble the included components in the following order.



Clamp Ring tightening torque: 1.2 - 1.5 kgf-cm  
Sealing Nut tightening torque: 1.3 - 1.8 kgf-cm

## [Contact Signal IN/OUT Connector]





Data Cable: CFQ-5404 (Option)

Terminal Number (CFQ-5404)	Name	Explanation	
1	Unused		
2			
3			
4			
5			
6			
7 (Purple)	Contact Output 1	COM	Outputs contact signal. (Refer to "5.19.7.5 Setting Contact Output 1" for configuration details)
8 (Grey)		NC	
9 (White)		NO	
10 (Black)	Contact Output 2	COM	Outputs contact signal. (Refer to "5.19.7.6 Setting Contact Output 2" for configuration details)
11 (Pink)		NC	
12 (Light Blue)		NO	
13 (Light Green)	Contact Input	ACKIN+	Inputs contact signal. (Performed by shorting both terminals)
14 (Light Brown)		ACKIN-	


NO: Normally Open

NC: Normally Closed

## Connection Cable Appearance




## [Ethernet Connector]



Terminal Number (CFQ-5473)	Name		Explanation
1 (Orange/White)	TX	+	Outputs data. (Refer to "5.19.7.7 Setting LAN Settings" for configuration details)
2 (Orange)		-	
3 (Green/White)	RX	+	Inputs data. (Refer to "5.19.7.7 Setting LAN Settings" for configuration details)
4 (Blue)			
5 (Blue/White)			
6 (Green)	RX	-	Inputs data. (Refer to "5.19.7.7 Setting LAN Settings" for configuration details)
7 (Brown/White)			
8 (Brown)			

### [RS232C Connector]


This port is a dedicated port for updates and printer connection.  
Remove the two screws from the rear, remove the cover, and connect the cable.  
Perform printer configuration via Data IN/OUT1.  
Use a straight cable for updating, and a cross cable when connecting a printer.



Female (S-type)

Terminal Number	Name	Explanation
1	Unused	
2	TXD	Transmitted data
3	RXD	Received data
4	Unused	
5	GND ISO	Signal ground
6	Unused	
7	CTS	Transmission possible
8	RTS	Transmission request
9	Unused	

### RS232C Cable for updating



\* An all-pin cable can also be used.

## 6.4 Optional Peripheral Connection

### 6.4.1 Sub Display Connection

Connect the sub display sensor connection terminal to the main display external equipment connection terminal (serial).

Use a junction box (CQD-10).

Any main display external equipment connection terminal can be used. The following specifications apply to the terminal.



Data format: IEC

Bit rate: 4800 bps

Sentence Sub Display: "On"

To display satellite information on the sub display, change the bit rate to "9600 bps", and add "GSV" and "CD, GP, 3" to the sentence setting.

Set the display type to "Sub" to use the unit as a sub-display.



## 6.4.2 Junction Box Connection


### ⚠ Caution



The junction box rubber gaskets ( $\phi 25$  Gland side) fit  $\phi 10 - 20$  cables.

- **How to Mount the Junction Box on a Flat Surface**

Securely mount the junction box on a given flat surface using self-tapping screws and flat washers as shown below.





**Memo**

The self tapping screws and flat washers in the figure above are not included with this equipment.

- **How to Mount the Junction Box on the Mast**


Securely mount the junction box on the mast using the pole mounting kit (option: MPBP30608).





- **Internal Connection**

Connect the respective cables (cable from the DGPS sensor and extension cable) to the terminals provided in the junction box as shown in the following figure.




DGPS Sensor Cable	Junction Box Terminal
Red	1
Black	2
White	3
Green	4
Yellow	5
Brown	6
Shield Line	3

JLR-4340 GPS Sensor Cable	Junction Box Terminal
Red	1
Black	2
White	3
Green	4
Yellow	5
Brown	6
Blue	3
Shield Line	3
Orange(not use)	

#### 6.4.3 Coaxial Cable Kit Connection


Please refer to the instructions included in the coaxial cable kit for details regarding coaxial cable kit connection.



#### 6.4.4 Printer Connection

The RS-232C connector can be connected to the printer (DPU-414).

The RS-232C connector can be configured via Data IN/OUT1. Set the Data IN/OUT1 data format to "Printer". The printer format data is output from RS-232C connector and also DATA IN/OUT connector No.3,4-pin. Another equipment cannot be connected this pin.



Please refer to "DPU-414 Operation Manual" and set the DIP switches on DPU-414.

DIP SW1

Switch No.	Function	Settings	
			ON/OFF
1	Input Method	Serial	OFF
2	Printing speed	High	ON
3	Auto loading	ON	ON
4	CR Function	Carriage return	OFF
5	DIP SW setting Command	Enable	ON
6	Print density	100%	OFF
7			ON
8			ON

DIP SW2

Switch No.	Function	Settings	
			ON/OFF
1	Print mode	Normal printing(40 columns)	ON
2	User-defined characters buck-up	ON	ON
3	Character type	Ordinary characters	ON
4	Zero font	0	ON
5	International character set	Japanese	ON
6			ON
7			ON
8			ON

DIP SW3

Switch No.	Function	Setting	
			ON/OFF
1	Data bit length	8 bits	ON
2	Parity permission	Without	ON
3	Parity condition	Odd	ON
4	Flow control	H/W BUSY	ON
5	Baud rate	4800bps	ON
6			OFF
7			OFF
8			OFF


## 6.4.5 Connecting Two Navigation Devices to a Printer

A switch (NCZ-777) is necessary when connecting 2 GPS units to printer (DPU-414).

RS-232C connectors and printer (DPU-414) can be connected.

The RS-232C connectors for both units are configured in Data IN/OUT1. The Data IN/OUT1 data format should be set to "printer".

Use the printer connection kit (7ZXJD0076) to extend the printer power cable.




**Printer Cable (7ZCNA4109/7ZCNA4112) Pin**

3	Red	RXD
4	Black	TXD
7	Green	RTS (Not Use)
5	Blue	GND

Cable Connector

**Connection Example**



## 6.4.6 Connecting 2 GPS Units to an Automatic GPS Select Switch


An automatic GPS select switch (NCZ-1537A) can be used to connect and automatically switch between two GPS units. The No. 1 GPS unit normally outputs data, but when it is not performing positioning, the No. 2 GPS unit is automatically switched over to.

To perform automatic switching, the two GPS units must be connected in a LAN, and the No. 2 GPS unit must output control signaling to the automatic GPS select switch.

Set the No. 1 GPS unit LAN setting mutual monitoring to "On".

Set the No. 2 GPS unit LAN setting mutual monitoring to "On", and set the control signal output port data format to "SWITCH".


Set the Dip switch (S1) on NCZ-1537A to 1: ON and 2: ON.



### Connection Example

The following connection conditions apply to the connection example.

- GPS Data is output from TXD3 Port (DATA OUT3) of each GPS Unit.
- Control signal is output from TxD2 Port (DATA OUT2) of No2 GPS Unit.




## 6.5 LAN and Serial Connection

This section contains representative examples of LAN and serial connections and settings. Please refer to "5.19.7 Configuring Data I/O" for details regarding configuration.

The following connection conditions apply to the connection example.

- Two GPS units, 1 sub-display, and ECDIS are connected via LAN and are sharing routes
- The LAN is connected to remote maintenance
- Serial cabling is used to connect to the automatic GPS select switch and printer.
- The HUB of ECDIS is used.

### Connection Example



### Setting Examples

Setting Item	No. 1 GPS Unit	No. 2 GPS Unit	Sub-Display	
1. Display Type	Main	Main	Sub	
2. Sensor No.	1	2	1	
3. LAN				
ACTIVE Route	Share4	Share4	Share4	
DATA Route	Share	Share	Share	
Mutual Monitoring	On	On	On	
Data OUT	Connect	Multicast	Multicast	Multicast
	Format	IEC	IEC	IEC
	Sentence	Sub-Display ALR, ACK	Sub-Display ALR, ACK	ALR, ACK
Remote Maintenance	On	On	Off	
4. Serial				
Data IN/OUT1	Data Format	Printer	Printer	Not yet determined
	Bit Rate	4800	4800	
Data OUT2	Data Format	Unused	Switch	
Data OUT3	Data Format	IEC	IEC	
	Bit Rate	4800	4800	
	Sentence	User Selected	User Selected	
Data IN/OUT4		Unused	Unused	


If the "PRINTER" data format is selected, output will be in a printer-only dedicated format.

If the "SWITCH" data format is selected, automatic GPS select switch control signaling will be output.

Selecting "SUB-Display" as the sentence will allow you to select the necessary sentence for the sub-display.

## 6.6 Connection Diagram

### Typical Connection Example



# Section 7 After-Sales Service

## 7.1 Warranty

- Specific periods may vary based on our warranty policies, but the standard warranty period is **one year** from the date of purchase.

## 7.2 Repair parts stocking Period

- We keeps functional repair parts for this equipment (parts necessary for the functioning of this equipment) in stock for 10 years from the discontinuation of production.

## 7.3 When Requesting Service

When you think the equipment is not operating properly, please read "5.3 Troubleshooting" carefully, and inspect the equipment again. If the problem persists, stop using the equipment, and consult your dealer, or a JRC branch or affiliate.

- **Repairs during the warranty period**

Should a malfunction or failure occur when the equipment is operated according to the descriptions and instructions contained herein, it is repaired free of charge during the warranty period by JRC or another location specified by your dealer. However, any repair for failures resulting from misuse, negligence, or natural disasters, fire, or other Acts of God is charged.

- **Repairs after the warranty period**

Repairs to restore the proper equipment operation can be made at a specified rate with the user's consent. In this case, the equipment can either be sent to JRC or an affiliate, or on-ship repairs can be performed at a location specified by JRC or a sales affiliate. Repairs which cannot be performed on-board the ship needs to be performed in a repair plant.

- **Information that needs to be provided when requesting service**

- Name, model, production date, and serial number
- Detailed description of the malfunction (alarm number, etc.)
- Name, address, and telephone number of your company or organization

## 7.4 Recommended Checks and Inspection

Equipment performance is subject to degradation due to age and change of component conditions over time. In addition to your own routine check, additional inspection and maintenance is recommended. Please consult with your dealer or one of our local offices. Note that this inspection and maintenance is not free of charge.

If you have any other questions about after-sales service, please direct your inquiries to your dealer or nearest local office.

A list of branches is provided at the end of the "Contact List".



# Section 8      Disposal



## WARNING



When disposing of the used lithium battery, place insulating tape over the battery terminals, or otherwise insulate the battery. Failure to do so may result in heating, explosion, or fire due to a shorted battery.

### 8.1 Disposal of the Equipment

- Observe all rules and regulations of the local authorities when disposing of this equipment.

### 8.2 Disposal of Used Batteries

This equipment contains a lithium battery.

- When disposing of the used lithium battery, place insulating tape over the battery terminals, or otherwise insulate the battery. Dispose of the battery properly as directed by the local authorities. Consult your dealer, our sales office, or the local authorities for further details on disposal methods.



# Section 9 Specification

## 9.1 NWZ-4740 DISPLAY UNIT

### 9.1.1 Basic

- Display Unit : 5.7 inch FSTN LCD 320×240 dots
- Backlight : LCD and Key lighting
- Dimmer Levels : Bright, Medium, dark, off
- Memories : Waypoints 10000points maximum  
Event/Mark 1000points maximum (include MOB)  
Track 2000points maximum  
Route 100routes maximum
- Route plan : 512 waypoints per one route
- Geodetic datum : Selection among 46 geodetic datum
- Magnetic Variation : Automatic or manual
- Navigation Calculation : Grate circle or Rhumb line selectable
- Alarm : Arrival, Anchor, Boundary, XTD, No position fix, Speed, Trip, Temperature\*, Depth\*, HDOP
- Plot Function Scale : 0.2,0.5,1,2,5,10,20,50,100,200,300NM
- Interval : 1~60min(1 sec) or 0.01~99.99NM(0.01NM) selectable
- Data Input/Output : RS-422 4 output ports, 1 input port, 1 LAN port
- Contact : 2 output ports, 1 input port
- Selectable Unit : Distance, Speed NM, kn or km, km/h or mi, mi/h selectable  
height, Depth m or ft or fm selectable  
Temperature °C or °F selectable
- Loran Conversion Function : Latitude and longitude can be converted into the Loran time difference.
- Display Language : Japanese or English
- Power Supply Voltage : DC12/24V (+30%, -10%)
- Power Consumption : less than 10W (JLR-7800)  
less than 9W (JLR-7500)  
less than 7W (NWZ-4740)
- Dimension : 267.4(W)×162(H)×85(D)mm
- Mass : Approximately 2.3Kg

\*: External sensor must be connected.

### 9.1.2 Environment

- Operating Temperature : -15°C~+55°C
- Storage Temperature : -25°C~+70°C
- Vibration : IEC60945 ed.4 conformant
- EMC : IEC60945 ed.4 conformant
- Waterproofing : IP44

### 9.1.3 External Interface

#### (1) Serial Transmission

Channel	Specification			Notes
DATA IN/OUT1	RS-422	Output	NMEA, IEC, JRC	
	RS-232C	Input/Output	-	for PC or Printer
DATA OUT2	RS-422	Output	NMEA, IEC, JRC	
DATA OUT3	RS-422	Output	NMEA, IEC, JRC	
DATA IN/OUT4	RS-422	Input	NMEA	External Equipment
		Output	NMEA, IEC, JRC	

#### (1-1) NMEA

- Specification : NMEA0183
- Version : Ver1.5,2.1,2.3
- Bit Rate : 4800,9600,19200,38400bps
- Data Bit : 8bit
- Parity Bit : None
- Start Bit : 1bit
- Stop Bit : 1bit
- Output Sentence : GGA,RMC,GLL,VTG,GSA,GSV,DTM,GBS,GRS,GST,ZDA,GNS,  
MSS\*\*,ALR,VDR\*,VHW\*,APB,BOD,BWC,BWR,RMB,XTE,ZTG,  
AAM,ALR,RTE,WPL,ACK,  
HDT\*,THS\*,DBT\*,DPT\*,MTW\*,CUR\*,VBW\*  
: 1s,2s,3s,4s,5s,6s,7s,8s,9s,OFF
- Input Sentence : HDT,THS,DBT,DPT,MTW,CUR,VBW,VHW,ACK,WPL,RTE,ALR

\*\*Function only available on JLR-7800

\*External sensor must be connected

- 1) Some combinations of output sentence, bit rates, and output intervals may not be possible.

#### (1-2) IEC

- Specification : IEC61162

#### (1-3) JRC

- Specification : JRC
- Bit Rate : 1200bps
- Data Bit : 8bit
- Parity Bit : None
- Start Bit : 1bit
- Stop Bit : 2bit

#### (2) Contact Signal

Channel	I/O	Notes
CONTACT OUT1	Output	Alarm,200p/NM,400p/NM,ACK
CONTACT OUT2	Output	Alarm,200p/NM,400p/NM,ACK
CONTACT 3	Input	ACK

#### (3) LAN

- Specification : JRC
- Bit Rate : 10/100Mbps
- Common Route : JRC
- Data output : NMEA, IEC

## 9.2 JLR-4341 DGPS Sensor

### 9.2.1 Basic

#### (1)GPS Unit

- Reception Method : Multi channel 12ch + SBAS 1ch
- Reception Frequency : 1575.42MHz±1MHz (C/A code)
- Maximum Number of Tracked Satellites : 12 satellites
- Accuracy : 13m 2DRMS (HDOP≤4 SA off)  
5m 2DRMS (Beacon selected)  
7m 2DRMS (SBAS selected)
- SBAS : WAAS, MSAS, EGNOS
- Geodetic datum : Selection among 46 geodetic datum

#### (2)Beacon Unit

- Reception Frequency : 283.5~325kHz
- Selection of Beacon Station : Automatic or manual

#### (3)Power Supply

- Power Supply Voltage : DC12/24V (+30%,-10%)
- Power Consumption : less than 2.5W

#### (4)Dimensions and Mass

- Dimensions : φ134mm×H155mm
- Mass : Approximately 1.7kg (Include Cable)

### 9.2.2 Environment

- Operating Temperature : -25°C~+55°C
- Storage Temperature : -40°C~+70°C
- Vibration : IEC60945 ed.4 conformant
- EMC : IEC60945 ed.4 conformant
- Waterproofing : IP56

## 9.3 JLR-4340 GPS Sensor

### 9.3.1 Basic

#### (1)GPS Unit

- Reception Method : Multi channel 12ch + SBAS 1ch
- Reception Frequency : 1575.42MHz±1MHz (C/A code)
- Maximum Number of Tracked Satellites : 12 satellites
- Accuracy : 13m 2DRMS (HDOP≤4 SA off)  
7m 2DRMS (SBAS selected)
- SBAS : WAAS、MSAS、EGNOS
- Geodetic datum : Selection among 46 geodetic datum

#### (2)Power Supply

- Power Supply Voltage : DC12/24V (+30%,-10%)
- Power Consumption : less than 1.5W

#### (3)Dimension and Mass

- Dimensions : φ108mm×H108mm
- Mass : Approximately 0.7Kg (Include Cable)

### 9.3.2 Environment

- Operating Temperature : -25°C～+55°C
- Storage Temperature : -40°C～+70°C
- Vibration : IEC60945 ed.4 conformant
- EMC : IEC60945 ed.4 conformant
- Waterproofing : IP56

# Appendix

## Appendix1 List of Geodetic System

Screen Display	Setting		Geodetic System
W84	WGS-84	0	WGS-84
W72	WGS-72	1	WGS-72
TOY	JAPAN	2	Tokyo Datum
NAS	NAD27 USA	3	North American 1927 (USA)
NAS	NAD27 CAN	4	North American 1927 (Canada, Alaska)
EUR	EUROPE 50	5	Europe 1950 (Europe)
AUA	AUSTRA 66	6	Australian geodetic 1966 (Australia)
OGB	OSGB-36	7	Ordnance Survey of Great Britain (England)
008	NAD-83	8	NAD-83
ADI	ADI	11	Adindan (Ethiopia, Sudan)
ARF	ARF	12	ARC 1950 (Botswana)
AUG	AUG	13	Australian Geodetic 1984 (Australia)
BER	BER	14	Bermuda 1957 (Bermuda islands)
BOO	BOO	15	Bogota Observatory (Columbia)
CAI	CAI	16	Compo Inchauspe (Argentine)
CHI	CHI	17	Chatham 1971 (Chatham Islands)
CHU	CHU	18	Chua Astro (Paraguay)
COA	COA	19	Corrego Alegre (Brazil)
BAT	BAT	20	Djakarta (Vatavia) (Sumatra)
EUR	EUR	21	European 1979 (Europe)
GEO	GEO	22	Geodetic Datum 1949 (New Zealand)
GUA	GUA	23	Guam 1963 (Guam)
024	024	24	Hayford 1910 (Finland)
HJO	HJO	25	Hjorsey 1955 (Iceland)
IND	IND	26	Indian (India, Napal)
IRL	IRL	27	Ireland 1965 (Ireland)
KEA	KEA	28	Kertau 1948 (West Malaysia, Singapore)
LCF	LCF	29	L.C.5 Astro (Cayman Brac island)
LIB	LIB	30	Liberia 1964 (Liberia)
LUZ	LUZ	31	Luzon (Philippines)
MER	MER	32	Merchich (Morocco)
MIN	MIN	33	Minna (Cameroon)
NAH	NAH	34	Nahrwan (Oman)
NAP	NAP	35	Naparima, BWI (Trinidad and Tobago)
OEG	OEG	36	Old Egyptian (Egypt)
OHA	OHA	37	Old Hawaiian (Hawaiian Islands )
PLN	PLN	38	Pico de las Nieves (Canary Islands)
PRP	PRP	39	Provisional south American 1956 (South America)
HIT	HIT	40	Provisional south Chilean 1963 (South Chile)
PUR	PUR	41	Puerto Rico (Puerto Rico, Virgin Islands)
QUO	QUO	42	Qornoq (South Greenland)
043	043	43	RT90 (Sweden)
SAO	SAO	44	Santa Braz (San Miguel, Santa Maria islands)
SAN	SAN	45	South American 1969 (South America)
046	046	46	Southwest Base (Faial, Gracinao, Pico, San Jorge, Terceira islands)
TIL	TIL	47	Timbalai 1948 (Brunei, Malaysia)

## Appendix2 List of standard terms, units and abbreviations

Term	Abbreviation	Term	Abbreviation
Acknowledge	ACK	Change	CHG
Acquire, Acquisition	ACQ	Circularly Polarised	CP
Acquisition Zone	AZ	Clear	CLR
Adjust, Adjustment	ADJ	Closest Point of Approach	CPA
Aft	AFT	Compact Disk Read Only Memory	CDROM
Alarm	ALARM	Consistent Common Reference Point	CCRP
Altitude	ALT	Consistent Common Reference System	CCRS
Amplitude Modulation	AM	Contrast	CONT
Anchor Watch	ANCH	Coordinated Universal Time	UTC
Antenna	ANT	Correction	CORR
Anti Clutter Rain	RAIN	Course	CRS
Anti Clutter Sea	SEA	Course Over the Ground	COG
April	APR	Course Through the Water	CTW
Audible	AUD	Course To Steer	CTS
August	AUG	Course Up	C UP
Automatic	AUTO	Cross Track Distance	XTD
Automatic Frequency Control	AFC	Cursor	CURS
Automatic Gain Control	AGC	Dangerous Goods	DG
Automatic Identification System	AIS	Date	DATE
Automatic Radar Plotting Aid	ARPA	Day	DAY
Autopilot	AP	Dead Reckoning, Dead Reckoned Position	DR
Auxiliary System/Function	AUX	December	DEC
Available	AVAIL	Decrease	DECR
Azimuth Indicator	AZI	Delay	DELAY
Background	BKGND	Delete	DEL
Bearing	BRG	Departure	DEP
Bearing Waypoint To Waypoint	BWW	Depth	DPTH
Bow Crossing Range	BCR	Destination	DEST
Bow Crossing Time	BCT	Deviation	DEV
Brilliance	BRILL	Differential GLONASS	DGLONASS
Built in Test Equipment	BITE	Differential GNSS	DGNSS
Calibrate	CAL	Differential GPS	DGPS
Cancel	CNCL	Digital Selective Calling	DSC
Carried (for example, carried EBL origin)	C	Display	DISP
Central Processing Unit	CPU	Distance	DIST
Centre	CENT		

Term	Abbreviation	Term	Abbreviation
Distance Root Mean Square	DRMS	Geometric Dilution Of Precision	GDOP
Distance To Go	DTG	Global Maritime Distress and Safety System	GMDSS
Drift	DRIFT	Global Navigation Satellite System	GNSS
Dropped (for example, dropped EBL origin)	D	Global Orbiting Navigation Satellite System	GLONASS
East	E	Global Positioning System	GPS
Echo Reference	REF	Great Circle	GC
Electronic Bearing Line	EBL	Grid	GRID
Electronic Chart Display and Information System	ECDIS	Ground	GND
Electronic Chart System	ECS	Grounding Avoidance System	GAS
Electronic Navigational Chart	ENC	Group Repetition Interval	GRI
Electronic Position Fixing System	EPFS	Guard Zone	GZ
Electronic Range and Bearing Line	ERBL	Gyro	GYRO
Emergency Position Indicating Radio Beacon	EPIRB	Harmful Substances (applies to AIS)	HS
Enhance	ENH	Head Up	H UP
Enter	ENT	Heading	HDG
Equipment	EQUIP	Heading Control System	HCS
Error	ERR	Heading Line	HL
Estimated Position	EP	High Frequency	HF
Estimated Time of Arrival	ETA	High Speed Craft	HSC
Estimated Time of Departure	ETD	Horizontal Dilution Of Precision	HDOP
European Geo-Stationary Navigational Overlay System	EGNOS	I - Band	I-Band
Event	EVENT	Identification	ID
Exclusion Zone	EZ	In	IN
External	EXT	Increase	INCR
F - Band (applies to Radar)	F-Band	Indication	IND
February	FEB	Information	INFO
Foreword	FWD	Infrared	INF RED
Fishing Vessel	FISH	Initialisation	INIT
Fix	FIX	Input	INP
Forward	FWD	Input/Output	I/O
Frequency	FREQ	Integrated Bridge System	IBS
Frequency Modulation	FM	Integrated Navigation System	INS
Full	FULL	Integrated Radio Communication System	IRCS
Gain	GAIN	Interference Rejection	IR
Geographics	GEOG		

Term	Abbreviation
Interswitch	ISW
Interval	INT
January	JAN
July	JUL
June	JUN
Label	LBL
Latitude	LAT
Latitude/Longitude	L/L
Leeway	LWY
Limit	LIM
Line Of Position	LOP
Log	LOG
Long Pulse	LP
Long Range	LR
Longitude	LON
Loran	LORAN
Lost Target	LOST TGT
Low Frequency	LF
Magnetic	MAG
Man Overboard	MOB
Manoeuvre	MVR
Manual	MAN
Map(s)	MAP
March	MAR
Maritime Mobile Services Identity number	MMSI
Maritime Pollutant (applies to AIS)	MP
Maritime Safety Information	MSI
Marker	MKR
Master	MSTR
Maximum	MAX
May	MAY
Medium Frequency	MF
Medium Pulse	MP
Menu	MENU
Minimum	MIN
Missing	MISSING
Mute	MUTE
Navigation	NAV
Night	NT
Normal	NORM
North	N
North Up	N UP
Not Less Than	NLT
Not More Than	NMT
Not Under Command	NUC
November	NOV
October	OCT
Off	OFF
Officer On Watch	OOW
Offset	OFFSET
On	ON
Out/Output	OUT
Own Ship	OS
Panel Illumination	PANEL
Parallel Index Line	PI
Past Positions	PAST POSN
Passenger Vessel	PASSV
Performance Monitor	MON
Permanent	PERM
Person Overboard	POB
Personal Identification Number	PIN
Pilot Vessel	PILOT
Port/Portside	PORT
Position	POSN
Positional Dilution Of Precision	PDOP
Power	PWR
Predicted	PRED
Predicted Area of Danger	PAD
Predicted Point of Collision	PPC
Pulse Length	PL
Pulse Modulation	PM
Pulse Repetition Frequency	PRF
Pulse Repetition Rate	PRR
Pulses Per Revolution	PPR
Racon	RACON
Radar	RADAR

Term	Abbreviation	Term	Abbreviation
Radar Plotting	RP	Speed	SPD
Radius	RAD	Speed and Distance Measuring Equipment	SDME
Rain	RAIN	Speed Over the Ground	SOG
Range	RNG	Speed Through the Water	STW
Range Rings	RR	Stabilized	STAB
Raster Chart Display System	RCDS	Standby	STBY
Raster Navigational Chart	RNC	Starboard/Starboard Side	STBD
Rate Of Turn	ROT	Station	STN
Real-time Kinematic	RTK	Symbol(s)	SYM
Receive	Rx RX	Synchronised/Synchronous	SYNC
Receiver	RCDR	Target	TGT
Receiver Autonomous Integrity Monitoring	RAIM	Target Tracking	TT
Reference	REF	Test	TEST
Relative	REL	Time	TIME
Relative Motion	RM	Time Difference	TD
Revolutions per Minute	RPM	Time Dilution Of Precision	TDOP
Rhumb Line	RL	Time Of Arrival	TOA
Roll On/Roll Off Vessel	RoRo	Time Of Departure	TOD
Root Mean Square	RMS	Time to CPA	TCPA
Route	ROUTE	Time To Go	TTG
Safety Contour	SF CNT	Time to Wheel Over Line	TWOL
Sailing Vessel	SAIL	Track	TRK
Satellite	SAT	Track Control System	TCS
S-Band	S-BAND	Tracking	TRKG
Scan to Scan	SC/SC	Trail(s)	TRAIL
Search And Rescue	SAR	Transmit and Receive	TXRX
Search And Rescue Transponder	SART	Transceiver	TCVR
Search And Rescue Vessel	SARV	Transferred Line Of Position	TPL
Select	SEL	Transmit	TX
September	SEP	Transmitter	TMTR <sup>1</sup>
Sequence	SEQ	Transmitting Heading Device	THD
Set (i.e., set and drift, or setting a value)	SET	Transponder	TPR
Ship's Time	TIME	Trial	TRIAL
Short Pulse	SP	Trigger Pulse	TRIG
Signal to Noise Ratio	SNR	True	T
Simulation	SIM	True Motion	TM
Slave	SLAVE	Tune	TUNE
South	S	Ultrahigh Frequency	UHF
		Uninterruptible Power Supply	UPS

Term	Abbreviation
Universal Time, Coordinated	UTC
Universal Transverse Mercator	UTM
Unstabilised	UNSTAB
Variable Range Marker	VRM
Variation	VAR
Vector	VECT
Very High Frequency	VHF
Very Low Frequency	VLF
Vessel Aground	GRND
Vessel at Anchor	ANCH
Vessel Constrained by Draught	VCD
Vessel Engaged in Diving Operations	DIVE
Vessel Engaged in Dredging or Underwater Operations	DRG
Vessel Engaged in Towing Operations	TOW
Vessel Not Under Command	NUC
Vessel Restricted in Manoeuvrability)	RIM
Vessel Traffic Service	VTS

Term	Abbreviation
Vessel Underway Using Engine	UWE
Video	VID
Visual Display Unit	VDU
Voyage	VOY
Voyage Data Recorder	VDR
Warning	WARNING
Water	WAT
Waypoint	WPT
Waypoint Closure Velocity	WCV
West	W
Wheel Over Line	WOL
Wheel Over Point	WOP
Wheel Over Time	WOT
World Geodetic System	WGS
X-Band	X-BAND

## Appendix3 Default Settings

Main Menu	Sub Menu	Sub Menu	Default
1.DISPLAY	1.CONTRAST		7
	2.DIMMER -MAXIMUM-		9
	3 -TYPICAL-		6
	4. -MINIMUM-		4
	5.CLICK SOUND		ON
	6.REVERSING MODE		NORMAL
	7.INPUT ASSIST		OFF
	8.DISPLAY SELECT	1.NAV	START
		2.PLOT 1	ON
		3.PLOT 2	ON
		4.PLOT 3	ON
		5. CDI	ON
		6. GPS INFO	ON
		7.WPT INFO	ON
		8.BEACON INFO	ON
		9.NAV ASSIST	ON
2.PLOT	1.WPT		○ (small size)
	2.MARK		● (small size)
	3.EVENT		<input checked="" type="checkbox"/> (small size)
	4.TRACK PERIOD		TIME 0min10sec
	5.TRACK		.
	6.LINE		—
	7. EVENT/MARKLIST		
	8.DELETE EVENT/ MARK/TRACK	1.DELETE EVENT/MARK LIST	
		2.DELETE ALL EVENT	
		3.DELETE ALL MARK	
		4.DELETE ALL EVENT/MARK	
		5.DELETE TRACK	
	8.VISIBLE/INVISIBLE	1.WPT	ON
		2.WPT No.	ON
		3.MARK	ON
		4.EVENT	ON
		5.EVENT/MARK No.	ON
		6.TRACK	ON
		7.LINE	ON
		8.ARRIVAL CIRCLE	LEG
		9.XTD	LEG
		0.NEXT PAGE	
		1.SCALE BAR	ON
		2.SYMBOL INFO	ON
		3.CURSOR INFO	ON
		4.GRID LINE	ON
3.WPT/ROUTE	5.GRID LAT		ON
	6.GRID LON		ON
	0.PREVIOUS PAGE		
	0.NEXT PAGE		
	1.CURSOR		LARGE
3.WPT/ROUTE	2.OWN CIRCLE		OFF
	3.OWN VECTOR		OFF
	0.PREVIOUS PAGE		
	1.ENTRY WPT/ WPT LIST		
3.WPT/ROUTE	2.MAKE ROUTE/ ROUTE LIST		

Main Menu	Sub Menu	Sub Menu	Default
	3.ROUTE START/END	1.LEG CHANGE 2.DIRECTION 3.NAVIGATION	
	4.COPY WPT/ROUTE	1.WPT COPY 2.ROUTE COPY	
	5.DELETE WPT/ROUTE	1.WPT DEL 2.ROUTE DEL	
	6. TRANSFER WPT/ROUTE (LAN)	1.OUT / IN 2.CONNECT / FROM IP 3.TO IP 4.PORT No. 5.FORMAT 6.OUT TYPE 0.START	OUT MULTICAST 0.0.0.0(at shipment) 0(at shipment) SHARE ROUTE ROUTE+WPT
	7.DEFAULT SETTINGS	1.WIDTH PORT 2.WIDTH STBD 3.ARRIVAL RAD 4.SPEED 5.SAIL GC/RL 6.SOG SMOOTHING	1.00NM 1.00NM 1.00NM 10.00kn RL OFF
4.ALARM	1.ARRIVAL/ANCHOR 2.XTD/BOUNDARY 3. DGPS 4. HDOP 5.TEMP 6.DPTH 7.TRIP 8.SPD		ARV XTD ON→OFF 4 OFF OFF OFF OFF
	0.ALARM SOUND SET	1.SYSTEM 2.ARRIVAL/ANCHOR 3.XTD/BOUNDARY 4. DGPS 5. HDOP 6.TEMP 7.DPTH 8.TRIP 9.SPEED	2 1 1 6 2 3 3 3 3

Main Menu	Sub Menu	Sub Menu	Default
5.SYSTEM	1.TIME DIFF		+00:00
	2.DATE DISP		DD MM,YY
	3.TIME DISP		24hr
	4.DATUM		WGS84
	5.UNIT - DIST/SPEED		NM,kn
	6. HEIGHT, DEPTH		m
	7. TEMPERATURE		°C
	8.MAG CORR		OFF
	9.SPEED METER		50kn
6. GPS/BEACON/ SBAS	1.GPS MODE		AUTO
	2.FIX MODE		AUTO
	3.SAT ELV MASK		5 Degrees
	4. HDOP		10
	5.SMOOTHING POSITION		10 sec
	SPEED		10 sec
	COURSE		10 sec
	6. RAIM ACCURACY LEVEL		100m
	7. GPS INITIALIZATION	1.LATITUDE	35° 00.00'N
		2.LONGITUDE	139° 00.00'E
		3.ANT HEIGHT	+10m
		4.DATE	Fixing Value / -(No Fix)
		5.TIME	Fixing Value /-(No Fix)
		0.SET	
	8.BEACON/SBAS	1.STATION SELECT	AUTO
		2.FREQUENCY	321.0KHz(MANUAL)
		3.BIT RATE	200bps(MANUAL)
		4. BEACON INFORMATION	ON
		6.SBAS SEARCH	AUTO
		7. TYPE0 INFORMATION	OFF
		8.RANGING	OFF
9.LORAN	1.LORAN A/C		OFF
	LORAN A		
	1.LORAN A/C		LOLAN A
	2.STN SELECT STN 1		2S0
	3. STN 2		2S2
	4. TD CORR TD1		+0.0 μs
	5. TD2		+0.0 μs
	LORAN C		
	1.LORAN A/C		LOLAN C
	2. GRI CHAIN		8930
	3. TD DATA TD1		11
	4. DATA TD2		30
	5. TD CORR TD1		+0.0 μs
	6. TD2		+0.0 μs
7.VERSION			
8.LANGUAGE	1.LANGUAGE		ENGLISH

Main Menu	Sub Menu	Sub Menu	Default
0.EQUIP SET	1.DISPLAY TYPE		MAIN
	2.SENSOR No.		1(At shipment)
	3. CCRP	1.SHIP	DISABLE(At shipment)
		2.BEAM	1. 0m (At shipment)
		3.LENGTH	1. 0m (At shipment)
		4SENSOR	DISABLE(At shipment)
		5.X	0. 0m (At shipment)
		6.Y	0. 0m (At shipment)
		7.CCRP	DISABLE(At shipment)
		8.X	0. 0m (At shipment)
		9.Y	0. 0m (At shipment)
	4.CHECK		OFF
	5.RESET		OFF
	6.DEMO	1.DEMO TYPE	OFF
		2.DATE	
3.TIME			
4.LATITUDE			
5.LONGITUDE			
6.SPEED			
7.COURSE			
8.RADIUS			
9.ROUTE			
0.START			
7.DATA I/O	1.DATA IN/OUT1	NMEA(default)	1.VERSION: Ver2.3 2.BIT RATE: 4800bps 3.SENTENCE: GGA RMC VTG DTM ZDA APB RMB ACK (all interval 1s)
	JRC		
	IEC		1.BITRATE 4800bps 2.SENTENCE GGA RMC VTG DTM ZDA APB RMB ACK (all interval 1s)
	ROUTE		1.DATA IN/OUT: OUT 2.BIT RATE: 4800bps 3.FORMAT: NMEA Ver2.3 4.OUT TYPE: ROUTE+WPT
	PRINTER		1.BITRATE: 4800bps 2.INTERVAL: OFF
	SWITCH		
	2.DATA OUT2	NMEA (default)	1.VERSION: Ver2.3 2.BIT RATE: 4800bps 3.SENTENCE: GGA RMC VTG DTM ZDA APB RMB ACK (all interval 1s)

Main Menu	Sub Menu	Sub Menu	Default
		JRC	
		IEC	1.BITRATE 4800bps 2.SENTENCE GGA RMC VTG DTM ZDA APB RMB ACK (all interval 1s)
		ROUTE	1.BIT RATE: 4800bps 2.FORMAT: NMEA Ver2.3 3.OUT TYPE: ROUTE+WPT
		SWITCH	
	3.DATA OUT3	NMEA(default)	1.VERSION: Ver2.3 2.BIT RATE: 4800bps 3.SENTENCE: GGA RMC VTG DTM ZDA APB RMB ACK (all interval 1s)
		JRC	
		IEC	1.BITRATE 4800bps 2.SENTENCE GGA RMC VTG DTM ZDA APB RMB ACK (all interval 1s)
		ROUTE	1.BIT RATE: 4800bps 2.FORMAT: NMEA Ver2.3 3.OUT TYPE: ROUTE+WPT
		SWITCH	
	4.DATA IN/OUT4	NMEA(default)	1.VERSION: Ver2.3 2.BIT RATE: 4800bps 3.SENTENCE: GGA RMC VTG DTM ZDA APB RMB ACK (all interval 1s)
		JRC	
		IEC	1.BITRATE 4800bps 2.SENTENCE GGA RMC VTG DTM ZDA APB RMB ACK (all interval 1s)
		ROUTE	1.DATA IN/OUT: OUT 2.BIT RATE: 4800bps 3.FORMAT: NMEA Ver2.3 4.OUT TYPE: ROUTE+WPT
		SWITCH	

Main Menu	Sub Menu	Sub Menu	Default	
			EXT EQUIP	1.CURRENT LAYER-A LAYER:001 DATA No:ALL LAYER-B LAYER:002 DATA No:ALL LAYER-C LAYER:003 DATA No:ALL
	5.CONTACT OUTPUT 1		SYSTEM	
	6.CONTACT OUTPUT 2		ALARM ACK	
	7. LAN	ACTIVE ROUTE OFF	1.CONNECT MULTICAST	
		DATA ROUTE: SHARE		
		MUTUAL:OFF	1.CONNECT MULTICAST	
		DATA OUT : NMEA Ver2.3	1.CONNTECT: MULTICAST 2.TO IP: 0.0.0.0 (at shipment) 3.PORT NO: 0(at shipment) 4.FORMAT: NMEA Ver2.3 5.SENTENCE: OFF	
		REMOTE MAINTENANCE: OFF	1.CONNTECT: UNICAST 2.TO IP: 192.168.60.3 (at unicast) 3.PORT NO: 6001(at unicast) 4.INTERVAL: 1s	
	8.SOFT UPDATE	1.UPDATE AREA	DISPLAY	
		2.BIT RATE	SENSOR AUTO DISPLAY 115200bps	
		3.UPDATE STANDBY		
	9. IP	1. IP ADDR	MAIN SENSOR No.1 192.168.60.163 MAIN SENSOR No.2 192.168.60.164 MAIN SENSOR No.3 192.168.60.165 SUB SENSOR No.1 192.168.60.166 SUB SENSOR No.2 192.168.60.167 SUB SENSOR No.3 192.168.60.168	
		2.SUBNET MASK	255.255.255.0	
		3.DEFAYLT GATWAY	192.168.1.1	

**有毒有害物质或元素的名称及含量**  
(Names & Content of toxic and hazardous substances or elements)

形式名(Type): JLR-7800/7500

名称(Name): GPS Navigator

部件名称 (Part name)	有毒有害物质或元素 (Toxic and Hazardous Substances and Elements)					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr <sup>6+</sup> )	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
GPS接收器 (Antenna)	×	○	×	×	×	×
船内装置(Inboard Unit) ·显示装置(Display Unit) ·信号处理装置 (Processing Unit)	×	○	×	×	×	×
外部设备(Peripherals) ·选择(Options) ·电线类(Cables) ·手册(Documentnts)	×	○	×	×	×	×

○: 表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006 标准规定的限量要求以下。  
(Indicates that this toxic, or hazardous substance contained in all of the homogeneous materials for this part is below the requirement in SJ/T11363-2006.)

× : 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006 标准规定的限量要求。  
(Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T 11363-2006.)





アスベストは使用しておりません  
Not use the asbestos

CODE No.7ZPNA4137

For further information, contact:



*Japan Radio Co., Ltd.*

*Since 1915*

URL <http://www.jrc.co.jp>

Marine Service Department

Telephone : +81-3-3492-1305

Facsimile : +81-3-3779-1420

e-mail : [tmsc@jrc.co.jp](mailto:tmsc@jrc.co.jp)

AMSTERDAM Branch

Telephone : +31-20-658-0750

Facsimile : +31-20-658-0755

e-mail : [service@jrcams.nl](mailto:service@jrcams.nl)

SEATTLE Branch

Telephone : +1-206-654-5644

Facsimile : +1-206-654-7030

e-mail : [service@jrcamerica.com](mailto:service@jrcamerica.com)

01ETM

ISO 9001, ISO 14001 Certified

©JUL. 2009 Edition 2

JRC

Printed in Japan